

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [tectake](#) /

› **tectake Canton Computer Desk 800993 User Manual**

tectake 800993

tectake Canton Computer Desk 800993 User Manual

Model: 800993

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your tectake Canton Computer Desk 800993. Please read these instructions carefully before assembly and use to ensure safe and correct handling of the product. This computer desk is designed to provide a functional and stable workspace for home or office environments, featuring a spacious desktop and integrated side storage compartments.



Image 1.1: Overview of the tectake Canton Computer Desk 800993, showcasing its industrial light wood finish and integrated

shelving.

2. SAFETY WARNINGS

Warning: Assembly required. Exercise caution during mounting and when using the desktop.

- Ensure all components are present and undamaged before beginning assembly.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Do not overtighten screws, as this may damage the material.
- Keep small parts away from children during assembly.
- Periodically check all fasteners to ensure they remain tight.
- Do not exceed the maximum load capacities specified in the 'Specifications' section.
- Avoid placing hot items directly on the desktop surface without protection.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Desktop Panel (1)
- Steel Frame Components (various)
- Side Shelf Panels (2)
- Adjustable Feet (4)
- Assembly Hardware (screws, bolts, Allen key)
- Instruction Manual (this document)

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your tectake Canton Computer Desk. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface. Refer to the parts list to ensure everything is present.
2. **Assemble the Main Frame:** Connect the long horizontal steel bars to the vertical leg frames using the provided screws and Allen key. Ensure all connections are secure but do not fully tighten yet.
3. **Attach Side Shelf Supports:** Secure the steel supports for the side shelves to the main frame as indicated in the diagram.
4. **Install Side Shelf Panels:** Slide and secure the two side shelf panels onto their designated supports.




Image 4.1: Detailed view of the integrated side shelves, illustrating their placement within the desk frame.

5. **Attach Desktop Panel:** Carefully place the desktop panel onto the assembled frame. Align the pre-drilled holes on the desktop with the holes on the frame. Secure the desktop using the appropriate screws.



Image 4.2: An angled view of the assembled desk, showing the desktop attached to the steel frame and shelves.

6. **Install Adjustable Feet:** Screw the four adjustable plastic feet into the bottom of the desk legs.



Image 4.3: Close-up of an adjustable foot, demonstrating its leveling mechanism.

7. **Final Tightening and Leveling:** Once all components are in place, fully tighten all screws. Adjust the plastic feet to ensure the desk is stable and level on your floor.

5. OPERATING GUIDELINES

- **Placement:** Position the desk on a flat, stable surface. Avoid direct sunlight or extreme temperature changes to prevent material damage.
- **Load Capacity:** Do not exceed the maximum load capacity of 150 kg for the tabletop and 25 kg for each side compartment. Distribute weight evenly.
- **Cable Management:** Utilize the space behind the desk for organizing cables to maintain a tidy workspace.
- **Stability:** Regularly check the adjustable feet and tighten them if the desk becomes wobbly.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the engineered wood.
- **Fasteners:** Periodically inspect all screws and bolts and tighten them as necessary to maintain structural

integrity.

- **Protection:** Use coasters or protective pads under hot items or items that may scratch the surface.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly	Uneven floor; loose fasteners	Adjust the leveling feet; tighten all screws and bolts.
Parts are missing or damaged	Shipping error; manufacturing defect	Contact tectake customer support with your purchase details.
Difficulty during assembly	Incorrect step sequence; misaligned parts	Review the assembly instructions carefully; ensure parts are correctly oriented before tightening.

8. SPECIFICATIONS

Model: 800993

Brand: tectake

Color: Industrial Light Wood

Material: Engineered Wood, Alloy Steel

Total Dimensions (W x D x H): Approximately 120 x 60 x 75.5 cm

Top Side Compartments (W x D x H): Approximately 20 x 58 x 34 cm

Bottom Side Compartment (W x D x H): Approximately 20 x 58 x 30 cm

Steel Body Dimensions: Approximately 2 x 2 cm

Adjustable Plastic Feet Height: Approximately 1.5 cm

Tabletop Load Capacity: 150 kg

Each Side Compartment Load Capacity: 25 kg

Item Weight: 15 kg

Special Features: Adjustable feet



Image 8.1: Detailed diagram illustrating the dimensions of the tectake Canton Computer Desk.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please contact your retailer or the manufacturer, tectake. Please have your purchase receipt and model number (800993) available when contacting support.

Manufacturer: tectake

Seller: TecTake Sweden AB

