

## YVV BK-120MM

# YVV Motorized Rotating Display Stand (BK-120MM) Instruction Manual

**Model:** BK-120MM | **Brand:** YVV

## INTRODUCTION

The YVV Motorized Rotating Display Stand, model BK-120MM, is designed to showcase various items with a smooth, 360-degree rotation. It is ideal for displaying products, collectibles, epoxy glitter tumblers, jewelry, and for use in photography or video recording. This stand offers quiet operation and flexible power options, making it a versatile tool for both personal and professional use.

## WHAT'S IN THE BOX

Upon opening your YVV Motorized Rotating Display Stand package, you should find the following components:

- 1 x YVV Motorized Rotating Display Stand (BK-120MM)
- 1 x USB Data Cable
- 1 x Silicone Anti-slip Mat (Blue)
- 1 x Instruction Manual

*Note: 3 x AA batteries are required for battery operation and are not included in the package.*

Your browser does not support the video tag.

**Video:** Unboxing and initial setup of the YVV Motorized Rotating Display Stand, showing included components and basic functionality.

## SETUP

### Power Supply

The YVV Motorized Rotating Display Stand offers two power options:

1. **USB Power:** Connect the provided USB data cable to the DC-5V port on the side of the stand and plug the other end into a USB power source (e.g., laptop, power bank, USB wall adapter).
2. **Battery Power:** Open the battery compartment on the bottom of the stand and insert 3 x AA batteries (not included),

ensuring correct polarity.

**Important:** Do not use both USB power and batteries simultaneously. This can damage the device.



**Image:** Illustration of the multiple power supply options for the display stand, including USB cable connection and battery insertion.

## Placing an Item

Place the blue silicone anti-slip mat on the top surface of the rotating stand. Carefully center the item you wish to display on the mat. The mat helps prevent items from sliding during rotation.

# Power Supply Mode



USB Plug



Mobile Power



3\*AA Battery



Image: A tumbler placed on the blue silicone mat of the rotating display stand, ready for display.

## OPERATING INSTRUCTIONS

### Power On/Off and Rotation Direction

Locate the switch on the side of the display stand. This switch controls the power and rotation direction:

- **CW (Clockwise):** Slide the switch to the left. The indicator light will turn green, and the stand will rotate clockwise.
- **OFF:** Slide the switch to the center position to turn off the stand.
- **CCW (Counter-Clockwise):** Slide the switch to the right. The indicator light will turn blue, and the stand will rotate counter-clockwise.

## 360° rotation



**Green Light**

**Turn left:**

**Clockwise rotating**



**Blue Light**

**Turn right:**

**Counterclockwise rotating**

**Image:** Close-up of the display stand's control switch, illustrating the clockwise (CW), off, and counter-clockwise (CCW) settings with corresponding green and blue indicator lights.

Your browser does not support the video tag.

**Video:** Demonstrates the operation of the CW/OFF/CCW switch and the resulting rotation direction of an item on the stand.


### Rotation Speed

The display stand rotates at a fixed speed of approximately 15 seconds per full circle. There are no adjustable speed settings.

### KEY FEATURES

- **360° Automatic Rotation:** Continuously rotates to display items from all angles.
- **Smooth and Quiet Operation:** Designed for silent rotation, making it suitable for video recording and quiet environments.
- **High Load Capacity:** Can support items up to 80 ounces (approximately 4.4 pounds).
- **Non-slip Base and Mat:** Equipped with five anti-skid pads on the bottom and a removable silicone mat on top to ensure stability and prevent items from slipping.

- **Dual Power Options:** Can be powered via USB cable (DC-5V) or 3 x AA batteries for flexible use.
- **Compact Design:** With a diameter of 4.72 inches (12 cm) and a height of 1.77 inches (4.5 cm), it is portable and fits well in various display settings.
- **Directional Control:** Easily switch between clockwise and counter-clockwise rotation.



(Five anti-skid pads at the bottom, 360° anti-skid, can prevent the turntable from sliding when rotating, ensuring safe use.)

**Image:** Visual summary of the display stand's key features including 360 rotation, load capacity, low power consumption, quiet operation, and dimensions.

## SPECIFICATIONS

| Feature      | Detail              |
|--------------|---------------------|
| Brand        | YVV                 |
| Model Number | ND-BLACK (BK-120MM) |
| Color        | Black               |
| Material     | Resin               |

| Feature                  | Detail                                   |
|--------------------------|------------------------------------------|
| Diameter                 | 4.72 inches (12 cm)                      |
| Height                   | 1.77 inches (4.5 cm)                     |
| Item Weight              | 10.6 ounces (0.3 kg)                     |
| Maximum Recommended Load | 80 ounces (4.4 pounds)                   |
| Power Supply             | USB (DC-5V) or 3 x AA Batteries          |
| Rotation Speed           | Approx. 15 seconds per circle            |
| Rotation Direction       | Clockwise (CW) / Counter-Clockwise (CCW) |
| Special Feature          | 360 degree rotation, Mute operation      |

## MAINTENANCE

To ensure the longevity and optimal performance of your YVV Motorized Rotating Display Stand, follow these maintenance guidelines:

- **Cleaning:** Wipe the surface of the stand and the silicone mat with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Storage:** When not in use, store the display stand in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If using batteries, remove them if the stand will not be used for an extended period to prevent leakage and potential damage.
- **Load Capacity:** Do not exceed the maximum recommended load of 80 ounces (4.4 pounds) to prevent motor strain and damage.

## TROUBLESHOOTING

If you encounter any issues with your YVV Motorized Rotating Display Stand, please refer to the following common solutions:

| Problem                            | Possible Cause                                                            | Solution                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Stand is not rotating.             | No power, incorrect power source, switch in OFF position, dead batteries. | <ul style="list-style-type: none"><li>◦ Ensure USB cable is securely connected to a working power source.</li><li>◦ If using batteries, check if they are inserted correctly and are not depleted. Replace if necessary.</li><li>◦ Verify the switch is set to CW or CCW, not OFF.</li><li>◦ Do not use USB and batteries simultaneously.</li></ul> |
| Rotation is intermittent or stops. | Insufficient power, overloaded, obstruction.                              | <ul style="list-style-type: none"><li>◦ Ensure the power source provides stable DC-5V. Some power banks may have auto-shutoff for low current devices.</li><li>◦ Reduce the weight of the item on the stand; ensure it does not exceed 80 ounces (4.4 pounds).</li><li>◦ Check for any objects obstructing the rotation mechanism.</li></ul>        |

| Problem                               | Possible Cause                                    | Solution                                                                                                                                                                                                                       |
|---------------------------------------|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Stand is making unusual noise.</b> | Overloaded, internal obstruction, uneven surface. | <ul style="list-style-type: none"><li>◦ Reduce the load on the stand.</li><li>◦ Ensure the stand is placed on a flat, stable surface.</li><li>◦ Check for any foreign objects that might have entered the mechanism.</li></ul> |

## WARRANTY AND SUPPORT

YVV stands behind the quality of its products. For warranty information, technical support, or any other inquiries, please contact YVV customer service through the retailer where you purchased the product or visit the official YVV store online.

**YVV Store:** [Visit the YVV Store on Amazon](#)

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

#### Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

#### Details

Submit question