onerbl AC Power Cord

onerbl AC Power Cord Replacement Instruction Manual

For Black & Decker PPRH5B SEL Portable Professional Power Station, B&D BD Jump-Starter, and Compressor

1. Introduction

This manual provides essential instructions for the proper use, installation, and maintenance of your onerbl AC Power Cord. This product is designed as a direct replacement for the original power cord of compatible Black & Decker portable power stations, jump-starters, and compressors. Please read this manual thoroughly before use to ensure safe and effective operation.

2. Product Overview

The onerbl AC Power Cord is a high-quality replacement cable engineered for durability and reliable performance. It features a standard two-prong AC plug on one end and a two-slot (figure-8) connector on the other, designed to fit compatible devices.



Image 2.1: The onerbl AC Power Cord, illustrating the standard two-prong wall plug and the two-slot device connector.

2.1 Key Features

- **High-Quality Construction:** Manufactured with durable materials for extended lifespan.
- **Tested Units:** Each cord is tested to ensure proper working condition.
- **Durable Design:** Engineered for resilience, featuring a 10,000+ bend lifespan.
- **Copper Wire Core:** Utilizes copper wiring for efficient power transmission.
- **PVC Jacket:** Protected by a robust PVC jacket for insulation and durability.



Image 2.2: Close-up view of the power cord connectors, highlighting the robust design and flexibility for a 10,000+ bend lifespan.




Image 2.3: An illustrative diagram detailing the internal copper wire and protective PVC jacket, emphasizing the quality

control and durable construction of the power cord.

3. Compatibility

This onerbl AC Power Cord is specifically designed as a replacement for the following Black & Decker models:

- Black & Decker PPRH5B SEL Portable Professional Power Station
- Black & Decker BD Jump-Starter models (requiring a two-slot AC input)
- Black & Decker Compressor models (requiring a two-slot AC input)

Please verify that your device requires a two-slot (figure-8) AC power cord before purchase and use.

4. Setup and Installation

Follow these steps to properly install the AC power cord:

1. **Ensure Device is Off:** Before connecting or disconnecting any cables, ensure your Black & Decker power station, jump-starter, or compressor is turned off and disconnected from any power source.
2. **Connect to Device:** Insert the two-slot (figure-8) end of the onerbl AC Power Cord firmly into the AC input port of your compatible Black & Decker device.
3. **Connect to Power Outlet:** Plug the two-prong end of the AC Power Cord into a standard, grounded 120V AC wall outlet.
4. **Verify Connection:** Ensure both ends of the cord are securely connected.

5. Operation

Once the onerbl AC Power Cord is securely connected to both your device and a power outlet, you can operate your Black & Decker unit according to its specific instruction manual. The power cord facilitates the transfer of AC power from the wall outlet to your device for charging or operation.

6. Safety Information

Adhere to the following safety guidelines when using the AC power cord:

- Do not use the power cord if it is damaged, frayed, or has exposed wires.
- Do not overload electrical outlets.
- Keep the power cord away from water, heat sources, and sharp objects.
- Always grasp the plug, not the cord, when disconnecting from an outlet.
- Ensure the power cord is fully inserted into both the device and the wall outlet.
- This cord is for indoor use or in dry conditions only.

7. Maintenance

Proper care will extend the life of your onerbl AC Power Cord:

- **Cleaning:** Wipe the cord with a dry, soft cloth. Do not use liquid cleaners.

- **Storage:** Store the cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cord sharply.
- **Inspection:** Periodically inspect the cord for any signs of damage, such as cuts, abrasions, or bent prongs. Discontinue use immediately if damage is found.

8. Troubleshooting

If your device does not power on or charge after connecting the onerbl AC Power Cord:

- **Check Connections:** Ensure both ends of the power cord are securely and fully inserted into the device and the wall outlet.
- **Test Outlet:** Plug another working appliance into the same wall outlet to confirm the outlet is functional.
- **Inspect Cord:** Visually inspect the power cord for any visible damage. If damaged, replace it.
- **Device Issue:** If the cord and outlet are confirmed to be working, the issue may lie with the Black & Decker device itself. Refer to your device's manual for further troubleshooting.

9. Specifications

Feature	Description
Brand	onerbl
Model	AC Power Cord Replacement
Color	Black
Connector Gender	Male-to-Male (AC plug to device connector)
Total Power Outlets	1 (Refers to the single device connection point)
Special Feature	Travel-friendly design
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Cable Length Options	Available in 10 ft and 6.6 ft lengths
Durability	10,000+ bend lifespan



Image 9.1: Illustration of the available cable lengths, including 10 ft and 6.6 ft options, demonstrating the extended cord design.

10. Warranty and Support

For information regarding warranty coverage, returns, or technical support for your onerbl AC Power Cord, please refer to the seller or manufacturer's official website. Keep your purchase receipt as proof of purchase.

© 2023 onerbl. All rights reserved.