Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 19V 3.42A 65W AC/DC Adapter

onerbl 19V 3.42A 65W AC/DC Adapter Instruction Manual

Model: 19V 3.42A 65W AC/DC Adapter

1. Introduction and Overview

This manual provides essential instructions for the safe and effective use of your onerbl 19V 3.42A 65W AC/DC Adapter. This adapter is designed as a high-quality replacement power supply for various electronic devices, including specific Medion Akoya laptop models and other compatible equipment requiring 19V output at 3.42A (65W).

Please read this manual thoroughly before using the product to ensure proper operation and to prevent damage to the adapter or your connected devices.

2. Safety Instructions

To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions:

- Use the adapter only with devices that match its voltage (19V) and current (3.42A) specifications. Exceeding these limits can damage your device or the adapter.
- Do not expose the adapter to water, rain, or excessive moisture.
- Avoid using the adapter in extremely hot or cold environments. Ensure adequate ventilation around the adapter during use.
- Do not open or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the power cord is not frayed, cut, or damaged. Replace damaged cords immediately.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- This adapter features built-in protections against over-voltage, over-current, and short-circuit conditions to safeguard your devices.

3. Package Contents

Verify that all items are present in your package:

- 1 x onerbl 19V 3.42A 65W AC/DC Adapter Unit
- 1 x AC Power Cord (for wall outlet connection)



Image: The included AC power cord, featuring a standard two-prong plug for wall outlets and a figure-8 connector for the adapter unit.

4. Product Features

- **Universal Input:** AC 100-240V, 50/60Hz, allowing for worldwide compatibility.
- **Output:** DC 19V, 3.42A, 65W.
- **Extended Cable Length:** Approximately 10 feet (3 meters) total cable length for flexible placement.
- **Multiple Protection Features:** Includes over-voltage protection, over-heat protection, over-current protection, and short-circuit protection for enhanced safety and device longevity.
- **Durable Design:** Constructed with quality materials, including copper wire, for reliable performance.



Image: Visual representation of the adapter's integrated safety features, including protection against short-circuits, over-voltage, and over-current.




Image: Illustration highlighting the durable construction of the adapter, including the use of copper wire for efficient power transmission.




Image: Depiction of the adapter's extended cable length, offering greater flexibility for connecting to devices from a power outlet.

5. Setup

Follow these steps to set up your AC/DC adapter:

1. **Connect the AC Power Cord:** Insert the figure-8 connector of the AC power cord firmly into the corresponding port on the adapter unit.
2. **Connect to Wall Outlet:** Plug the two-prong end of the AC power cord into a standard wall electrical outlet (AC 100-240V).
3. **Connect to Device:** Insert the DC output connector of the adapter into the power input port of your compatible electronic device (e.g., laptop). Ensure the connector is fully seated.
4. **Verify Power:** Once connected, the adapter's indicator light (if present) should illuminate, and your device should begin charging or power on.



Image: The AC adapter properly connected to a wall outlet and supplying power to a laptop, demonstrating a typical setup.

6. Operating Instructions

Once properly set up, the adapter operates automatically:

- The adapter converts the AC wall power to the required DC 19V for your device.
- It will supply power to your device and charge its battery (if applicable).
- Always ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Disconnect the adapter from the device and wall outlet when moving your device or when the adapter is not needed.

7. Maintenance

Proper maintenance ensures the longevity and performance of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly winding the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter unit and cables for any signs of damage, such as cuts, fraying, or bent pins. If damage is found, discontinue use and replace the adapter.

8. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

- **No Power to Device:**
  - Ensure all cable connections are secure at both the wall outlet, the adapter unit, and your device.
  - Check if the wall outlet is functional by plugging in another device.
  - Verify that the adapter's indicator light is on. If not, check connections again.
- **Device Not Charging:**
  - Confirm that your device's power input port is clean and free of debris.
  - Ensure the adapter's output specifications (19V, 3.42A) match your device's requirements.
  - If your device has a removable battery, try reseating it.
- **Adapter Overheating:**
  - Ensure the adapter is in a well-ventilated area and not covered by objects.
  - Verify that the adapter's output matches your device's power requirements. An undersized adapter can overheat.
  - If overheating persists, discontinue use and seek assistance.

If these steps do not resolve the issue, contact customer support for further assistance.

9. Specifications

Specification	Value
Brand	onerbl
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 19V

Specification	Value
Output Current	3.42A
Output Power	65W
Cable Length	Approximately 10 feet (3 meters)
Item Dimensions (L x W x H)	6 x 4 x 2 inches (Adapter Unit)
Power Source	Corded Electric
Manufacturer	Shenzhen Waweis Technology Co., Ltd
ASIN	B09Z6HN663




Image: Detailed diagram illustrating the physical dimensions of the adapter unit and its connected cables.

Compatible Devices (Partial List)

This adapter is compatible with various devices requiring 19V 3.42A 65W power, including but not limited to:

- Medion Akoya P4020, P6210, P6611, P6624, P6627
- Medion MD95400, MD97900, MD98000, MD97610, MD97600, MD97500, MD98200, MD96910, MD-9494AK
- FSP FSP065-AAC, FSP065-ASC, FSP065-REB
- Other devices such as certain set-top boxes, routers, batteries, LED strips, oxygen machines, humidifiers, cameras,

and game players that match the voltage and current specifications.



Image: An illustrative diagram showcasing a wide range of electronic devices that can be powered by this adapter, provided their power requirements match.

10. Warranty and Support

Specific warranty information is not provided in this document. For details regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact the seller directly. The seller for this product is GreatComputerParts.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Z6HN663

More documents and user manuals: **https://manuals.plus/**