

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Phomemo](#) /

› [Phomemo D30 Label Maker User Manual](#)

Phomemo D30

Phomemo D30 Label Maker User Manual

Model: D30

INTRODUCTION

This manual provides instructions for the safe and efficient operation of your Phomemo D30 Label Maker. Please read this manual thoroughly before using the device to ensure proper setup, usage, and maintenance. The Phomemo D30 is a portable, inkless thermal label printer designed for various labeling needs, connecting wirelessly via Bluetooth to your smartphone.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Phomemo D30 Mini Label Maker
- 3 x Clear Thermal Label Tapes
- 1 x White Thermal Label Tape
- 1 x USB Charging Cable
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The Phomemo D30 is a compact and lightweight label printer. It features a power button, a charging port, and a label output slot.



Easy to Use One-click Printing



Download from
App Store



GET IT ON
Google Play

The Phomemo D30 label maker connects wirelessly to your smartphone via Bluetooth. The 'Print Master' app allows for easy label creation and one-click printing. Download the app from the App Store or Google Play.

SETUP

1. Charging the Device

Before first use, fully charge the Phomemo D30 label maker. Connect the provided USB charging cable to the charging port on the device and to a standard USB power adapter (not included). The indicator light will show charging status.

2. App Installation

Download the "Print Master" application from your smartphone's app store. Search for "Print Master" on the Apple App Store for iOS devices or Google Play Store for Android devices.

3. Bluetooth Connection


1. Ensure your Phomemo D30 is powered on.

2. Enable Bluetooth on your smartphone.
3. Open the "Print Master" app.
4. Within the app, search for available devices and select "D30" to connect. The indicator light on the printer will confirm a successful connection.

4. Loading Label Roll

To load a label roll:

1. Open the cover of the label maker.
2. Insert the label roll with the printing surface facing upwards and the label edge extending slightly out of the printer slot. Ensure the roll is seated correctly.
3. Close the cover firmly until it clicks into place.



This diagram illustrates the specifications of the D30 thermal label tape, including dimensions (14mm x 30mm), quantity per roll (210 labels), and key features such as BPA-free material, strong adhesion, and resistance to abrasion and water.

OPERATING INSTRUCTIONS

1. Creating Labels

Open the "Print Master" app on your smartphone. You can choose from a variety of pre-designed templates or create custom labels using the app's editing tools. The app offers over 300 symbols, 60 frames, and various fonts to personalize your labels.



The Phomemo D30 utilizes thermal printing technology to produce clear, crisp labels. This image shows the printer in action, highlighting the quality of the printed text.

2. Printing Labels

Once your label design is complete in the "Print Master" app, tap the "Print" button. The label maker will print the label. Carefully tear off the printed label from the output slot.

3. Label Applications

The D30 label maker is suitable for various applications, including price tags, cable identification, personal item identification, and food date marking.



Labels printed with the Phomemo D30 can be used for organizing kitchen items like spice jars, providing clear identification with black text on translucent tape.



The D30 label maker is suitable for labeling small compartments, such as those in a pill organizer, to help with daily organization and identification of contents.

MAINTENANCE

1. Cleaning the Print Head

To maintain print quality, regularly clean the print head. Use a cotton swab lightly dampened with isopropyl alcohol to gently wipe the print head. Ensure the device is turned off and completely dry before use.

2. Storage

Store the Phomemo D30 in a cool, dry place away from direct sunlight and extreme temperatures. Remove the label roll if the device will not be used for an extended period.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to a power source and wait for the charging indicator.
- **Cannot connect via Bluetooth:**
 - Ensure Bluetooth is enabled on your smartphone.
 - Make sure the "Print Master" app is open and attempting to connect.
 - Restart both the label maker and your smartphone.
 - Ensure the label maker is within Bluetooth range.
- **Poor print quality:**
 - Check if the label roll is loaded correctly with the printing surface facing up.
 - Clean the print head as described in the Maintenance section.
 - Ensure you are using genuine Phomemo D30 thermal labels.
- **Labels not feeding correctly:**
 - Verify the label roll is inserted properly and not jammed.
 - Ensure the label roll is not empty.

SPECIFICATIONS

Model Name	D30
Brand	Phomemo
Control Method	App
Connectivity Technology	Bluetooth
Printing Technology	Thermal
Special Feature	Portable
Printer Output	Monochrome
Controller Type	iOS, Android (via app)
Print Media	Labels
Compatible Devices	Smartphones

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

This video provides a visual guide to the Phomemo D30 Label Maker, showcasing its compact design, app connectivity, and various applications for home and office organization.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your Phomemo D30 Label Maker, please refer to the official Phomemo website or contact their customer service directly. Contact details are typically available on the product packaging or the official brand website.



