

[Manuals.plus](#) /

> [Ingco](#) /

> Ingco 20V Battery Vacuum Cleaner CVLI2001 User Manual

## Ingco CVLI2001

# Ingco 20V Battery Vacuum Cleaner CVLI2001 User Manual

Model: CVLI2001

## 1. INTRODUCTION

---

Thank you for choosing the Ingco 20V Battery Vacuum Cleaner, model CVLI2001. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and keep it for future reference. This product is designed for dry vacuuming applications.

## 2. GENERAL SAFETY INSTRUCTIONS

---

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions carefully before operating the appliance.
- Do not use the vacuum cleaner outdoors or on wet surfaces. This appliance is for dry use only.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Use only Ingco 20V batteries and chargers specifically designed for this product. Using other batteries or chargers may create a risk of injury and fire.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filter in place.
- Turn off the appliance before connecting or disconnecting the battery pack.
- Store the vacuum cleaner indoors in a dry place.

## 3. PACKAGE CONTENTS

---

Please check the package contents to ensure all items are present and undamaged:

- Ingco 20V Battery Vacuum Cleaner Unit (CVLI2001)
- Crevice Nozzle
- Brush Nozzle

- Extension Tube
- Flexible Hose
- Floor Nozzle



Figure 3.1: Ingco 20V Battery Vacuum Cleaner with all included accessories, including the main unit, crevice nozzle, brush nozzle, extension tube, flexible hose, and floor nozzle.

## 4. SETUP AND ASSEMBLY

---

### 4.1 Battery Installation (Battery and Charger Sold Separately)

The Ingco CVLI2001 vacuum cleaner operates on a 20V lithium-ion battery. Please note that the battery and charger are typically sold separately. Ensure you use a compatible Ingco 20V battery and charger.

1. Align the battery pack with the battery port on the vacuum cleaner handle.
2. Slide the battery pack into the port until it clicks securely into place.
3. To remove the battery, press the release button on the battery pack and slide it out.



Figure 4.1: The main Ingco 20V Battery Vacuum Cleaner unit, ready for battery insertion and accessory attachment.

## 4.2 Attaching Accessories

Various accessories can be attached directly to the vacuum's suction inlet or to the extension tube/flexible hose for different cleaning tasks.

- **Crevice Nozzle:** Ideal for reaching tight spaces, corners, and edges. Push it firmly onto the suction inlet.
- **Brush Nozzle:** Useful for dusting surfaces, upholstery, and delicate items. Attach it to the suction inlet or the crevice nozzle.
- **Extension Tube:** Connects to the suction inlet to extend reach for floors or high areas.
- **Flexible Hose:** Provides flexibility for cleaning awkward angles or inside vehicles. Attach to the suction inlet, then attach other nozzles to the hose.
- **Floor Nozzle:** Designed for cleaning larger floor areas. Attach to the extension tube or flexible hose.



Figure 4.2: The Ingco 20V Battery Vacuum Cleaner with the extension tube attached, suitable for extended reach.



Figure 4.3: The Ingco 20V Battery Vacuum Cleaner configured with the extension tube and floor nozzle for cleaning larger surfaces.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Powering On/Off

The vacuum cleaner features a touch control method for operation.

1. Ensure the battery is fully charged and securely installed.
2. Press the power button (touch control) located on the handle to turn the vacuum cleaner ON.
3. Press the power button again to turn the vacuum cleaner OFF.

### 5.2 Vacuuming Techniques

Select the appropriate nozzle for the cleaning task. For general surfaces, the brush nozzle is effective. For tight gaps, use the crevice nozzle. For floors, attach the extension tube and floor nozzle.

### 5.3 Emptying the Dust Container

For optimal suction and performance, empty the dust container regularly, especially when it appears full.

1. Ensure the vacuum cleaner is turned OFF and the battery is removed.
2. Locate the dust container release button or latch, typically near the main body of the vacuum.
3. Press the release and carefully detach the dust container from the main unit.
4. Empty the contents into a waste bin.
5. Reattach the dust container, ensuring it clicks securely into place.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your vacuum cleaner.

### 6.1 Cleaning the Dust Container

After emptying, the dust container can be wiped clean with a damp cloth. Ensure it is completely dry before reattaching.

### 6.2 Filter Cleaning/Replacement

The Ingco CVLI2001 uses a cloth filter. A clean filter is crucial for maintaining suction power.

1. With the dust container removed, carefully take out the cloth filter.
2. Gently tap the filter over a waste bin to dislodge dust and debris.
3. If heavily soiled, the cloth filter can be hand-washed in cool water. Do not use harsh detergents.
4. Allow the filter to air dry completely for at least 24 hours before reinserting. Do not use a wet filter.
5. Replace the filter if it is damaged or if suction power remains low after cleaning.

### 6.3 General Cleaning

Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure no water enters the motor housing.

## 7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

| Problem                        | Possible Cause                                                                    | Solution                                                                                            |
|--------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Vacuum does not turn on        | Battery not installed correctly<br>Battery discharged<br>Power button malfunction | Ensure battery is securely clicked in<br>Charge the battery fully<br>Contact customer support       |
| Low suction power              | Dust container full<br>Filter clogged<br>Nozzle/hose blocked                      | Empty dust container<br>Clean or replace filter<br>Check and clear any blockages in nozzles or hose |
| Unusual noise during operation | Blockage in suction path<br>Damaged motor (rare)                                  | Check for and remove any blockages<br>Discontinue use and contact customer support                  |

## 8. TECHNICAL SPECIFICATIONS

The following are the technical specifications for the Ingco 20V Battery Vacuum Cleaner CVLI2001:

| Feature            | Specification          |
|--------------------|------------------------|
| Brand              | Ingco                  |
| Model              | CVLI2001               |
| Power Source       | Battery Powered        |
| Voltage            | 20 Volts               |
| Wattage            | 120 watts              |
| Item Weight        | 0.21 Kilograms (209 g) |
| Product Dimensions | 10 x 20 x 37 cm        |
| Filter Type        | Cloth                  |
| Special Features   | Spotless Cleaning      |
| Control Method     | Touch                  |

## 9. WARRANTY AND CUSTOMER SUPPORT

Ingco products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official Ingco website. If you encounter any issues not covered in this manual or require further assistance, please contact Ingco customer support through their official channels.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B09Z7GH76W>

More documents and user manuals: <https://manuals.plus/>