

PXLISIE HairT

PXLISIE Professional Cordless Hair Trimmer User Manual

Model: HairT

Brand: PXLISIE

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your PXLISIE Professional Cordless Hair Trimmer. Please read these instructions thoroughly before first use and retain for future reference.

2. WHAT'S INCLUDED

Your PXLISIE Professional Cordless Hair Trimmer package includes:

- PXLISIE Professional Cordless Hair Trimmer (Model: HairT)
- USB Charging Cable
- 4 Guide Combs (1.5mm, 2mm, 3mm, 4mm)
- Cleaning Brush
- Blade Oil



Professional Hair Trimmer

Image: The PXLISIE Professional Cordless Hair Trimmer shown with its included accessories: USB charging cable, four guide combs, cleaning brush, and blade oil.

3. PRODUCT FEATURES

- **T-Blade Trimmer:** Features a carbon steel and self-sharpening ceramic blade for precise trimming of hair, beard, sideburns, face, and body hair. The R-shaped obtuse edge design ensures gentle contact with the skin.
- **Multifunctional Use:** Ideal for hair cutting, beard trimming, and creating sharp lines.
- **USB Quick Charge:** Equipped with a powerful Lithium-ion battery, providing at least 180 minutes of working time after a 2.5-hour full charge. The cordless design offers convenience for travel and home use. Compatible with USB adapters, laptops, car chargers, and power banks.
- **Powerful Motor:** The beard trimmer features a powerful rotary motor for quick and even trimming with low noise.
- **Ergonomic Design:** Stylish, lightweight, and comfortable to hold with an all-metal body for durability.



Image: A detailed view highlighting the carbon steel cutter head, sharp blade, all-metal body, powerful motor, ON/OFF button, and charging port of the PXLISIE Hair Trimmer.

4. SAFETY INFORMATION

- Keep water away from the body of the trimmer. Only the cutter head can be washed with water.
- Do not immerse the entire unit in water.
- Keep out of reach of children.
- Ensure the trimmer is fully charged before each use for optimal performance and to prevent pulling hair.

5. SETUP

5.1 Initial Charging

Before first use, and before each subsequent use, ensure the trimmer is fully charged. Connect the provided USB charging cable to the charging port at the bottom of the trimmer and plug the other end into a compatible USB power

source (e.g., USB adapter, laptop, power bank).

- Charging Time: Approximately 2.5 hours for a full charge.
- Operating Time: Up to 180 minutes on a full charge.



Image: The PXLISIE Hair Trimmer being charged via its USB cable connected to a laptop. The image indicates 2 hours cordless use and 2 hours charge time.

5.2 Attaching Guide Combs

Select the desired guide comb (1.5mm, 2mm, 3mm, or 4mm) based on the hair length you wish to achieve. Align the comb with the trimmer blade and gently push it into place until it clicks securely.



Image: The PXLISIE Hair Trimmer displayed alongside its four guide combs (1.5mm, 2mm, 3mm, 4mm) and a larger comb attachment.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

To turn the trimmer on, press the power button located at the bottom of the unit. The blue light will illuminate, and the trimmer will begin to vibrate. To turn it off, press the power button again.

Note: The trimmer operates with low noise and low vibration for a comfortable experience.



Image: The PXLISIE Hair Trimmer next to a graphic indicating quiet operation (below 55dB), with a sleeping baby and mother in the background.

6.2 Trimming Hair

Hold the trimmer firmly and move it against the direction of hair growth. Use the guide combs for desired hair lengths. For precise edging and detailing, remove the guide comb and use the T-blade directly, ensuring gentle contact with the skin.

Tip: For best results, ensure hair is clean and dry before trimming.

7. MAINTENANCE

7.1 Cleaning the Blades

After each use, turn off the trimmer and remove any attached guide comb. Use the provided cleaning brush to remove loose hairs from the blade area. The cutter head can be rinsed under running water. Ensure no water enters the main body of the trimmer.



Image: The PXLISIE Hair Trimmer with its blade being rinsed under water, illustrating its waterproof blade feature.

7.2 Oiling the Blades

Regularly apply a small drop of the included blade oil to the trimmer blades to maintain optimal performance and longevity. Turn the trimmer on for a few seconds after oiling to distribute the oil evenly.

8. TROUBLESHOOTING

If you encounter any issues with your PXLISIE Professional Cordless Hair Trimmer, please refer to the following common solutions:

- **Trimmer not turning on:** Ensure the battery is fully charged. Connect the USB charging cable and allow it to charge for 2.5 hours.
- **Trimmer pulling hair:** This often indicates a low battery. Recharge the trimmer fully. Also, ensure the blades are clean and oiled.
- **Reduced cutting performance:** Clean the blades thoroughly with the brush and rinse the cutter head. Apply blade

oil. If the issue persists, the blades may need professional sharpening or replacement.

For further assistance, please contact PXLISIE customer support.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	5.31 x 2.17 x 7.28 inches
Item Model Number	HairT
Weight	7.05 ounces
Battery Type	Lithium-Ion (1 AAA battery required, likely internal)
Charging Time	2.5 Hours
Included Components	Trimmer, USB Charging Cable, 4 Guide Combs, Cleaning Brush, Blade Oil
Blade Material	Carbon Steel and Self-Sharpening Ceramic

10. OFFICIAL PRODUCT VIDEOS

Watch these official videos from the seller for additional guidance and demonstrations:

Professional beard trimmer Hair clipper for Men

Your browser does not support the video tag.

Video: A demonstration of the PXLISIE Professional Cordless Hair Trimmer, showcasing its features and use for beard trimming and hair clipping.

Hair clipper & Beard trimmer for men

Your browser does not support the video tag.

Video: This video provides a visual guide on using the hair clipper and beard trimmer for men, demonstrating its versatility.

T-Bladed Cordless Beard Trimmer for Men

Your browser does not support the video tag.

Video: A detailed look at the T-bladed cordless beard trimmer, showing its design and functionality for men's grooming.

11. WARRANTY & SUPPORT

For warranty information or customer support, please refer to the product packaging or contact PXLISIE directly through their official channels. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question