

PXLISIE HairT8-Gold

PXLISIE Hair Trimmer T Blade

CORDLESS RECHARGEABLE HAIR CUTTING KIT INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the PXLISIE Hair Trimmer T Blade. This professional-grade cordless hair cutting kit is designed for precision grooming, offering versatility for hair, beard, sideburns, face, and body hair. This manual provides essential information for safe and effective use, maintenance, and troubleshooting to ensure optimal performance of your device.

2. Safety Information

- **Water Exposure:** Only the cutter head can be washed with water. Do not allow water to enter the main body of the trimmer.
- **Charging:** Use only the provided USB charging cable. Ensure the charging port is dry before connecting.
- **Storage:** Store the trimmer in a dry place, away from direct sunlight and extreme temperatures.
- **Children:** Keep out of reach of children. This device is not a toy.
- **Damage:** Do not operate the trimmer if it is damaged or malfunctioning. Contact customer support for assistance.

3. Package Contents

Verify that all items are present in your package:

- PXLISIE Hair Trimmer T Blade (Gold)
- Guide Combs (1.5mm, 2mm, 3mm, 4mm)
- USB Charging Cable
- Cleaning Brush

- Ear Spoon Tool Set



Image 1: PXLISIE Hair Trimmer T Blade and included accessories, featuring the gold trimmer, four guide combs, USB charging cable, cleaning brush, and an ear spoon tool set.

4. Product Features

- **T Blade Trimmer:** The professional T-blade is crafted from carbon steel and self-sharpening ceramic, designed for precise trimming of hair, beard, sideburns, face, and body hair. Its R-shaped obtuse edge ensures gentle contact with the skin, minimizing irritation.
- **USB Quick Charge:** Equipped with a powerful Lithium-ion battery, the trimmer provides up to 180 minutes of cordless operation after a full 2.5-hour charge. The cordless design enhances portability, making it ideal for travel or home use. It can be charged via USB adapter, laptop, car charger, or power bank.
- **Powerful Motor:** The beard trimmer features a robust rotary motor for quick and efficient trimming. It operates with strong power and low noise levels (below 55dB), ensuring a smooth and quiet grooming experience.
- **Multifunctional Hair Cutting Trimmer:** Includes four guide combs (1.5mm, 2mm, 3mm, 4mm) to achieve desired hair lengths. Perfect for various grooming needs, including hair cutting, beard trimming,

shaving, and creating precise lines.

- **Ergonomic Design:** The trimmer boasts a stylish, lightweight, and comfortable-to-hold all-metal body, ensuring durability and ease of use.



Image 2: Detailed view highlighting the carbon steel cutter head, sharp blade, all-metal body, powerful motor, ON/OFF button, and charging port of the PXLISIE Hair Trimmer.



Image 3: An illustrative diagram showcasing the powerful rotary motor of the PXLISIE Hair Trimmer, emphasizing its efficiency and low noise operation.

5. Setup

- 1. Initial Charge:** Before first use, fully charge the trimmer for approximately 2.5 hours. Connect the USB charging cable to the trimmer's charging port and plug the other end into a compatible USB power source (e.g., USB adapter, laptop, power bank). The charging indicator light will show the charging status.
- 2. Attaching Guide Combs:** Select the desired guide comb (1.5mm, 2mm, 3mm, or 4mm) based on your preferred hair length. Align the comb with the trimmer blade and push it firmly until it clicks into place. To remove, gently pull the comb away from the blade.



Image 4: The PXLISIE Hair Trimmer connected via its USB cable to a laptop, illustrating its convenient charging capability and highlighting its 2-hour cordless use after a 2-hour charge.



Image 5: The PXLISIE Hair Trimmer displayed with its four guide combs (1.5mm, 2mm, 3mm, 4mm) and key dimensions (1.57 inches blade width, 6.06 inches total length).

6. Operation

1. **Power On/Off:** Press the ON/OFF button located at the bottom of the trimmer to turn it on or off.
2. **Hair Trimming:** For general hair cutting, attach the appropriate guide comb. Hold the trimmer against the hair, moving it slowly and steadily against the direction of hair growth.
3. **Beard and Detailing:** For beard trimming or precise detailing (zero-gapped trimming), remove the guide comb. Use the T-blade carefully to create sharp lines and edges.
4. **Body Hair:** The trimmer can also be used for body hair. Always ensure the skin is clean and dry before use.



Image 6: The PXLISIE Hair Trimmer being used to trim hair, demonstrating its professional application and ability to create various hairstyles.

7. Maintenance

1. **Cleaning the Cutter Head:** After each use, turn off the trimmer and detach the guide comb. Use the provided cleaning brush to remove any loose hair from the blade and the trimmer head. The cutter head can be rinsed under running water. Ensure it is completely dry before reattaching or storing.
2. **Lubrication:** Periodically apply a small amount of blade oil (not included) to the trimmer blades to maintain optimal cutting performance and prevent wear. Turn the trimmer on for a few seconds after applying oil to distribute it evenly.
3. **Storage:** Store the trimmer and its accessories in a clean, dry place.

8. Troubleshooting

- **Trimmer Not Turning On:** Ensure the trimmer is fully charged. If the battery is low, connect it to a power source using the USB cable.
- **Reduced Cutting Performance / Pulling Hair:**
 - Clean the blades thoroughly to remove any trapped hair or debris.

- Apply blade oil to lubricate the blades.
- Ensure the guide comb is correctly attached and not damaged.
- **Battery Not Holding Charge:** If the trimmer's battery life significantly decreases, ensure you are using the correct charging cable and a functional power source. If issues persist, the battery may require replacement or professional servicing.

9. Specifications

Feature	Specification
Brand	PXLISIE
Model Name	T Blade Trimmer
Item Model Number	HairT8-Gold
Battery Type	Lithium-Ion
Charging Time	2.5 Hours
Operating Time	Up to 180 minutes
Included Components	Hair Clipper, Guide Combs, USB Cable, Cleaning Brush, Ear Spoon Tool Set
Cutter Head Material	Carbon Steel and Self-Sharpening Ceramic
Noise Level	Low (typically <55dB)

10. Warranty and Support

Specific warranty details are not provided in the product information. For warranty claims, technical support, or any product-related inquiries, please refer to the contact information provided with your purchase or visit the official PXLISIE website.