

manuals.plus /

› [Donner](#) /

› [Donner DED-70 Electric Drum Set User Manual](#)

Donner DED-70

Donner DED-70 Electric Drum Set User Manual

Model: DED-70 | Brand: Donner

INTRODUCTION

The Donner DED-70 Electric Drum Set is a comprehensive electronic drum kit designed for beginners and young players. It features quiet mesh drum pads, a sound module with various kits and sounds, and a portable design. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your DED-70 drum set to ensure optimal performance and longevity.



Image: The complete Donner DED-70 Electric Drum Set, including drum pads, cymbals, sound module, drum throne, headphones, and drumsticks.

SETUP GUIDE

Follow these steps to assemble and set up your Donner DED-70 Electric Drum Set.

1. Unpacking and Component Identification

Carefully unpack all components from the box. Ensure all parts listed below are present:

- 4 x 6" Mesh Electronic Drum Pads
- 3 x 8" Rubber Cymbal Pads
- Tough Metal Rack
- Drum Sound Module
- Drum Throne

- Drumsticks
- All necessary cables



Image: All components of the DED-70 drum set laid out before assembly, showing the drum pads, cymbals, module, and frame.

2. Assembling the Drum Rack

Assemble the metal rack according to the included diagram. Ensure all connections are secure. The flexible stand design allows for height and angle adjustments suitable for players aged 4-14 years.

ADJUSTABLE STAND FOR GROWING TEENS

Adjust the height and angle in accordance with the height of your child



Roller stool



Image: A child playing the DED-70 drum set, highlighting the adjustable stand design for different player heights.



Image: The DED-70 drum set demonstrating its adjustable and folding design for easy storage and height customization.

3. Attaching Pads and Cymbals

Attach the mesh drum pads and rubber cymbal pads to the rack. Connect each pad and cymbal to the sound module using the provided cables. Ensure connections are firm to prevent signal loss.



Image: A close-up view of the 6-inch mesh drum pads, highlighting their quiet design and responsiveness.



Image: A close-up view of an 8-inch rubber cymbal pad, showing its full strike zone for realistic play.

4. Connecting the Pedals

Connect the two switch pedals (kick and hi-hat) to the designated ports on the sound module. Position them comfortably for playing.



PRO PEDAL WITH SMALLER SIZES

The ded-70 uses a highly sensitive kick drum pedal to restore the original sound drum design

Image: A close-up of the DED-70's kick drum pedal, designed for sensitive response and compact size.



Image: A user's foot operating the DED-70 drum set pedal, demonstrating its compact and responsive design.

5. Power Connection

Connect the power adapter to the sound module and plug it into a power outlet. The DED-70 also supports USB Power Bank (not included) for portable use.

PORTABLE CHARGER SUPPLY

Playing drums anywhere and anytime with power supply or portable charger, whether you're practicing indoors or on the road.



Image: A user connecting a portable power bank to the DED-70 drum set, illustrating its portable charging capability.



Image: A hand connecting the power cable to the sound module of the DED-70 drum set.

OPERATING INSTRUCTIONS

Learn how to use the various features of your DED-70 Electric Drum Set.

1. Sound Module Overview

The sound module is the central control unit. It features buttons for power, kit selection, volume control, and metronome/play functions.



Image: A hand interacting with the sound module, showing the various buttons and knobs for controlling the drum set's functions.

2. Selecting Drum Kits and Sounds

The DED-70 offers 10 pre-set drum kits and 68 exclusive acoustic and electronic drum sounds. Use the "Kit" or "Select" buttons on the module to cycle through different sound options. The intelligent dynamic clarity technology provides realistic sound.



SELECTION OF DEMO AND SOUNDS

Listen and learn to develop children's sense of music

12  DRUM KITS

68  SOUNDS

10  SONGS

Image: Graphic illustrating the DED-70's sound capabilities, including 12 drum kits, 68 sounds, and 10 songs for practice.

3. Using Headphones for Quiet Practice

For silent practice, plug the included headphones into the headphone jack on the sound module. This allows you to play without disturbing others, making it ideal for apartment living or late-night practice sessions.



SAY GOODBYE TO THE NOISY DRUMMING OF YOUR CHILD

Truly Quiet



Noisy & Disturbing Neighbors



40 FREE
Lessons Included For You



MELODICS

Image: A child wearing headphones while playing the DED-70 drum set, emphasizing the quiet practice feature.



SILENT MODE EASY FOR NEIGHBORS

With headphones, you can learn and practice drums without disturb others.



Image: The DED-70 drum set with dimensions shown, highlighting the "Silent Mode Easy for Neighbors" feature when using headphones.

4. Learning Functions and Melodics Lessons

The coaching module includes 10 play-along songs and practice exercises. The DED-70 also supports the Donner Play APP and comes with 40 virtual lessons from Melodics. Contact customer service to receive access to the Melodics courses.

5. Video Demonstration

Watch this official video for a demonstration of the Donner DED-70 Electric Drum Set in action, showcasing its features and sound

capabilities.

Your browser does not support the video tag.

Video: Official demonstration of the Donner DED-70 Electric Drum Set, highlighting its features and suitability for young drummers.

MAINTENANCE

Proper maintenance will extend the life of your drum set.

- **Cleaning:** Use a soft, dry cloth to wipe down the pads, cymbals, module, and frame. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the drum set in a cool, dry place away from direct sunlight and extreme temperatures. The adjustable folding design allows for easy storage in limited space.
- **Cable Management:** Keep cables neatly organized to prevent tangling and damage.
- **Pad Tension:** The mesh drum heads can be adjusted for tension. Use a drum key (not included) to tighten or loosen the tension rods around the rim of the pads for desired feel.



BIGGER DRUM HEAD BIGGER FUN

Image: A close-up of a DED-70 drum pad, indicating the "Thickened Design" and showing the "Tighten" and "Loose" indicators for adjusting mesh head tension.

TROUBLESHOOTING

If you encounter issues with your DED-70 drum set, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|---------------------------|--|--|
| No Sound | <ul style="list-style-type: none">Power not connected or turned on.Headphones/speaker not properly connected.Volume too low.Cable from pad to module loose. | <ul style="list-style-type: none">Ensure power adapter is securely plugged in and module is powered on.Check headphone/speaker connection to the correct port.Increase the volume on the module.Verify all pad cables are firmly connected to the module. |
| Inconsistent Pad Response | <ul style="list-style-type: none">Loose cable connection.Pad tension too loose or too tight. | <ul style="list-style-type: none">Check and secure all cables from pads to module.Adjust the tension of the mesh drum heads. |
| Pedal Not Responding | <ul style="list-style-type: none">Pedal cable loose or disconnected. | <ul style="list-style-type: none">Ensure the pedal cable is securely connected to the module. |






SPECIFICATIONS

| Feature | Detail |
|---------------------|---|
| Model Name | DED-70 |
| Brand | Donner |
| Drum Pads | 4 x 6" Mesh Drum Pads |
| Cymbal Pads | 3 x 8" Rubber Cymbal Pads |
| Pedals | 2 Switch Pedals (Kick, Hi-Hat) |
| Drum Kits | 10 Pre-set Kits |
| Sounds | 68 Exclusive Acoustic & Electronic Sounds |
| Learning Functions | 10 Play-along Songs, Practice Exercises, Donner Play APP Support, 40 Melodics Lessons |
| Power Supply | Adapter, USB Power Bank (not included) |
| Expanded Size | 41.34 x 15.79 x 38.2 inches |
| Item Weight | 11.33 Kilograms (24.9 pounds) |
| Body Material | Iron |
| Included Components | Cymbal, Snare, Drum Throne, Drumsticks, Headphones |

WARRANTY AND SUPPORT

For warranty information, product support, or to access your Melodics lessons, please refer to the official Donner website or contact Donner customer service directly. Specific warranty terms and conditions may vary by region and purchase location. Visit the official Donner Store: [Donner Store on Amazon](#)

Related Documents - DED-70

| | |
|--|--|
|  <p>DED-400 ELECTRONIC DRUM</p> <p>User Manuals</p> <p>This product is subject to change without notice</p> | <p>Donner DED-400 Electronic Drum User Manual Installation & Operation Guide</p> <p>Comprehensive user manual for the Donner DED-400 Electronic Drum, covering function introduction, installation guide, operation, maintenance, and safety precautions. Learn how to set up, use, and care for your electronic drum kit.</p> |
|  <p>DONNER</p> <p>USER MANUAL</p> <p>ELECTRONIC DRUM</p> <p>Thank You for Choosing DONNER</p> | <p>Donner DED-80 Electronic Drum User Manual</p> <p>User manual for the Donner DED-80 Electronic Drum, providing setup, operation, and maintenance instructions for an optimal musical experience.</p> |
|  <p>DONNER</p> <p>USER MANUAL</p> <p>Electric Drum Set</p> | <p>Donner DED-70L Electric Drum Set User Manual and Instructions</p> <p>Comprehensive user manual and installation guide for the Donner DED-70L Electric Drum Set, covering setup, operation, specifications, panel and socket descriptions, and safety precautions.</p> |
|  <p>DED-100 ELECTRONIC DRUM</p> <p>INSTRUCTION MANUAL</p> <p>This product is subject to change without notice</p> | <p>Donner DED-100 Electronic Drum Instruction Manual</p> <p>Comprehensive instruction manual for the Donner DED-100 Electronic Drum, covering setup, operation, features, maintenance, and safety precautions.</p> |
|  <p>DONNER</p> <p>USER MANUAL</p> <p>DED-70</p> | <p>Donner DED-70 Sound Module User Manual</p> <p>This user manual provides comprehensive instructions for operating the Donner DED-70 Sound Module, covering safe usage, panel descriptions, connections, and operational guides for playing drums, adjusting metronome settings, and managing other features.</p> |



Donner USER MANUAL

ELECTRONIC DRUM 
Thank You For Choosing Donner!
Please Read This Manual Carefully Before Use.

[Donner DED-80 Electronic Drum User Manual](#)

Comprehensive user manual for the Donner DED-80 Electronic Drum Kit, covering safe usage, setup, operation, features, and maintenance.