

[Manuals.plus](#) /

> [Dual](#) /

> Dual DL-32HD-008 LED TV User Manual

## Dual DL-32HD

# Dual DL-32HD-008 LED TV User Manual

Model: DL-32HD

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Dual DL-32HD-008 LED TV. Please read these instructions carefully before using the television and retain them for future reference. This 32-inch (81 cm) HD LED TV features a 1366 x 768 resolution, multiple connectivity options including HDMI and USB, and an integrated DVB-T/C/S2 tuner.



## 2. SAFETY INFORMATION

---

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury.

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Keep the TV away from direct sunlight, heat sources, and strong magnetic fields.
- Unplug the TV during lightning storms or when unused for long periods.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the box:

- Dual DL-32HD-008 LED TV
- Stand Feet (2 pieces)
- Remote Control
- User Manual (this document)

## 4. SETUP

---

### 4.1. Stand Installation

To install the stand feet:

1. Carefully place the TV face down on a soft, flat surface to prevent screen damage.
2. Align each stand foot with the corresponding slots on the bottom of the TV.
3. Secure the feet using the provided screws.



Image 4.1: TV with stand feet installed.

## 4.2. Wall Mounting

The TV supports VESA 100 x 100 mm wall mounts. A wall mount kit is not supplied. Please consult a professional for wall mounting to ensure safety and proper installation.

## 4.3. Connecting External Devices

The TV offers various ports for connecting external devices:

- **HDMI Ports:** Connect Blu-ray players, game consoles, or set-top boxes. This model includes 1 HDMI 1.4 port and 1 HDMI ARC port.
- **USB 2.0 Port:** For media playback or PVR (Personal Video Recorder) functionality.
- **Antenna Input:** Connect your terrestrial, cable, or satellite antenna for DVB-T/C/S2 reception.
- **CI+ Slot:** For Conditional Access Modules (CAM) to decrypt encrypted channels.




Image 4.2: Rear panel with connectivity ports.

#### 4.4. Power Connection and First-Time Setup

1. Connect the power cord to the TV and then to a wall outlet.
2. Press the Power button on the remote control or on the TV.
3. Follow the on-screen instructions for the initial setup, including language selection, channel scanning, and network configuration (if applicable).

## 5. OPERATING

---

### 5.1. Remote Control Overview

Familiarize yourself with the remote control buttons for optimal TV operation.





Image 5.1: Remote Control.

## 5.2. Basic TV Functions

- **Power:** Press the **POWER** button to turn the TV on or off.
- **Volume:** Use the **VOL +/-** buttons to adjust the volume.
- **Channel:** Use the **CH +/-** buttons to change channels.
- **Input:** Press the **INPUT** button to select different input sources (HDMI, USB, TV).

- **Menu:** Press the **MENU** button to access the main menu for settings adjustments.

### 5.3. Tuner Operation

Your TV supports DVB-T (terrestrial), DVB-C (cable), and DVB-S2 (satellite) signal formats. After initial setup, channels will be scanned and stored. Use the **EPG** button to view the Electronic Program Guide.

### 5.4. USB PVR Function

Connect a USB storage device to the USB 2.0 port to record TV programs. Refer to the on-screen menu for PVR setup and operation instructions.

## 6. MAINTENANCE

### 6.1. Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Never spray liquid directly onto the screen.

### 6.2. Cleaning the Casing

Use a soft, dry cloth to clean the TV casing. Avoid using abrasive cleaners or solvents.

## 7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord disconnected; no power from outlet.	Check power cord connection; test outlet with another device.
No picture, but sound is present	Incorrect input source selected; faulty cable.	Press <b>INPUT</b> to select correct source; check HDMI/AV cable connections.
No sound, but picture is present	Volume muted or too low; external audio system issue.	Unmute or increase volume; check external audio connections.
Remote control not working	Batteries depleted or incorrectly inserted; obstruction.	Replace batteries (CR2032 type); ensure clear path to TV's IR sensor.
Poor picture quality	Weak signal; incorrect picture settings.	Check antenna connection; adjust picture settings in the menu.

## 8. SPECIFICATIONS

Detailed technical specifications for the Dual DL-32HD-008 LED TV:

Feature	Specification
Model Name	DL-32HD
Screen Size	32 Inches (81 cm)

<b>Feature</b>	<b>Specification</b>
Display Technology	LED
Resolution	720p (1366 x 768)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Contrast Ratio	1200:1
Maximum Brightness	180 Candelas per square meter
Response Time	8 milliseconds
Viewing Angle	178 Degrees
Audio Output Mode	Surround
Speaker Description	2 x 8 Watts Speakers
Total HDMI Ports	2 (1x HDMI 1.4, 1x HDMI ARC)
Total USB Ports	2 (USB 2.0)
Tuner Type	DVB-T, DVB-C, DVB-S2
VESA Mount Standard	100 x 100 mm
Power Consumption	65 Watts (On), 0.5 Watts (Standby)
Line Voltage	100-240 V AC 50-60 Hz
Item Dimensions (D x W x H)	19P x 73.2W x 47.8H cm
Item Weight (without stand)	3.5 Kilograms
Item Weight (with stand)	4.5 Kilograms
Remote Control Battery Type	CR2032




Image 8.1: TV dimensions.

### 8.1. Energy Label



# ENERG



**DUAL**

DL-32HD-DG21-NS0015






Image 8.2: EU Energy Label. For more details, visit the official EPREL database: [EPREL Product Page](#)

## 9. WARRANTY AND SUPPORT

### 9.1. Warranty Information

This product comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions.

## **9.2. Spare Parts and Software Updates**

Information regarding the availability of spare parts and guaranteed software updates for this model is currently not available. Please contact your retailer or the manufacturer for further inquiries.

## **9.3. Customer Support**

For technical assistance or customer service, please contact your point of purchase or visit the official Dual website for support resources.