

[Manuals.plus](#) /

› [LUXPRO](#) /

› LUXPRO Bright 2849 Lumen Rechargeable Work Light Instruction Manual

LUXPRO LP1850

LUXPRO Bright 2849 Lumen Rechargeable Work Light

Model: LP1850

PRODUCT OVERVIEW

The LUXPRO Bright 2849 Lumen Rechargeable Work Light (Model LP1850) is a versatile and durable lighting solution designed for various tasks and environments. It features a high-output LED, multiple lighting modes, and a rechargeable battery with a USB-C charging port for convenience.



Image: The LUXPRO Bright 2849 Lumen Rechargeable Work Light, showcasing its black and yellow design with a large LED panel and integrated handle/stand.

SETUP

1. Unboxing and Initial Inspection

Carefully remove the work light and all accessories from the packaging. Verify that the following items are included:

- LUXPRO Bright 2849 Lumen Rechargeable Work Light
- USB-C Charging Cable

Inspect the light for any visible damage. If any components are missing or damaged, contact customer support.

2. Initial Charging

Before first use, fully charge the work light. Connect the included USB-C charging cable to the light's USB-C port and plug the other end into a compatible USB power adapter (not included). The charging indicator lights will illuminate to show charging progress. A full charge typically takes approximately 4 hours.



Charge On The Go

Comes with a USB-C charging cord and features a USB charge port to charge portable devices.

Image: Close-up view of the LUXPRO work light's side, showing the USB-C charging port and USB-A output port with battery indicator lights.

3. Adjusting the Collapsible Base

The work light features a collapsible and pivoting base, allowing for easy storage and versatile positioning. To adjust the base, simply pivot the yellow side supports to the desired angle. This enables the light to stand independently on various surfaces.



Image: The LUXPRO work light with its collapsible base extended, demonstrating its ability to stand upright for hands-free operation.

OPERATING INSTRUCTIONS

1. Powering On/Off and Mode Selection

Locate the power button on the work light. Press the button once to turn the light on. Subsequent presses will cycle through the available lighting modes:

- **High Mode:** Provides maximum brightness (2849 lumens) for intense illumination.
- **Medium Mode:** Offers a balanced brightness level.
- **Low Mode:** Delivers reduced brightness (950 lumens) for extended run time or less intense lighting needs.

To turn the light off, continue pressing the power button until the light extinguishes, or hold the button down for a few

seconds in any mode.

3 Lighting Modes



High, Medium, and Low.




Image: The LUXPRO work light illuminating a workspace, with text indicating the availability of High, Medium, and Low lighting modes.

ULTRA BRIGHT

2849 Lumens on high



Image: The LUXPRO work light brightly illuminating a red workbench, highlighting its

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09ZGH4QD6>

More documents and user manuals: **<https://manuals.plus/>**