Baby Born 832752

BABY Born Weekend House 832752 Instruction Manual

Model: 832752 | Brand: Baby Born

1. Introduction

Thank you for choosing the BABY Born Weekend House 832752. This play accessory is designed to provide an engaging and imaginative play experience for children aged 3 years and up, accommodating BABY Born dolls of 36cm and 43cm. This manual contains important information regarding the assembly, operation, and care of your Weekend House. Please read it thoroughly before use and retain it for future reference.

2. Safety Information

- **Adult Supervision:** Always ensure adult supervision during assembly and play, especially for younger children.
- **Small Parts:** This product contains small parts that may pose a choking hazard for children under 3 years. Keep all small components out of reach of infants.
- **Battery Safety:** If the product includes light and sound features, ensure batteries are inserted correctly according to polarity (+/-). Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are only to be charged under adult supervision.
- **Cleaning:** Clean the product with a damp cloth only. Do not immerse in water.
- **Placement:** Place the Weekend House on a stable, flat surface to prevent tipping.

3. Package Contents

Carefully unpack all components and verify that all items listed below are present. If any parts are missing or damaged, please contact customer support.

- BABY Born Weekend House structure (main frame, roof fabric, curtains)
- 2 Stools
- Sink unit with faucet
- Stove and grill unit
- Cooking pot and frying pan
- Utensils (fork, spoon, knife, spatula)

- Plates and cups
- Play food items (e.g., pretzels, sausages, carrots, flowers)
- 2 Planting boxes
- Play mat and pillow



Image 1: The assembled BABY Born Weekend House with included accessories, ready for play.

4. Setup and Assembly

Assembly should be performed by an adult. Please follow these general steps:

1. **Unpack Components:** Lay out all parts on a clean, flat surface.
2. **Assemble Main Frame:** Connect the side panels and base according to the visual guides. Ensure all connections are secure.
3. **Attach Roof:** Secure the fabric roof to the top frame of the house. The roof is designed to be convertible.
4. **Install Curtains:** Attach the decorative curtains to the designated points on the house frame.
5. **Set up Kitchen Area:** Place the sink unit with faucet and the stove/grill unit into their respective slots on the side counter.
6. **Battery Installation (for Light & Sound Effects):** Locate the battery compartment (usually on the underside or rear of the main unit). Insert the required batteries (not included) following the polarity indicators. Close the compartment securely.
7. **Add Accessories:** Arrange the stools, planting boxes, play mat, pillow, and other play food/utensils as desired.



Image 2: Two children engaging in imaginative play with the fully assembled Weekend House.

5. Operating Instructions

The BABY Born Weekend House offers various interactive features for enhanced play.

5.1. Convertible Roof

The fabric roof can be adjusted to create different play scenarios. Gently push or pull the roof fabric to change its configuration, allowing for open-air play or a more enclosed house setting.

5.2. Light and Sound Effects

If batteries are installed, the Weekend House features interactive light and sound elements. Locate the activation button or switch, typically near the kitchen area or roof. Pressing this button will activate various sounds and lights, enhancing the play experience.

5.3. Play Features

- **Kitchen Area:** The integrated sink with a movable faucet allows for pretend washing. The stove and grill provide areas for imaginative cooking with the included pots, pans, and play food.
- **Dining Area:** Use the small table and stools for dolls to enjoy meals.
- **Gardening:** The planting boxes can be used to 'grow' the included play carrots and flowers, fostering imaginative gardening play.



Image 3: A hand demonstrating the operation of the faucet in the play sink.



Image 4: Detailed view of the planting boxes filled with colorful play carrots and flowers.

6. Maintenance and Care

- **Cleaning:** Wipe all surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** When not in use, store the Weekend House in a clean, dry place away from direct sunlight to prevent fading and material degradation.
- **Fabric Care:** The fabric roof and curtains can be gently spot cleaned with mild soap and water. Allow to air dry completely.
- **Battery Replacement:** Replace batteries as needed to maintain light and sound functionality. Always dispose of used batteries responsibly.

7. Troubleshooting

- **Lights/Sounds Not Working:**
  - Check if batteries are installed correctly with the correct polarity.
  - Replace old or exhausted batteries with new ones.
  - Ensure the battery compartment is securely closed.
- **Parts Not Fitting Together:**
  - Refer to the assembly instructions and diagrams to ensure correct orientation of parts.
  - Do not force parts together. If a part does not fit, re-examine the instructions.

8. Specifications

Product Name	BABY Born Weekend House
Model Number	832752
Brand	Baby Born
Product Dimensions	20.67 x 14.17 x 20.67 inches (52.5 x 36 x 52.5 cm)
Item Weight	3.31 pounds (1.5 kg)
Recommended Age	3 years and up
Compatible Doll Sizes	36cm and 43cm BABY Born dolls
Features	Convertible roof, light and sound effects, integrated kitchen, dining, and gardening play areas.

9. Warranty and Support

For warranty information or customer support, please refer to the packaging or contact the retailer where the product was purchased. You may also visit the official Baby Born website for further assistance and contact details.
Online Resources: For additional product information, assembly videos, or frequently asked questions, please visit the official Baby Born website or the product page on the retailer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question