

[Manuals.plus](#) /

> [OPPO](#) /

> [OPPO K10 Smartphone User Manual](#)

OPPO K10

OPPO K10 Smartphone User Manual

Model: K10

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your OPPO K10 smartphone. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



The image shows a close-up of a smartphone screen with a vibrant blue and purple gradient background. The text "90 HZ" is prominently displayed in the upper left quadrant in a large, white, sans-serif font. The phone's black bezel is visible around the screen.

90 HZ

Figure 1: OPPO K10 Key Features Overview

WHAT'S IN THE BOX

Upon unboxing your OPPO K10, verify that all standard components are present:

- OPPO K10 Smartphone
- USB Cable
- Charger (Power Adapter)
- SIM Ejector Tool
- Protective Case
- Quick Start Guide
- Safety Guide



Figure 2: OPPO K10 Box Contents

1. Insert SIM Card and microSD Card:

Locate the SIM tray on the side of your device. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM card(s) and an optional microSD card into the designated slots. Ensure the cards are correctly oriented as indicated on the tray. Gently push the tray back into the phone until it clicks into place.

2. Power On:

Press and hold the Power button (located on the right side) until the OPPO logo appears on the screen. The device will boot up.

3. Initial Configuration:

Follow the on-screen prompts to select your language, region, connect to a Wi-Fi network, and set up your Google account. You will also be guided through setting up security features like a PIN, pattern, or fingerprint.

4. Charge the Battery:

For optimal performance, it is recommended to fully charge your device before first use. Connect the USB cable to the phone's charging port and the other end to the power adapter. Plug the adapter into a wall outlet.

OPERATING YOUR DEVICE

Basic Controls

- **Power Button:** Press and hold to power on/off or restart. Short press to lock/unlock the screen.
- **Volume Buttons:** Adjust media volume, call volume, or notification volume.
- **Touchscreen Gestures:**
 - **Tap:** Select an item or open an app.
 - **Swipe:** Navigate through screens or scroll content.
 - **Pinch:** Zoom in or out on images and web pages.





Figure 3: OPPO K10 Side View with Buttons

Navigation

The OPPO K10 uses ColorOS 11.1 based on Android 11. You can navigate using on-screen gestures or traditional navigation buttons (Home, Back, Recent Apps), which can be configured in Settings.

CAMERA FEATURES

The OPPO K10 is equipped with a versatile camera system:

- **Rear Camera System:** 50 MP main sensor, 2 MP macro lens, and 2 MP depth sensor.
- **Front Camera:** 16 MP AI Selfie Camera.

Using the Camera App

1. **Open Camera:** Tap the Camera icon on your home screen or lock screen.
2. **Switch Modes:** Swipe left or right on the viewfinder to switch between modes like Photo, Video, Portrait, Night, and more.
3. **Take a Photo:** Tap the Shutter button.

4. **Zoom:** Pinch in or out on the screen, or use the zoom options above the shutter button.
5. **Settings:** Tap the gear icon for advanced camera settings, including resolution, timer, and grid lines.






Figure 4: OPPO K10 Rear Camera Module

BATTERY AND CHARGING

Your OPPO K10 is equipped with a 5000 mAh Lithium-Ion battery and supports 33W SUPERVOOC fast charging.

Charging Instructions

- Use only the official OPPO charger and USB cable provided with your device to ensure safe and efficient charging.
- Connect the USB cable to the phone's USB-C port and the power adapter.
- Plug the power adapter into a standard wall outlet.
- The charging indicator will appear on the screen.
- Charging time is approximately 60 minutes for a full charge from 0% using the 33W SUPERVOOC charger.

Battery Optimization Tips

- Reduce screen brightness.
- Turn off Wi-Fi, Bluetooth, and GPS when not in use.
- Close background apps.
- Enable power saving modes in Settings.

MAINTENANCE

Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body.
- Avoid using harsh chemicals, abrasive cleaners, or compressed air.
- Ensure charging ports and speaker grilles are free of dust and debris.

Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > About device > ColorOS version** to check for updates.

Storage Management

Periodically clear unnecessary files, cache data, and uninstall unused applications to free up storage space and maintain device speed. The OPPO K10 supports microSDXC for expandable storage.

Water Resistance

The OPPO K10 is rated as "Water Resistant". This means it can withstand splashes and light rain, but it is not designed for submersion in water. Avoid exposing the device to excessive moisture, high humidity, or liquids.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Solution
Device not turning on	Ensure the battery is charged. Connect to the charger for at least 15 minutes. If it still doesn't turn on, perform a force restart by holding the Power button and Volume Up button simultaneously for about 10 seconds.
Apps crashing or freezing	Close the problematic app and reopen it. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the issue persists, uninstall and reinstall the app. Ensure your device software is up to date.
Poor network signal	Check if your SIM card is properly inserted. Try restarting the device. Toggle Airplane Mode on and off. If the issue persists, contact your network provider.
Battery drains quickly	Review battery usage in Settings to identify power-hungry apps. Reduce screen brightness, disable unnecessary features (Wi-Fi, Bluetooth, GPS), and close background apps.
Fingerprint sensor not working	Ensure your finger is clean and dry. Re-register your fingerprints in Settings > Password & biometrics. Clean the sensor area.

For more complex issues, consider performing a factory reset (**Settings > System settings > Back up and reset > Reset phone > Erase all data**). **Warning:** This will erase all data on your device. Back up important data before proceeding.

SPECIFICATIONS

Feature	Detail
Brand	OPPO
Model	K10
Operating System	ColorOS 11.1 (based on Android 11)
Processor	Qualcomm SM6225 Snapdragon 680 4G (6 nm), Octa-core
RAM	6 GB
Internal Storage	128 GB
Expandable Storage	microSDXC (dedicated slot), up to 128 GB
Display	6.59 inches IPS LCD, 1080 x 2412 pixels
Rear Camera	50 MP (wide), 2 MP (macro), 2 MP (depth)
Front Camera	16 MP (wide)
Battery Capacity	5000 mAh Lithium-Ion

Feature	Detail
Charging	33W SUPERVOOC (approx. 60 minutes for full charge)
Dimensions (H x W x D)	164.4 x 75.7 x 8.4 mm (6.47 x 2.98 x 0.33 in)
Weight	189 g (6.67 oz)
SIM Card	Dual Nano-SIM
Connectivity	5G Cellular Technology, USB Type-C
Water Resistance	Water Resistant

WARRANTY AND SUPPORT

Your OPPO K10 smartphone comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use conditions.

For detailed warranty terms, service center locations, or further technical assistance, please visit the official OPPO support website or contact OPPO customer service.

Official OPPO Website: <https://www.oppo.com/in/support/>