

TecTake 404603

tectake® Hanging Garden Chair User Manual

Model: 404603

1. INTRODUCTION

Thank you for choosing the tectake® Hanging Garden Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new garden chair. Please read these instructions carefully before use and retain them for future reference.

This ergonomically designed hanging lounger offers a comfortable and stylish relaxation spot for your garden, patio, or balcony. It features a sturdy steel frame, a padded lying surface, a headrest, a UV-protected sun canopy, and a convenient side pocket.

2. SAFETY INFORMATION

WARNING:

- This product has a maximum weight limit of **160 kg**. Do not exceed this limit.
- Ensure the chair is assembled and used on a stable, even surface to prevent tipping.
- Follow all assembly instructions precisely. Incorrect assembly can lead to instability and injury.
- In case of strong wind or storm, remove the sun canopy and additionally secure or store the hanging lounger to prevent damage or injury.
- Keep children and pets away from the chair during assembly and ensure they do not play unsupervised around the chair when in use.
- Regularly inspect all components for wear, damage, or loose connections. Do not use the chair if any parts are damaged.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact TecTake customer support.

- Hanging Lounger Frame (Steel/Iron base frame, powder-coated)
- Padded Lying Surface with Headrest (Polyester)
- UV-Protected Sun Canopy
- Side Pocket with four compartments
- Assembly Materials (Screws, nuts, washers, tools if included)
- Assembly Instructions (Separate document, if applicable)

tectake
garden

Product information

MEASUREMENTS

Dimensions

132 x 195 x 197 cm

Lying surface

71 x 208 cm

Sun canopy

132 x 154 cm

Pocket

37 x 32 cm

Lying height (without load)

63 cm

TECHNICAL DATA

Load capacity 160 kg

Weight 31.5 kg

Material powder-coated steel,
polyester

CONTENTS

Hanging lounger

Side pocket

Assembly materials

Assembly instructions

Measurements may vary




Figure 3.1: Product Information and Contents Diagram. This diagram illustrates the main components and their approximate dimensions, including the hanging lounger, side pocket, sun canopy, and assembly materials.

4. ASSEMBLY INSTRUCTIONS

The tectake® Hanging Garden Chair is supplied as a disassembled kit. Assembly typically requires two people and patience. Please refer to the separate assembly instructions provided in your package for detailed, step-by-step guidance. If no specific instructions were included, please contact TecTake customer support for assistance.

General Assembly Tips:

1. **Unpack and Organize:** Lay out all components and hardware on a clean, flat, and soft surface to prevent scratches. Verify against the package contents list.
2. **Identify Parts:** Familiarize yourself with each part by comparing them to the diagrams in the assembly instructions.
3. **Follow Sequence:** Assemble the chair strictly according to the numbered steps in the instructions. Do not skip steps.
4. **Do Not Overtighten:** Initially, hand-tighten all screws. Once the entire frame is assembled and stable, go back and fully tighten all connections with the provided tools.
5. **Attach Fabric and Canopy:** Once the frame is secure, attach the padded lying surface and the sun canopy as per instructions. Ensure the canopy is securely fastened to provide UV protection.
6. **Final Check:** Before first use, double-check all connections to ensure they are tight and secure. Gently test the stability of the chair.



Figure 4.1: Canopy Attachment Detail. This image shows how the sun canopy attaches to the main frame, highlighting the secure connection points.



Figure 4.2: Fabric Lacing Detail. This image illustrates the method by which the padded lying surface is secured to the chair's frame using elastic cords and eyelets.

5. OPERATING INSTRUCTIONS

Using your tectake® Hanging Garden Chair is straightforward, designed for maximum comfort and relaxation.

How to Use:

- **Seating:** Gently sit on the padded lying surface. The ergonomic design will naturally cradle your body.
- **Sun Canopy:** The integrated UV-protected sun canopy provides shade. It can be adjusted or removed if not needed.
- **Side Pocket:** Utilize the practical side pocket with four compartments to store small items such as books, phones, or drinks within easy reach.

- **Movement:** The chair is designed to gently swing, providing a soothing motion. Ensure there is adequate clear space around the chair to allow for this movement without obstruction.



Figure 5.1: Chair in Use. This image shows the hanging garden chair being used on a balcony, highlighting its comfort and suitability for outdoor relaxation.



Figure 5.2: Side Pocket Feature. This image provides a clear view of the convenient side pocket, demonstrating its capacity for storing personal items.

6. MAINTENANCE AND CARE

Proper maintenance will extend the lifespan and preserve the appearance of your tectake® Hanging Garden Chair.

- **Cleaning:** Clean the steel frame with a damp cloth and mild detergent. Wipe the padded surface with a clean, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Weather Protection:** To ensure longevity, especially when using outdoors, we recommend using a protective cover to shield the chair from bad weather conditions (rain, snow, prolonged direct sunlight).
- **Storage:** During off-season or extended periods of non-use, store the chair in a dry, sheltered location. The chair can be disassembled for more compact storage if needed.
- **Rust Prevention:** The steel frame is powder-coated against corrosion. However, prolonged exposure to moisture can lead to rust. Regularly inspect the frame for any signs of rust, especially at joints and welds. If rust appears, clean the area and apply a rust-inhibiting paint.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your hanging garden chair.

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose fasteners; uneven ground; incorrect assembly.	Ensure all screws and bolts are fully tightened. Move the chair to a flat, level surface. Review assembly instructions to confirm correct setup.
Difficulty during assembly.	Missing instructions; misaligned parts; insufficient tools.	Refer to the provided assembly manual. If missing, contact TecTake support for a digital copy. Ensure parts are correctly oriented before tightening. Use appropriate tools.
Rust appearing on the frame.	Prolonged exposure to moisture; damage to powder coating.	Clean the rusted area thoroughly. Apply a rust-inhibiting primer and paint. Use a protective cover when not in use, especially in wet conditions.
Sun canopy not providing adequate shade.	Incorrect positioning; sun angle.	Adjust the canopy's position. Consider repositioning the chair itself to optimize shade.

8. SPECIFICATIONS

Detailed technical specifications for the tectake® Hanging Garden Chair:

Brand: TecTake

Model Number: 404603

Colour: Beige

Product Dimensions (L x W x H): 195 x 132 x 197 cm (approximate, based on diagram)

Lying Surface Dimensions: 71 x 208 cm (approximate, based on diagram)

Sun Canopy Dimensions: 132 x 154 cm (approximate, based on diagram)

Lying Height (without load): 63 cm (approximate, based on diagram)

Load Capacity: 160 kg

Item Weight: 13.9 kg

Material: Powder-coated Steel (frame), Polyester (padded surface, canopy)

Special Features: Side Pocket, Headrest, UV-Protected Sun Canopy, Non-Slip Caps

Seating Capacity: 1 person



Figure 8.1: Full Product View. This image provides an overall view of the tectake hanging garden chair, showcasing its design and features.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact TecTake customer service. Keep your purchase receipt as proof of purchase.

TecTake Customer Service: Please refer to the contact information provided with your purchase or visit the official TecTake website for support details.

Online Resources: For additional information and product updates, you may visit the TecTake brand store on Amazon: [TecTake Store](#)

© 2024 TecTake. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question