Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Asvine JOSGZ271C

Hongdian Black Forest Fountain Pen

INSTRUCTION MANUAL

1. INTRODUCTION

The Hongdian Black Forest Fountain Pen is designed to provide an exceptional and comfortable writing experience. Crafted with a durable metal body and a unique, streamlined stainless steel medium nib, this pen combines classic sophistication with modern technology. It is well-balanced for extended writing sessions and comes with a converter for bottled ink, making it a versatile writing instrument.



Figure 1: Hongdian Black Forest Fountain Pen with cap removed, showcasing the matte black finish and textured barrel.

2. Product Components

Your Hongdian Black Forest Fountain Pen set includes the following components:

- Fountain Pen (Barrel, Section, Nib, Cap)
- Ink Converter (pre-installed or included separately)
- Metal Pen Case



Figure 2: Exploded view of the fountain pen components, including the nib unit, converter, barrel, and cap.

3. Setup and Ink Filling

Your Hongdian fountain pen does not include ink for safety during transit. You can use either bottled ink with the included converter or Hongdian 3.4mm ink cartridges.

3.1. Filling with Bottled Ink (Using Converter)

1. Unscrew the barrel from the section to expose the converter.

2. Ensure the end of the converter with the open ring is securely inserted into the back of the section block.
3. Twist the end of the converter to send the piston down to the end inserted into the section block.
4. Submerge the nib completely into your non-carbon bottled ink.
5. Twist the black knob on the converter in the opposite direction to draw ink up into the converter.
6. Remove the nib from the ink bottle and gently twist the converter knob a small amount to expel a few drops of ink, ensuring proper ink flow.
7. Wipe any excess ink from the nib and section with a soft cloth.
8. Reassemble the pen by screwing the barrel back onto the section.

3.2. Filling with Cartridge

1. Unscrew the barrel from the section.
2. Remove the pre-installed converter (if present) by gently pulling it out.
3. Insert the narrow end of a new Hongdian 3.4mm ink cartridge into the back of the section block with enough pressure to create a snug fit. The pin inside the section will puncture the seal of the cartridge, allowing ink to flow.
4. Reassemble the pen by screwing the barrel back onto the section.




Figure 3: Visual guide for filling the pen with bottled ink via converter or with an ink cartridge.

3.3. Initial Ink Flow Activation

When filling the pen for the first time, or after a period of disuse, gently shake the pen to encourage a few drops of ink to come out of the nib. This helps to prime the feed and ensures quick and consistent ink flow.

Your browser does not support the video tag.

Video 1: Official guide on how to properly fill and initiate ink flow for your Hongdian fountain pen. This video demonstrates the steps for both converter and cartridge use, and provides tips for ensuring smooth writing from the start.

4. Operating Your Fountain Pen

The Hongdian Black Forest Fountain Pen is designed for comfortable and precise writing. Its carefully calculated weight provides a balanced feel, making it suitable for long writing sessions.



Figure 4: Demonstrates the comfortable grip and smooth writing experience of the pen during use.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your fountain pen.

5.1. Cleaning the Pen

To clean your pen, especially if you notice poor ink flow or are changing ink colors:

1. Disassemble the pen by removing the barrel and converter/cartridge.
2. Fill the converter with clean water and expel it out through the nib. Repeat this process about ten times until the water runs clear.
3. For thorough cleaning, you can gently remove the nib and feed from the section and rinse them separately under cool running water.
4. Allow all components to air dry completely before reassembling or refilling.

Important: Do not use carbon bottled ink (waterproof ink) as it can easily clog fountain pens. Never clean your acrylic pen parts with alcohol, as it will damage the acrylic body.



Figure 5: The pen disassembled, illustrating the parts that can be cleaned.

6. Troubleshooting

Here are some common issues and their solutions:

6.1. Poor Ink Flow (Dry, Skip, Inconsistent Flow)

- **Clean the pen:** Follow the cleaning steps in Section 5.1 to remove any dried ink or debris that might be obstructing the ink flow.
- **Check nib and feed alignment:** Ensure the nib lines up correctly with the black feed. There should be no significant gap between the nib and the feed. You can gently adjust them manually if needed.
- **Remove debris from nib slit:** If cleaning doesn't resolve the issue, you may use a thin brass sheet or a razor blade to carefully clear any debris from the nib slit.

6.2. Pen Leaks

- **Check cartridge/converter insertion:** Ensure the ink cartridge or converter is inserted tightly and securely into the section. A loose connection can cause leaks.
- **Replace cartridge/converter:** If the issue persists, try replacing the cartridge or converter with a new one, as the seal might be faulty.



Figure 6: Detailed view of the nib, illustrating points to check for proper alignment and potential obstructions.

7. Specifications

Brand	Asvine
Manufacturer	Hongdian
Model Number	JOSGZ271C
Item Weight	2.39 ounces
Package Dimensions	6.97 x 1.57 x 0.75 inches
Color	Black
Material Type	Metal
Point Type	Medium
Line Size	0.8 Millimeters
Ink Color	No Ink Included

8. Warranty and Support

This product is from a small business brand committed to quality. For any video instructions or questions regarding the use of your Hongdian Black Forest Fountain Pen, please send us a message. We are here to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZHZMCHN

More documents and user manuals: **https://manuals.plus/**