

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Toyota](#) /

› [2022 Toyota Camry Owner's Manual](#)

Toyota Camry

2022 Toyota Camry Owner's Manual

Comprehensive guide for your vehicle.

INTRODUCTION

This manual provides detailed information and instructions for the safe and efficient operation, maintenance, and care of your 2022 Toyota Camry. Please read this manual thoroughly to understand your vehicle's features and capabilities. Keep this manual in your vehicle for quick reference.

For your safety, pay close attention to all warnings and cautions throughout this manual. Failure to follow these instructions could result in serious injury or damage to your vehicle.

SETUP AND INITIAL FAMILIARIZATION

Before operating your 2022 Toyota Camry, familiarize yourself with its key components and controls. This section covers initial setup procedures and important checks.

Key Fob and Door Locks

Your Camry comes with a smart key system. To unlock the doors, press the unlock button on the key fob or grasp the front door handle with the key fob in your possession. To lock, press the lock button or touch the sensor on the door handle.




Figure 1: Example of a Toyota Camry key fob. Use this to lock and unlock your vehicle and activate the alarm.

Seat and Steering Wheel Adjustment

Adjust your seat and steering wheel for optimal driving position and comfort. Most models feature power-adjustable seats. The steering wheel can be adjusted for tilt and telescoping. Ensure you have a clear view of the road and dashboard instruments.

- **Seat Adjustment:** Use the controls on the side of the seat to move it forward/backward, adjust height, and recline the seatback.
- **Steering Wheel Adjustment:** Pull the lever under the steering column to unlock, then adjust the wheel to your desired position. Push the lever back to lock.

OPERATING YOUR VEHICLE

This section details the procedures for starting, driving, and utilizing the various features of your 2022 Toyota Camry.

Starting the Engine

1. Ensure the shift lever is in Park (P).

2. Press the brake pedal firmly.
3. Press the ENGINE START/STOP button.

Note: If the key fob battery is low, you may need to hold the key fob against the ENGINE START/STOP button to start the vehicle.

Driving Modes

Your Camry may offer different driving modes (e.g., Eco, Normal, Sport) to optimize performance and fuel efficiency. Select the desired mode using the drive mode selector button, typically located near the gear shifter.




Figure 2: The dashboard of the 2022 Toyota Camry, showing the infotainment screen and climate controls.

Infotainment System

The infotainment system provides access to audio, navigation, and vehicle settings. Refer to the separate multimedia system manual for detailed instructions on its operation.

- **Audio:** Tune to radio stations, play media from USB devices, or connect your smartphone via Bluetooth.
- **Navigation:** Input destinations and follow turn-by-turn directions.

- **Settings:** Customize vehicle features such as lighting, door locks, and driver assistance systems.

MAINTENANCE AND CARE

Regular maintenance is crucial for the longevity and performance of your 2022 Toyota Camry. Follow the recommended service schedule outlined in your Warranty and Maintenance Guide.

Engine Oil Check

Check the engine oil level regularly, ideally every 5,000 miles or before a long trip. Park the vehicle on a level surface and allow the engine to cool before checking.

1. Locate the oil dipstick (usually with a yellow or orange handle).
2. Pull out the dipstick, wipe it clean, and reinsert it fully.
3. Pull it out again and check the oil level. It should be between the "MIN" and "MAX" marks.




Figure 3: The engine bay of the 2022 Toyota Camry, indicating the location of the engine oil dipstick.

Tire Pressure

Maintain correct tire pressure as specified on the tire placard located on the driver's side door jamb.

Incorrect tire pressure can affect handling, fuel economy, and tire wear.

Warning: Always check tire pressure when tires are cold.

Fluid Checks

Regularly check other fluid levels, including:

- Brake fluid
- Coolant
- Windshield washer fluid

TROUBLESHOOTING COMMON ISSUES

This section addresses common issues you might encounter with your 2022 Toyota Camry and provides basic troubleshooting steps.

Engine Will Not Start

- **Check Battery:** Ensure the battery terminals are clean and tight. If the battery is dead, jump-start the vehicle (refer to the "Jump Starting" section in your full manual).
- **Check Fuel Level:** Confirm there is sufficient fuel in the tank.
- **Key Fob:** Ensure the key fob is inside the vehicle and its battery is not depleted.

Warning Lights On

If a warning light illuminates on the dashboard, consult your full owner's manual for its specific meaning and recommended action. Some common warning lights include:

Warning Light	Possible Cause	Action
Check Engine Light	Engine or emission system malfunction.	Have the vehicle inspected by a Toyota dealer.
Low Tire Pressure Warning	One or more tires are significantly underinflated.	Check tire pressure and inflate to recommended levels. Inspect for punctures.
Oil Pressure Warning	Low engine oil pressure.	Stop the vehicle immediately and check engine oil level. Do not drive with this light on.

SPECIFICATIONS

This section provides general technical specifications for the 2022 Toyota Camry. Specific values may vary based on trim level and options.

- **Engine Type:** 2.5L 4-Cylinder DOHC 16-Valve with VVT-i (standard) or 3.5L V6 DOHC 24-Valve with D-4S Dual Injection (available).
- **Transmission:** Direct Shift-8AT 8-speed Electronically Controlled automatic Transmission.
- **Fuel Tank Capacity:** Approximately 15.8 gallons (60 liters).
- **Tire Size:** Varies by trim (e.g., 205/65R16, 235/45R18). Refer to your tire placard.
- **Dimensions (Approximate):**

- Length: 192.1 inches
- Width: 72.4 inches
- Height: 56.9 inches




Figure 4: The exterior profile of the 2022 Toyota Camry, illustrating its general dimensions.

WARRANTY AND SUPPORT

Your 2022 Toyota Camry is covered by a comprehensive warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the separate Warranty and Maintenance Guide provided with your vehicle.

For technical assistance, service appointments, or genuine Toyota parts, please contact your authorized Toyota dealership. You can find your nearest dealer by visiting the official Toyota website or by calling customer support.

Toyota Customer Support: www.toyota.com/support

Roadside Assistance: Refer to your warranty guide for roadside assistance contact information.

