

Casio 10631629

Casio 10631629 Pathfinder Replacement Watch Band Instruction Manual

For PAG240 and PAG40 Models

INTRODUCTION

This manual provides detailed instructions for the proper installation, care, and maintenance of your Casio 10631629 Genuine Factory Pathfinder Replacement Watch Band. This band is specifically designed for Casio Pathfinder PAG240 and PAG40 watch models. Please read these instructions carefully before proceeding with installation to ensure correct fitment and longevity of your watch band.

SETUP AND INSTALLATION

Installing your new Casio replacement watch band requires careful attention to detail. It is recommended to work on a clean, well-lit surface to prevent loss of small components.

Required Tools:

- Small precision screwdrivers (appropriate size for your watch's existing screws)
- Soft cloth or protective mat

Installation Steps:

1. **Prepare Your Watch:** Place your Casio Pathfinder watch face down on a soft cloth or protective mat to prevent scratching.
2. **Remove Old Band:** Carefully locate the screws that secure the existing watch band to the watch case. Using the appropriate precision screwdriver, slowly unscrew these fasteners. It is crucial to use the correct screwdriver size to avoid stripping the screw heads. Keep the screws in a safe place as they will be reused.
3. **Detach Old Band Sections:** Once the screws are removed, gently detach the old band sections from the watch case. Note how the old band was attached for reference.
4. **Position New Band:** Take one section of the new Casio 10631629 replacement band. Align the end

of the new band with the corresponding lug on the watch case. Ensure the band is oriented correctly (e.g., buckle side for the shorter strap, holes side for the longer strap).

5. **Secure New Band:** Insert the original screws back into their respective holes, passing through the new band and into the watch case. Carefully tighten the screws. Do not overtighten, as this can damage the band or the watch case. Repeat this process for the other section of the watch band.
6. **Verify Installation:** Once both sections are attached, gently tug on the band to ensure it is securely fastened to the watch. Check that there are no gaps and that the screws are flush.



Figure 1: Front view of the Casio 10631629 Pathfinder Replacement Watch Band, showing the resin strap and stainless steel buckle.



Figure 2: Angled view of the Casio 10631629 Pathfinder Replacement Watch Band, highlighting the 'Pathfinder' logo and textured resin material.

OPERATING AND USAGE

The Casio 10631629 replacement band is designed for durability and comfort. Once installed, operate your watch as usual. The stainless steel tang buckle provides a secure closure. Ensure the band is adjusted to a comfortable fit on your wrist, neither too tight nor too loose, to allow for proper blood circulation and prevent skin irritation.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Casio replacement watch band, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the resin/rubber band with a soft, damp cloth and mild soap. Rinse thoroughly with clean water and dry completely with a soft towel. Avoid harsh chemicals or abrasive cleaners, which can damage the material.
- **Avoid Extreme Conditions:** While the band is durable, prolonged exposure to direct sunlight, extreme temperatures, or harsh chemicals (e.g., solvents, strong detergents) can cause material degradation or discoloration.
- **Inspect Regularly:** Periodically check the band for any signs of wear, cracks, or damage. Also, ensure the screws securing the band to the watch case remain tight.

TROUBLESHOOTING

If you encounter issues during or after installation, consider the following:

- **Band Does Not Fit:** Ensure you have the correct replacement band for your specific Casio Pathfinder model (PAG240 or PAG40). Verify that the band is oriented correctly during installation.
- **Screws Are Difficult to Remove/Install:** Use the correct size precision screwdriver. If screws are stripped, professional assistance may be required. Do not force screws.

- **Band Feels Loose After Installation:** Double-check that all screws are fully tightened. Ensure the band ends are properly seated within the watch lugs.
- **Skin Irritation:** Ensure the band is clean and dry. If irritation persists, adjust the tightness or consult a medical professional.

SPECIFICATIONS

Product Name	Casio Genuine Factory Pathfinder Replacement Band
Model Number	10631629
Compatible Models	Casio Pathfinder PAG240, PAG40
Material	Resin/Rubber
Color	Black
Band Width	18mm - 29mm
Clasp Type	Tang Buckle (Stainless Steel)
Item Length	6 inches
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	0.63 ounces
Manufacturer	Casio

WARRANTY AND SUPPORT

This Casio Genuine Factory Replacement Band is manufactured to high-quality standards. For specific warranty information, please refer to the documentation provided with your original Casio watch or contact Casio customer support directly. Keep your purchase receipt as proof of purchase. For further assistance or inquiries, please visit the official Casio website or contact their customer service department.