

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [tectake](#) /

› [tectake Garden Table 150x90x74.5cm Instruction Manual, Model 404402](#)

tectake 404402

tectake Garden Table 150x90x74.5cm Instruction Manual

Model: 404402

1. PRODUCT OVERVIEW

The tectake Garden Table, Model 404402, is designed for outdoor use, offering a modern aesthetic and robust construction. Its frame is made from powder-coated aluminum, and the tabletop consists of durable polystyrene slats that mimic wood. This table is suitable for various outdoor settings, including gardens, patios, and balconies.




Image 1.1: The tectake Garden Table, Model 404402, showcasing its modern design and sturdy construction.

Key features include weather resistance, easy maintenance, and adjustable feet to ensure stability on uneven surfaces. The table's dimensions are 150 cm (length) x 90 cm (width) x 74.5 cm (height), with a maximum load capacity of 150 kg.



Image 1.2: The tectake Garden Table positioned on a balcony, demonstrating its suitability for various outdoor environments.

2. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure safe use and prevent injury or damage:

- **Weight Limit:** Do not exceed the maximum weight capacity of 150 kg (330 lbs) on the tabletop.
- **Stability:** Always ensure the table is stable before use. Adjust the feet as necessary to compensate for uneven ground.
- **Assembly:** Assemble the table strictly according to the provided instructions. Improper assembly can lead to instability and potential hazards.
- **Pinch Points:** Exercise caution during assembly and adjustment of feet to avoid pinching fingers or other body parts.
- **Anchoring:** If used in windy conditions or on sloped surfaces, consider anchoring the table to prevent tipping.
- **Children:** Keep children away from the table during assembly. Do not allow children to climb on or play unsupervised around the table.

3. PACKAGE CONTENTS

Upon opening the package, verify that all components are present and undamaged:

- Garden Table components (frame, tabletop slats)
- Mounting hardware (screws, bolts, washers, caps)
- Assembly instructions manual

If any parts are missing or damaged, please contact tectake customer support before proceeding with assembly.

4. ASSEMBLY INSTRUCTIONS

Follow these steps for proper assembly of your tectake Garden Table. It is recommended to assemble the table on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Identify all frame pieces, tabletop slats, and hardware.
2. **Assemble Frame:** Connect the side frames to the crossbars using the provided screws and tools. Ensure all connections are secure but do not overtighten initially.
3. **Attach Tabletop Slats:** Position the tabletop slats onto the assembled frame. The slats are designed to fit securely. Fasten them to the frame using the appropriate hardware.



Image 4.1: Underside view of the table frame, illustrating how the tabletop slats are secured.

4. **Install Adjustable Feet:** Locate the adjustable feet. Insert them into the designated holes at the bottom of two table legs. Twist the feet to adjust their height.




Image 4.2: Detail of the adjustable foot, showing the mechanism for height adjustment.

5. **Insert Caps:** Once all screws are tightened and the table is stable, insert the protective caps into any visible screw holes on the frame for a finished look and added protection.



Image 4.3: A hand demonstrating the insertion of a protective cap into a table leg.

6. **Final Tightening:** Once the table is fully assembled and standing upright, gently tighten all screws to ensure maximum stability. Avoid overtightening.

5. USAGE

The tectake Garden Table is designed for versatile outdoor use. Here are guidelines for optimal operation:

- **Placement:** Place the table on a flat, stable surface. Utilize the adjustable feet to level the table if the ground is uneven.
- **Load Distribution:** Distribute weight evenly across the tabletop. Avoid placing heavy objects on one side to prevent tipping.
- **Weather Conditions:** While weather-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, strong winds) may reduce the product's lifespan. Consider covering or storing the table during harsh weather.
- **Temperature:** Avoid placing extremely hot items directly on the tabletop without protection, as this may cause damage to the plastic slats.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your garden table:

- **Cleaning:** Clean the table regularly with a soft cloth, mild soap, and water. Avoid abrasive cleaners or harsh chemicals, which can damage the finish or material.
- **Inspection:** Periodically inspect all screws and connections to ensure they remain tight. Retighten if necessary.
- **Storage:** During off-season or extended periods of non-use, store the table in a dry, protected area to prolong its life.
- **Surface Protection:** Use placemats or coasters to protect the tabletop from scratches and heat marks.

7. TROUBLESHOOTING

This section addresses common issues you might encounter:

- **Table is Wobbly:**
 - Ensure all assembly screws are securely tightened.
 - Adjust the leveling feet on the table legs to compensate for uneven ground.
 - Verify that the table is placed on a flat surface.
- **Difficulty Assembling:**
 - Refer to the assembly instructions carefully.
 - Ensure all parts are correctly oriented before tightening screws.
 - Do not force components together; if parts do not fit, re-check the instructions and part identification.
- **Scratches or Damage:**
 - Minor scratches on the aluminum frame can sometimes be touched up with appropriate paint.
 - For significant damage, contact customer support for potential replacement parts.

8. SPECIFICATIONS


AFMETINGEN	TECHNISCHE DETAILS	INHOUD
Totale afmetingen 150 x 90 x 74,5 cm	Draagkracht 150 kg Gewicht ca. 16 kg Materiaal gepoedercoat aluminium, polystyreen	Tuintafel Montagemateriaal Montageanleitung
Afmeting per lamel 85,8 x 9 x 1,2 cm		
Afstand tussen lamellen 0,5 cm		
Hoogteverstelbaarheid voetjes 1 cm		
Afmetingen zijn bij benadering		
		

Image 8.1: Technical diagram illustrating the dimensions and key specifications of the tectake Garden Table.

Technical Data

Feature	Detail
Model Number	404402
Brand	tectake
Overall Dimensions (L x W x H)	150 cm x 90 cm x 74.5 cm
Tabletop Slat Dimensions (L x W x H)	85.8 cm x 9 cm x 1.2 cm (approx.)
Gap between Slat	0.5 cm (approx.)
Adjustable Feet Height	Up to 1 cm
Maximum Load Capacity	150 kg (330 lbs)
Weight	15.8 kg (34.8 lbs)
Frame Material	Powder-coated Aluminum

Feature	Detail
Tabletop Material	Polystyrene (Plastic)
Color	Grey/Silver
Intended Use	Outdoor

9. WARRANTY AND SUPPORT



For information regarding warranty coverage, replacement parts, or technical support, please refer to your purchase documentation or contact tectake customer service directly. Contact details can typically be found on the manufacturer's official website or through your retailer.




When contacting support, please have your model number (404402) and proof of purchase readily available.

© 2025 tectake. All rights reserved.

This manual is for informational purposes only. tectake reserves the right to make changes to product specifications without prior notice.

Related Documents - 404402

	<p>TecTake Rattan Garden Furniture Assembly Instructions</p> <p>Comprehensive assembly instructions for TecTake rattan garden furniture sets, including a detailed parts list and step-by-step visual guidance. Model numbers: 403696, 403697, 403880, 403881.</p>
	<p>TecTake 402756 Home Gym Assembly and Exercise Guide</p> <p>Instruction manual for the TecTake 402756 home gym, covering assembly, safety precautions, and exercise guidance. Includes preparation tips and warm-up/cool-down routines.</p>
	<p>TecTake 400777 Semi-Automatic Washing Machine User Manual and Instructions</p> <p>This user manual provides comprehensive instructions for the TecTake 400777 semi-automatic washing machine, covering installation, operation, safety guidelines, and maintenance. Learn how to effectively wash and spin your clothes with this efficient appliance.</p>

	<p><u>tectake Gazebo Instruction Manual - Assembly Guide</u></p> <p>Comprehensive instruction manual for assembling and maintaining your tectake gazebo. Includes parts list, step-by-step assembly, location advice, care instructions, and contact information.</p>
	<p><u>TecTake 400926/400927 Lift Desk Assembly Instructions</u></p> <p>Step-by-step assembly guide for the TecTake 400926 and 400927 lift desk, including a detailed parts list and safety warnings.</p>
	<p><u>tectake Height-Adjustable Desk Frame Installation Guide</u></p> <p>Installation guide for the tectake height-adjustable desk frame (Item No. 402999/403000). Includes technical specifications, parts list, assembly steps, operation, and troubleshooting.</p>