Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM IT713-066V90WT0631

HOMCOM Lift Recliner Armchair with Remote Control

MODEL: IT713-066V90WT0631

Cream PU Leather

Information | Assembly | Operation | Introduction | Maintenance | Safety | Troubleshooting | Specifications | Support

1. Introduction

Thank you for choosing the HOMCOM Lift Recliner Armchair. This electric armchair is designed to provide comfort and assistance, featuring both reclining and lifting functions controlled by a wired remote. The lift function aids users in standing up from a seated position, while the recline function allows for relaxation. Please read this manual thoroughly before assembly and operation to ensure safe and correct usage.



Figure 1: The HOMCOM Lift Recliner Armchair in cream PU leather, demonstrating its lift function in a living room environment.

2. Safety Information

- **General Safety:** This product is not a toy and should be kept out of reach of children. Ensure children and pets are clear of the chair's moving parts during operation.
- **Weight Limit:** Do not exceed the maximum weight capacity of 150 kg (330 lbs). Overloading can cause damage to the chair and potential injury.
- **Power Supply:** Only use the provided power adapter. Ensure the power cord is not pinched, tangled, or placed under the chair. Disconnect power before cleaning or maintenance.
- **Placement:** Place the armchair on a level, stable surface. Ensure there is adequate clearance around the chair for reclining and lifting movements. Avoid placing near heat sources or in damp environments.
- **Operation:** Do not attempt to stop the chair's movement manually during operation. Ensure no objects obstruct the recline or lift mechanisms.

- **Medical Conditions:** Individuals with certain medical conditions should consult a physician before using a lift recliner.

3. Package Contents

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Backrest Section
- Seat Base Section with Armrests
- Power Adapter and Cable
- Wired Remote Control
- Assembly Hardware (screws, bolts, etc., if applicable)
- Instruction Manual

4. Assembly Instructions

Assembly typically requires two adults due to the weight and size of the components. The chair weighs approximately 38 kg.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Backrest:** Align the metal brackets on the backrest section with the corresponding slots on the seat base. Slide the backrest down firmly until it clicks into place. Ensure it is securely locked.
3. **Connect Wiring:** Locate the electrical cables extending from the backrest and the seat base. Connect them securely. Ensure all connections are tight.
4. **Connect Power:** Plug the power adapter into the chair's power input port, then plug the adapter into a wall outlet.
5. **Test Functions:** Use the remote control to test the recline and lift functions to ensure proper operation before use.

5. Operating Instructions

The HOMCOM Lift Recliner Armchair is operated using the wired remote control. Ensure the chair is connected to a power source before use.



Figure 2: The armchair offers three positions: fully reclined, upright, and lifted for easy standing.

5.1 Remote Control Functions



Figure 3: The wired remote control with 'Extended' and 'Retracted' buttons.

- **'Extended' Button:** Press and hold this button to recline the backrest and extend the footrest. The backrest can recline up to 145 degrees. Release the button to stop at your desired position.
- **'Retracted' Button:** Press and hold this button to return the chair to an upright position, retract the footrest, and then initiate the lift function. The chair will tilt forward up to 45 degrees to assist you in standing. Release the button to stop at your desired position.

5.2 Remote Storage

The remote control can be conveniently stored in the side pocket located on the armchair when not in use.



Figure 4: Remote control stored in the side pocket.



Figure 5: Key features of the armchair, including the side pocket.

6. Maintenance

6.1 Cleaning

- **PU Leather:** Wipe the PU leather surface with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid abrasive cleaners or solvents, as these can damage the material.
- **Frame:** Dust the metal frame and base with a dry cloth.

6.2 General Care

- Regularly check all connections and fasteners to ensure they are tight.
- Inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support for a replacement.
- Avoid exposing the chair to direct sunlight or extreme temperatures, which can cause the PU leather to fade or crack.

7. Troubleshooting

Problem	Possible Cause	Solution
Chair does not move.	No power supply.	Ensure the power adapter is securely plugged into the chair and a working wall outlet. Check if the outlet has power.
Remote control is unresponsive.	Loose connection.	Check the connection of the remote control cable to the chair. Ensure it is fully inserted.
Chair makes unusual noises.	Loose hardware or obstruction.	Inspect the chair for any loose screws or bolts and tighten them. Check for any objects obstructing the mechanism.
Recline/Lift function is jerky or incomplete.	Overload or obstruction.	Ensure the user's weight does not exceed 150 kg. Check for any obstructions in the mechanism.

If you encounter any issues not listed here or if the suggested solutions do not resolve the problem, please contact HOMCOM customer support.

8. Specifications

Feature	Detail
Brand	HOMCOM
Model	IT713-066V90WT0631
Color	Cream
Material	Polyurethane (PU Leather)
Overall Dimensions (Upright)	67L x 95D x 105H cm
Reclined Dimensions	161L x 66D x 84H cm
Lifted Dimensions	84L x 66D x 138H cm
Seat Dimensions	48L x 50D x 48H cm
Maximum Load Capacity	150 kg (330 lbs)
Maximum Recline Angle	145°
Maximum Lift Angle	45°
Item Weight	38 kg
Special Features	Lift function, Reclining backrest, Footrest, Wired remote control, Side pocket, Thick padding, Robust metal base



Figure 6: Detailed dimensions of the armchair in different configurations.



Figure 7: View of the footrest extension mechanism.



Figure 8: Demonstration of the thick padding for enhanced comfort.

9. Warranty and Customer Support

For warranty information, product support, or to report any issues, please contact HOMCOM customer service. Refer to your purchase documentation for specific warranty terms and contact details. Keep your proof of purchase for any warranty claims.

Online Support: Visit the official HOMCOM website for FAQs and support resources.

Contact Information: Please refer to the contact details provided with your product packaging or on the retailer's website where the product was purchased.

© 2023 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZNZHCBV

More documents and user manuals: **https://manuals.plus/**