Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-XF-CS01-GRY-A2-BC11

VECELO Corner Cabinet/Table Instruction Manual

Model: KHD-XF-CS01-GRY-A2-BC11

Introduction

Thank you for choosing the VECELO Corner Cabinet/Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.
This product is designed to provide versatile storage and display options in various small spaces, including living rooms, kitchens, bathrooms, and bedrooms. It features a durable metal frame and three tiers of shelving with a protective door.

Safety Information

WARNING: To prevent tip-over, secure the cabinet to the wall using the appropriate hardware provided. Always supervise children and pets when the cabinet door is open to prevent injury from pinching.

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Distribute weight evenly on shelves. Do not exceed the weight limit of 15 pounds per shelf.
- Keep small parts away from children during assembly.

Package Contents

Please verify that all components are included in your package. This product is sold as a set of two units. The following list details the components for **one** VECELO Corner Cabinet/Table unit:

- Top Panel (Engineered Wood)
- Middle Shelf (Engineered Wood)
- Bottom Shelf (Engineered Wood)
- Metal Frame Components (Legs, Side Supports, Door Frames)
- Mesh Doors (2 pieces)
- Adjustable Feet (4 pieces)
- Assembly Hardware (Screws, bolts, Allen wrench, etc.)
- Anti-Tip Kit (Wall anchor, strap, screws)
- Instruction Manual (This document)

If any parts are missing or damaged, please contact VECELO customer service for assistance.

Setup and Assembly Instructions

Assembly typically takes a short time. Follow these steps carefully:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list to ensure all items are present.
2. **Assemble the Frame:** Attach the metal frame components together using the provided screws and Allen wrench. Ensure all connections are secure but do not fully tighten screws until the entire frame is assembled.
3. **Install Shelves:** Slide the middle and bottom engineered wood shelves into their designated slots within the metal frame. Ensure they are seated correctly and level.
4. **Attach Top Panel:** Place the top engineered wood panel onto the assembled frame and secure it with the appropriate screws.
5. **Install Doors:** Attach the mesh doors to the front frame using the provided hinges and screws. Ensure the doors open and close smoothly.
6. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the cabinet legs. These can be adjusted to level the cabinet on uneven floors.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws.
8. **Install Anti-Tip Kit:** For safety, secure the cabinet to a wall using the anti-tip kit. Follow the instructions provided with the kit to properly install the wall anchor and strap.



Figure 1: Assembled VECELO Corner Cabinets, illustrating potential uses.



Figure 2: Cabinet with doors open, showing interior storage space.

Operating Instructions

The VECELO Corner Cabinet/Table is designed for simple operation:

- **Door Operation:** The cabinet features two mesh doors that open outwards. Use the handles to open and close the doors. Ensure they are fully closed to protect contents.
- **Shelf Usage:** Utilize the three tiers of shelving for organizing and displaying various items such as books, decor, small appliances, or kitchen essentials.
- **Adjustable Feet:** If the cabinet wobbles, gently turn the adjustable feet at the bottom of each leg until the cabinet is stable and level.



Figure 3: Detail of the interior shelves and their capacity.

Maintenance

To ensure the longevity and appearance of your VECELO Corner Cabinet/Table, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood surfaces.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Moisture:** While the shelves are water-resistant, prolonged exposure to moisture should be avoided.

Troubleshooting

If you encounter any issues with your VECELO Corner Cabinet/Table, consider the following:

- **Wobbling Cabinet:** Adjust the leveling feet at the bottom of the legs to stabilize the cabinet on uneven floors. Ensure all assembly screws are fully tightened.
- **Doors Not Closing Properly:** Check that the hinges are correctly installed and tightened. Ensure no items inside the cabinet are obstructing the doors.
- **Scratches or Dents:** Minor cosmetic damage can sometimes be touched up with furniture repair pens or markers that match the finish.

For persistent issues or concerns not addressed here, please contact VECELO customer support.

Specifications

Feature	Detail
Brand	VECELO
Model Name	Corner Cabinet/Table, 3-Tier Shelves with Protection Door, Metal Frame
Model Number	KHD-XF-CS01-GRY-A2-BC11
Color	Grey
Product Dimensions (D x W x H)	20" x 20" x 27.6"
Item Weight	18 Pounds (per unit)
Weight Limit (per shelf)	15 Pounds
Number of Shelves	3
Frame Material	Metal
Top Material Type	Engineered Wood
Assembly Required	Yes
Special Feature	Storage, Protection Door



Figure 4: Product dimensions for the VECELO Corner Cabinet.

Warranty and Support

VECELO is committed to providing quality products and customer satisfaction. While specific warranty details are not included in this manual, VECELO typically offers professional customer service and support for their products.
If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact VECELO customer service through your purchase platform or the official VECELO website. Please have your model number (KHD-XF-CS01-GRY-A2-BC11) and purchase information ready when contacting support.

© 2024 VECELO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZNZJTQF

More documents and user manuals: **https://manuals.plus/**