

[Manuals.plus](#) /

› [Homemory](#) /

› Homemory Flameless Votive Candles with Remote (12-Pack) Instruction Manual

Homemory HMNBQDYK12

Homemory Flameless Votive Candles with Remote (12-Pack) Instruction Manual

This manual provides detailed instructions for the safe and efficient use of your Homemory Flameless Votive Candles with Remote. Please read thoroughly before first use.

SETUP INSTRUCTIONS

Unpacking

Carefully remove all candles and the remote control from the packaging. Inspect all components for any damage. Retain packaging for future storage or transport.

Battery Installation

Each flameless votive candle requires one CR2032 button cell battery. The remote control also requires a battery (typically CR2025 or CR2032, check remote compartment for specific type).

1. Locate the battery compartment on the bottom of each candle.
2. Open the compartment and insert the CR2032 battery with the positive (+) side facing up.
3. Close the battery compartment securely.
4. For the remote control, open the battery tray on the back and insert the required battery, ensuring correct polarity.



Image: A set of Homemory Flameless Votive Candles with their warm white glow, ready for use.

OPERATING INSTRUCTIONS

Powering On/Off

Each candle has a physical ON/OFF switch located at its base. Ensure this switch is in the "ON" position for the remote control to function. To conserve battery life, turn the physical switch to "OFF" when not in use for extended periods.

Once the candles are physically switched ON, use the remote control to turn all candles ON or OFF simultaneously.

Your browser does not support the video tag.

Video: Demonstrates the operation of the Homemory Flameless LED Votive Candles, including turning them on and off

with the remote.

Remote Control Functions

The included remote control allows for convenient operation of your flameless candles:

- **ON:** Press to turn all active candles on.
- **OFF:** Press to turn all active candles off.
- **6H:** Activates a 6-hour timer. Candles will stay on for 6 hours, then turn off for 18 hours, repeating the cycle daily.
- **8H:** Activates an 8-hour timer. Candles will stay on for 8 hours, then turn off for 16 hours, repeating the cycle daily.

Christmas Decoration

perfect for holiday decorations



Image: The remote control for the flameless votive candles, showing ON, OFF, 6H, and 8H buttons.

MAINTENANCE

Battery Replacement

When the light from the candles dims or the remote control becomes unresponsive, it is time to replace the batteries.

1. Turn the candle's physical switch to "OFF".
2. Open the battery compartment at the bottom of the candle.

- 3. Remove the old CR2032 battery and dispose of it properly.
- 4. Insert a new CR2032 battery with the positive (+) side facing up.
- 5. Close the compartment securely.
- 6. For the remote, replace its battery following the same polarity guidelines.

Cleaning

To clean your flameless candles, gently wipe them with a soft, dry cloth. Do not use abrasive cleaners or immerse them in water.

TROUBLESHOOTING

Issue	Solution
Candles do not turn on with the remote.	Ensure the physical ON/OFF switch on the bottom of each candle is in the "ON" position. Check if the remote control's battery needs replacement.
Remote control stops working after turning candles off.	After using the remote to turn candles off, you may need to manually flip the bottom switch of each candle off and then back on before the remote will work again. This resets the candles for remote functionality.
Short battery life.	To extend battery life, always turn the physical ON/OFF switch on the bottom of each candle to "OFF" when not in use, rather than relying solely on the remote's "OFF" button.
Flickering effect is inconsistent or absent.	Replace the battery in the affected candle. Low battery power can impact the flickering mechanism.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	HMNBQDYK12
Dimensions (each candle)	1.5"D x 1.5"W x 1.6"H
Material	Plastic
Light Source Type	LED
Light Color	Warm White
Power Source	Battery Powered
Battery Type (Candles)	CR2032 (12 required, pre-installed)
Estimated Battery Life	120+ Hours
Control Method	Remote Control
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

Safety Information

WARNING: Button cell battery included. Keep out of reach of children. Please do not swallow or place it inside any part of the body! Seek medical attention immediately if you suspect a battery has been swallowed or placed inside any part of the body.




Image: A graphic illustrating the battery warning for button cell batteries, emphasizing keeping them out of reach of children.

Warranty and Support

For any questions, concerns, or support regarding your Homemory Flameless Votive Candles, please contact Homemory customer service. Refer to your purchase documentation for specific warranty details and contact information.