



[Manuals.plus](#) /

› [Lifelong](#) /

› Lifelong LLGS50 Acer Manual Ignition 3 Burner Gas Stove User Manual

Lifelong LLGS50

Lifelong LLGS50 Acer Manual Ignition 3 Burner Gas Stove User Manual

Model: LLGS50


INTRODUCTION

Thank you for choosing the Lifelong LLGS50 Acer Manual Ignition 3 Burner Gas Stove. This manual provides essential information for the safe and efficient use, installation, and maintenance of your new gas stove. Please read these instructions carefully before operating the appliance and retain them for future reference.

Lifelong

PAN SUPPORTS

Power coated extra strong pan support



CONTROL KNOB

Elegant design with soft and smooth operations



Image: Lifelong LLGS50 Acer 3 Burner Gas Stove, showcasing its sleek design and three burners.

SAFETY INFORMATION

Your safety and the safety of others are paramount. Please observe the following safety precautions:

- This appliance is **ISI Certified**, ensuring it meets safety standards.
- The product is compatible with **LPG (Liquefied Petroleum Gas) only**. Do not attempt to use it with PNG (Piped Natural Gas) or any other gas type. The brand does not provide LPG to PNG conversion services.
- **Do not spill or clean with cold water when the glass surface is hot** Sudden temperature changes can damage the toughened glass.
- **Do not attempt to repair the appliance on your own** For any issues or repairs, contact Lifelong customer service.
- Ensure adequate ventilation in the kitchen area during operation.
- Keep flammable materials away from the gas stove.



FOR SMOOTH COOKING EXPERIENCE

Sturdy Pan Support



Designed to be spill proof



Ergonomically designed knobs



Image: Visual representation of key safety instructions: rotating knobs before first use, avoiding cold water on hot glass, and contacting customer service for repairs.

PRODUCT OVERVIEW AND COMPONENTS

The Lifelong LLGS50 Acer Gas Stove features a durable design for efficient cooking.

- **Toughened Glass Top:** Provides a sleek look and is easy to clean.
- **3 High-Efficiency Burners:** Designed for optimal heat distribution and fuel efficiency.
- **Manual Ignition:** Reliable and straightforward ignition system.
- **Ergonomic Spill-Proof Design:** Helps contain spills and makes cleaning easier.
- **Smoothly Operated Knobs:** For precise flame control.
- **360-Degree Multi-Directional Gas Inlet Nozzle:** Located on the right-hand side for flexible gas pipe connection.
- **Anti-Slip Legs:** Ensures stability during use.
- **Heavy-Duty Pan Stands:** Provides stable support for various cookware sizes.

Lifelong

STOVE COMES WITH A MANUAL IGNITION

Sleek toughened black glass top

Nylon knobs



ISI Certified



Sturdy Pan Support



Image: Close-up view of the power-coated pan supports and the elegant control knob for smooth operation.

Lifelong

Designed to make cooking convenient, efficient and safe.



Image: Detailed view highlighting the sturdy rubber legs, toughened glass cooktop, and high-efficiency burners.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the gas stove and all its components from the packaging. Check for any damage

during transit.

2. **Placement:** Place the gas stove on a stable, flat, and heat-resistant surface. Ensure there is sufficient clearance from walls and overhead cabinets for proper ventilation.
3. **Gas Connection:** Connect the 360-degree multi-directional gas inlet nozzle (located on the right-hand side of the stove) to an LPG cylinder using a certified gas hose and regulator. Ensure all connections are tight and leak-free. Use soapy water to check for leaks; bubbles indicate a leak.
4. **Pan Stands Installation:** Place the heavy-duty pan stands securely over each burner.



Image: The gas stove with its dimensions indicated: 69 cm in width and 41 cm in depth, useful for planning placement.

OPERATING INSTRUCTIONS

1. **First Use Preparation:** Before using the gas stove for the first time, rotate each control knob 5-6 times. This helps to ensure smooth operation and proper gas flow.
2. **Ignition:** To ignite a burner, press down on the corresponding control knob and turn it counter-clockwise to the 'SIM' (Simmer) or 'ON' position.

3. **Manual Lighting:** While holding the knob in the pressed and turned position, immediately use a manual gas lighter to ignite the burner. Release the knob once the flame is stable.
4. **Flame Adjustment:** Adjust the flame intensity by rotating the knob between the 'SIM' (low flame) and 'ON' (high flame) settings.
5. **Turning Off:** To turn off a burner, rotate the knob clockwise to the 'OFF' position. Ensure the flame is completely extinguished.



Image: A close-up of the control knob, showing 'SIM' (Simmer) and 'OFF' markings for flame control.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and efficient performance of your gas stove.

1. **Cool Down:** Always allow the gas stove to cool down completely before attempting any cleaning.
2. **Glass Top Cleaning:** Clean the toughened glass top with a soft cloth and a mild, non-abrasive detergent. Wipe dry with a clean cloth.
3. **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the glass surface and other components.
4. **Temperature Caution:** As a safety measure, **do not spill or clean with cold water when the glass surface is hot**
5. **Burner and Pan Stand Cleaning:** Remove the pan stands and burner components. Wash them with warm soapy water, rinse thoroughly, and dry completely before reassembling. Ensure burner ports are free from food debris or blockages.
6. **Knob Cleaning:** Wipe the control knobs with a damp cloth. Do not immerse them in water.

Please read & follow the instructions below, before using the Gas Stove.

Rotate all the knobs 5-6 times before using the gas stove for the first time.



Do not spill or clean with cold water when glass surface is hot.



Do not make repairs on your own, call our brand customer service.



Image: A person wearing gloves cleaning the toughened glass top of the gas stove with a sponge, demonstrating proper cleaning technique.

TROUBLESHOOTING GUIDE

If you encounter any issues with your gas stove, refer to the following common troubleshooting steps:

- **Burner not igniting:**

- Check if the gas cylinder is open and has sufficient gas.
- Ensure the gas hose and regulator are properly connected and not kinked.
- Verify that the burner cap and pan support are correctly placed on the burner.
- Use a functional manual gas lighter.
- Ensure the control knob is pressed down and turned correctly during ignition.

- **Irregular or yellow flame:**

- Clean the burner ports to remove any food debris or blockages that might be obstructing gas flow.
- Ensure the burner cap is seated correctly and not misaligned.

- **Gas smell:**

- Immediately turn off the gas supply from the cylinder.
- Open all windows and doors for thorough ventilation.
- Do not operate any electrical switches, light matches, or ignite any flames.
- Contact Lifelong customer service or a qualified gas technician immediately.

If the problem persists after following these steps, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Lifelong
Model Number	LLGS50
Colour	Black
Material	Toughened Glass
Special Feature	Manual Ignition
Number of Heating Elements	3
Controls Type	Knob
Power Source Type	Gas Powered (LPG only)
Item Dimensions (D x W x H)	41D x 69W x 13H Centimeters
Item Weight	8000 Grams
Included Components	1 N Gas Stove, 1 N User Manual, 1 N Warranty Card
Country of Origin	India

WARRANTY AND SUPPORT

Lifelong is committed to providing quality products and excellent customer service.

- **Warranty:** This product comes with a **1 Year warranty** from the date of purchase. Please refer to the warranty card included with your product for detailed terms and conditions.
- **Customer Service:** For any product-related queries, service requests, or technical support, please contact our customer care team.

Contact Information:

Phone: +91 9711558877

Email: customercare@lifelongonline.com

Address: 5th Floor, Unit No. 508, DLF South Court, Saket District Center, Saket New Delhi, India - 110017

