

[Manuals.plus](#) /

> [wa-gu-mi](#) /

> wa-gu-mi Yokozuna Shiranui Wooden 3D Puzzle Instruction Manual WGMI-YZSN

wa-gu-mi WGMI-YZSN

wa-gu-mi Yokozuna Shiranui Wooden 3D Puzzle Instruction Manual

Model: WGMI-YZSN

INTRODUCTION

This instruction manual provides guidance for the assembly and care of your wa-gu-mi Yokozuna Shiranui Wooden 3D Puzzle. This kit allows you to construct a detailed wooden model of a Yokozuna in Shiranui Style, reflecting Japanese culture. Please read these instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience.

The wa-gu-mi series offers wooden 3D puzzles designed for adults, featuring various cultural objects. This model, WGMI-YZSN, is crafted from sturdy wooden pieces that interlock without the need for glue.

PACKAGE CONTENTS

Verify that all components are present in your package before starting assembly.

- Wood sheets with precisely laser-cut pieces (typically 2 sheets).
- Instruction sheet with diagrams.



Package

Wooden
boards x 2

Instruction
sheet

Image Description: This image displays the typical contents of the wa-gu-mi puzzle package. It shows a brown cardboard package labeled "wa-gu-mi Wooden Art," two wooden sheets with various laser-cut puzzle pieces, and a folded instruction sheet with assembly diagrams.

ASSEMBLY INSTRUCTIONS (SETUP)

Follow these steps to assemble your Yokozuna Shiranui 3D puzzle. No glue is required for assembly.

- 1. Preparation:** Carefully remove all wooden pieces from the sheets. It is recommended to use a small tool, such as a craft knife or toothpick, to gently push out smaller pieces if they are not easily detached by hand. Be cautious not to break delicate parts.
- 2. Identify Pieces:** Refer to the included instruction sheet to identify each piece by its corresponding number or shape. The instruction sheet provides a visual guide for piece identification and placement.
- 3. Follow Diagrams:** Assemble the puzzle by following the step-by-step diagrams provided in the instruction sheet. Pieces are designed to interlock securely. If a piece does not fit easily, do not force it. Recheck the diagram to ensure correct orientation and piece selection.
- 4. Interlocking Mechanism:** The pieces are designed to fit snugly. Gentle pressure should be sufficient to connect them. Some pieces may require a slight twist or wiggle to align properly.
- 5. Completion:** Continue assembling until all pieces are connected and the Yokozuna Shiranui model is complete.



Image Description: This image shows two wooden sheets with numerous laser-cut puzzle pieces. Some pieces are still embedded, while others have been removed and partially assembled, demonstrating the interlocking nature of the components.



Image Description: A front view of the fully assembled wa-gu-mi Yokozuna Shiranui wooden 3D puzzle. The model depicts a sumo wrestler in a traditional stance, showcasing the intricate details and interlocking wooden construction.

CARE AND MAINTENANCE

- **Cleaning:** Dust the model gently with a soft, dry cloth or a soft brush. Avoid using water or cleaning solutions, as they may damage the wood.
- **Storage:** Store the assembled model in a dry environment, away from direct sunlight and extreme temperature fluctuations, to prevent warping or fading of the wood.
- **Handling:** Handle the model with care to avoid accidental breakage of delicate parts.

TROUBLESHOOTING

- **Pieces Not Fitting:**

Ensure you are using the correct piece for the current step and that its orientation matches the diagram. Do not force pieces together, as this can cause damage. If a piece is slightly tight, gently sand the edges with fine-grit sandpaper (not included) if necessary, but this is rarely needed.
- **Missing Pieces:**

Carefully check the wood sheets and packaging again. Sometimes small pieces can stick to the sheet or get overlooked. If a piece is genuinely missing, contact the retailer or manufacturer for assistance.
- **Broken Pieces:**

If a piece breaks during removal or assembly, a small amount of wood glue (not included) can be used to repair it. Apply sparingly and allow to dry completely before continuing assembly.

SPECIFICATIONS

Product Name	wa-gu-mi Yokozuna Shiranui Wooden 3D Puzzle
Model Number	WGMI-YZSN
Brand	wa-gu-mi
Manufacturer	Azone
Product Dimensions (Assembled)	2.56 x 6.1 x 3.74 inches (Length x Width x Height)
Item Weight	3.27 ounces
Number of Pieces	94 pieces
Recommended Age	15 years and up




Image Description: This image shows the assembled Yokozuna Shiranui wooden puzzle with arrows indicating its approximate dimensions: 6.1 inches in width, 3.7 inches in height, and 2.5 inches in depth.

SAFETY INFORMATION

- **Small Parts:** This product contains small parts and is not suitable for children under 3 years of age due to choking hazards. The manufacturer recommended age is 15 years and up.
- **Sharp Edges:** While pieces are laser-cut, some edges may be slightly sharp. Handle with care during assembly.
- **Material:** The puzzle is made of wood. Do not ingest any parts.

WARRANTY AND SUPPORT

Information regarding specific warranty terms for the wa-gu-mi Yokozuna Shiranui Wooden 3D Puzzle is not provided in the product details. For support, missing parts, or warranty inquiries, please contact the retailer where the product was purchased or the manufacturer, Azone, directly.

Refer to the packaging for potential contact information or visit the wa-gu-mi brand's official website if available.
