

Davivy BM8906

Davivy Bread Maker Machine User Manual

Model: BM8906 | Brand: Davivy

INTRODUCTION

Welcome to the Davivy Bread Maker Machine user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new bread maker. Please read this manual thoroughly before first use and keep it for future reference.

IMPORTANT SAFETY INFORMATION

For your safety, it is crucial to follow all instructions and warnings provided. Always ensure the appliance is unplugged before cleaning or when not in use. Do not immerse the main unit in water. Keep out of reach of children. For detailed safety guidelines, please refer to the official [Safety Information PDF](#).

PRODUCT OVERVIEW

The Davivy Bread Maker Machine (Model: BM8906) is designed for versatile bread making, offering 15 utility programs and a large 3.3LB capacity. It features an 850W high-power motor for efficient kneading and baking.

Key Features:

- **15 Programs:** Includes Basic, French, Whole Wheat, Sweet, Buttermilk Bread, Gluten Free, Super Rapid, Cake, Knead, Dough, Pasta Dough, Yogurt, Jam, Bake, and Homemade settings.
- **Large Capacity:** Bakes 2.2LB, 2.75LB, and 3.3LB loaves.
- **Crust Settings:** Choose from Light, Medium, or Dark crusts.
- **Delay Timer:** Up to 15-hour delay timer for fresh bread at your convenience.
- **Keep Warm Function:** Automatically keeps bread warm for up to 1 hour after baking.
- **Power-Off Memory:** Resumes operation within 10 minutes of a power interruption.
- **Non-stick Pan:** Premium BPA-free aluminum pan for even baking and easy cleaning.
- **Dual Kneading Paddles:** Ensures thorough and even dough kneading.
- **Viewing Window:** Large window on the lid allows monitoring of the baking process.

Components:

- Main Unit with Control Panel and LCD Display
- Non-stick Bread Pan
- Dual Dough Kneading Paddles
- Measuring Cup
- Measuring Spoon (Tsp&Tbsp)
- Metal Hook for lifting kneading paddles



Figure 1: Davivy Bread Maker Machine, front view with control panel and viewing window.



Figure 2: Internal view of the bread maker, highlighting the non-stick pan, dual kneading paddles, and heating elements.



Figure 3: Accessories included with your Davivy Bread Maker, including measuring tools and extra kneading paddles.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials and accessories.
2. **Cleaning:** Wash the bread pan and kneading paddles with warm, soapy water. Wipe the exterior of the bread maker with a damp cloth. Dry all parts thoroughly before assembly.
3. **Placement:** Place the bread maker on a stable, flat, heat-resistant surface, ensuring adequate ventilation around the unit.
4. **Install Kneading Paddles:** Insert the kneading paddles onto the shafts at the bottom of the bread pan. Ensure they are securely in place.
5. **Insert Bread Pan:** Place the bread pan into the main unit. Press down firmly until it clicks into position.
6. **Power Connection:** Plug the power cord into a grounded electrical outlet. The display will light up.



Figure 4: Visual guide for simple operations, including adding ingredients and starting the machine.

OPERATING INSTRUCTIONS

Basic Bread Making Steps:

1. **Add Ingredients:** Add ingredients to the bread pan in the order specified by your recipe (typically liquids first, then dry ingredients, with yeast last and not touching liquids).

2. **Select Program:** Press the "MENU" button to cycle through the 15 available programs until your desired program is selected. The program number will be displayed on the LCD.
3. **Select Loaf Size:** Press the "WEIGHT" button to choose your desired loaf size (2.2LB, 2.75LB, or 3.3LB).
4. **Select Crust Color:** Press the "COLOR" button to select your preferred crust setting (Light, Medium, or Dark).
5. **Set Delay Timer (Optional):** If you wish to delay the start of the baking process, use the "TIMER+" and "TIMER-" buttons to set the desired delay time (up to 15 hours).
6. **Start Baking:** Press the "START/STOP" button to begin the selected program. The machine will automatically mix, knead, rise, and bake the bread.
7. **Keep Warm:** After baking is complete, the machine will automatically enter a 1-hour "Keep Warm" cycle.
8. **Remove Bread:** Once the cycle is finished, unplug the machine. Using oven mitts, carefully remove the bread pan from the unit. Invert the pan to release the bread onto a wire rack to cool. Use the metal hook to remove the kneading paddles if they remain in the bread.

Understanding Programs:

The Davivy Bread Maker offers a variety of programs to suit different baking needs:

- **Basic:** For white and mixed breads.
- **French:** For light breads made from fine flour.
- **Whole Wheat:** For breads made with whole wheat flour.
- **Sweet:** For breads with high sugar content.
- **Buttermilk Bread:** Specific program for buttermilk recipes.
- **Gluten Free:** For gluten-free recipes.
- **Super Rapid:** For quick baking (under 1.5 hours).
- **Cake:** For baking cakes.
- **Knead:** For kneading dough without baking.
- **Dough:** For preparing dough for rolls, pizza, etc.
- **Pasta Dough:** For kneading pasta dough.
- **Yogurt:** For making homemade yogurt.
- **Jam:** For making fruit jams.
- **Bake:** For baking pre-prepared dough or reheating.
- **Homemade:** Customizable program for your own recipes.

15 IN 1



- | | |
|----------------------|-----------------|
| 1: Basic | 9: knead |
| 2: French | 10: Dough |
| 3: Whole Wheat | 11: Pasta dough |
| 4: Sweet | 12: Yogurt |
| 5: Butter milk Bread | 13: Jam |
| 6: Gluten free | 14: Bake |
| 7: Super rapid | 15: Homemade |
| 8: Cake | |



VARIETY OF BREADS



CAKE/DESSERT/BAKE



JAM



DOUGH



YOGURT

Figure 5: Overview of the 15 programmable options available on the Davivy Bread Maker.

15H Delay Timer

Delay time show on LCD= Time you want to complete – current time



22:00

Put the
ingredients Set



9:00

Set the
delay time



7:00

Fresh Bread

Figure 6: The 15-hour delay timer feature, allowing you to schedule baking for convenience.

3.3LB Large Capacity



Figure 7: Examples of the 3.3LB large capacity and options for 3 loaf sizes and 3 crust settings.

Official Product Video:

Your browser does not support the video tag.

Video 1: Learn how to become a master at bread with the Davivy Automatic Bread Maker. This video demonstrates key features and usage.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your Davivy Bread Maker.

- **Bread Pan:** The non-stick pan is dishwasher safe. For best results and to preserve the non-stick coating, hand washing with warm, soapy water is recommended.
- **Kneading Paddles:** Remove the paddles and clean them thoroughly after each use.
- **Housing:** Wipe the exterior of the bread maker with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.

- **Lid and Viewing Window:** Clean the lid and viewing window with a damp cloth. For stubborn stains, a mild detergent can be used.
- **Storage:** Ensure all parts are completely dry before storing the bread maker. Store in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your Davivy Bread Maker, please refer to the following general tips. For more specific problems, consult the comprehensive User Guide PDF.

Problem	Possible Cause & Solution
Bread not rising	Check yeast freshness, water temperature (too hot or cold), or incorrect ingredient measurements. Ensure yeast is not in direct contact with liquids or salt before mixing.
Bread pan sticking	Ensure the non-stick coating is intact. Lightly grease the pan before adding ingredients if necessary. Allow bread to cool slightly before removing.
Machine not starting	Check if the power cord is securely plugged in. Ensure the bread pan is correctly seated and locked. Press the START/STOP button firmly.
Unusual noise during operation	Ensure the bread maker is on a stable, flat surface. Check if the kneading paddles are properly installed. If noise persists, contact customer support.

For more detailed troubleshooting and error codes, please consult the full [User Guide \(PDF\)](#).

SPECIFICATIONS

Attribute	Detail
Brand	Davivy
Model Number	BM8906
Color	Silver
Product Dimensions	16"D x 11.8"W x 9.8"H
Wattage	850 Watt-hours
Item Weight	15 pounds
Number of Programs	15
Product Care Instructions	Dishwasher Safe for NON-STICK PAN, Hand Wash for Housing
ASIN	B09ZQLDRRF
Date First Available	June 29, 2022

WARRANTY AND SUPPORT

The Davivy Bread Maker Machine comes with a 1-year warranty. Davivy offers 7x24 customer service to assist you with any questions or concerns. Additionally, there is a 30-day no-reason return policy for the product. For support, please refer to the contact information provided with your purchase or visit the official Davivy store on Amazon: [Davivy Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question