

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Aoodor](#) /

> [Aoodor 10x10 ft Outdoor Pergola with Retractable Shade Canopy Instruction Manual](#)

Aoodor 800-056-BR

Aoodor 10x10 ft Outdoor Pergola with Retractable Shade Canopy

Model: 800-056-BR

Brand: Aoodor

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Aoodor 10x10 ft Outdoor Pergola with Retractable Shade Canopy. This pergola is designed to enhance your outdoor living space, offering adjustable shade and a durable structure for various outdoor settings.

Key features include a robust matte aluminum frame, four retractable roller shade curtains, and premium polyester fabric that is UV and fade-resistant, with a PA coating for water resistance.

SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use.

- Always inspect the product upon arrival for any damages. If damaged, contact customer support immediately.
- Exercise caution when assembling and disassembling the pergola due to its weight and size. It is recommended that two people perform the installation.
- Ensure the pergola is securely anchored to the ground to prevent tipping, especially in windy conditions.
- Do not use the pergola in extreme weather conditions, such as heavy winds, snow, or severe storms. Retract the canopy and curtains during such conditions.
- Keep children and pets away from the assembly area.

ASSEMBLY AND SETUP

The assembly process typically requires two people and can be completed in approximately 2 hours. All parts are clearly labeled with letters, and step-by-step instructions are included in the packaging.

1. **Unpack Components:** Carefully unpack all parts and verify against the parts list provided in your package. Ensure no components are missing or damaged.
2. **Assemble Frame:** Follow the numbered steps in the instruction manual to connect the aluminum frame components. Ensure all bolts and screws are tightened securely.

3. **Attach Canopy Rails:** Install the rails for the retractable canopy onto the top frame structure.
4. **Install Retractable Canopy:** Slide the canopy fabric onto the designated rails. Ensure the pulley system operates smoothly.
5. **Install Roller Curtains:** Attach the four roller shade curtains to the side posts as indicated in the manual.
6. **Anchor the Pergola:** Securely anchor the pergola to a stable surface (cement, lawn, or concrete) using appropriate hardware. This is crucial for stability and safety.



Stable Anchoring Stand



Cement Applicable




Lawn Applicable




Concrete Applicable

Image: Detail of the stable anchoring stand, showing applicability for cement, lawn, and concrete surfaces.

10' x 10' DIMENSIONS



ANCHOR BLUEPRINT



Various Color Options:

Image: An illustration of the pergola's anchoring stand, highlighting its sturdy design and ease of installation with rust-proof accessories.

OPERATING INSTRUCTIONS

Retractable Canopy

The pergola features an easily adjustable canopy for optimal shade. To adjust the canopy:

- **Extend Canopy:** Gently pull the canopy fabric along its rails to extend it over the desired area.
- **Retract Canopy:** Push the canopy fabric back along its rails to retract it.
- **Secure Position:** Use the integrated locking system to secure the canopy in your preferred position. Ensure it is firmly locked to prevent unwanted movement.



Image: A close-up view of the adjustable canopy mechanism, showing how it can be extended or retracted for optimal shade.



Image: An illustration demonstrating the adjustable canopy in both open and closed positions, providing control over shaded space.

Roller Shade Curtains

The four roller shade curtains provide additional privacy and sun protection. They can be used on one side or both sides of the pergola.

- **Deploy Curtains:** Unroll the curtains to the desired length.
- **Retract Curtains:** Roll up the curtains when not needed.

Your browser does not support the video tag.

Video: This video demonstrates the features of the Aoodor Outdoor Aluminum Pergola, including the functionality of the retractable canopy and side shades.

MAINTENANCE

Regular maintenance will prolong the life and appearance of your pergola.

- **Cleaning Frame:** Wipe the aluminum frame with a damp cloth and mild soap. Rinse thoroughly and dry to prevent water spots. Avoid abrasive cleaners.
- **Cleaning Fabric:** The polyester canopy and curtains are washable. Clean with mild soap and water. Allow to air dry completely before retracting or storing to prevent mildew.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Inspect the fabric for any tears or damage.
- **Winter Storage:** In areas with harsh winters, it is recommended to remove the canopy and curtains and store them indoors. The aluminum frame can typically remain outdoors, but covering it is advisable.

100% Polyester



Washable



UV-Protected



Wear-Resistant



Water-Resistant




Image: An illustration highlighting the key properties of the pergola's polyester fabric: washable, UV-protected, wear-resistant, and water-resistant.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Canopy or curtains do not slide smoothly.	Obstruction in the rails, dirt buildup, or misaligned components.	Inspect rails for debris and clean. Ensure all components are correctly aligned and lubricated if necessary.
Pergola feels unstable or wobbly.	Anchoring not secure, loose bolts, or uneven ground.	Verify that the pergola is properly anchored to a stable surface. Tighten all frame bolts. Ensure the installation surface is level.
Water pooling on canopy.	Canopy not fully extended or improper tension.	Ensure the canopy is fully extended and taut. Adjust tension if possible. Retract canopy during heavy rain.
Missing parts during assembly.	Packaging error or lost during unpacking.	Carefully check all packaging materials. Contact Aoodor customer support with your model number and part description for assistance.

SPECIFICATIONS

Model: 800-056-BR

Brand: Aoodor

Product Dimensions: 120"L x 120"W x 87.4"H (10 ft L x 10 ft W x 7.28 ft H)

Frame Material: Aluminum (Matte finish, powder-coated for rust and corrosion resistance)

Canopy & Curtain Material: Premium Polyester Fiber (UV-protected, fade-resistant, PA coated for water resistance)

Color: Brown

Shape: Square

Assembly Required: Yes

UPC: 671716579649

ASIN: B09ZQM2SN7

Product Dimension Drawing

Included: Canopy rolling curtain




Image: Detailed product dimension drawing for the 10x10 ft pergola, including canopy and rolling curtain measurements.

Rust-resistant Aluminum

Lightweight and durable aluminum frame



Image: A close-up view of the pergola's rust-resistant aluminum frame, highlighting its lightweight and durable construction.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Aoodor directly through their official website or the retailer where the product was purchased.

Note: Specific warranty terms may vary by region and retailer.