

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [UHURU](#) /

› [UHURU UEKM-20 Ergonomic Wireless Keyboard and Mouse Combo User Manual](#)

## UHURU UEKM-20

# UHURU UEKM-20 Ergonomic Wireless Keyboard and Mouse Combo User Manual

Model: UEKM-20

## 1. INTRODUCTION

Thank you for choosing the UHURU UEKM-20 Ergonomic Wireless Keyboard and Mouse Combo. This product is designed to provide a natural and comfortable typing and navigation experience, reducing strain and fatigue during extended use. Its advanced ergonomic features promote a healthier posture for your wrists and forearms.



Image: The UHURU UEKM-20 Ergonomic Wireless Keyboard and Mouse Combo, featuring the split keyboard design, integrated palm rest, and the ergonomic vertical mouse, alongside the 2.4G USB receiver.

## 2. PACKAGE CONTENTS

---

Please check the package contents to ensure all items are present:

- 1 x UHURU UEKM-20 Ergonomic Wireless Keyboard
- 1 x UHURU Ergonomic Wireless Mouse
- 1 x 2.4G USB Nano Receiver
- 2 x AA Batteries (for keyboard)
- 2 x AAA Batteries (for mouse)
- 1 x User Manual (this document)

## 3. PRODUCT OVERVIEW

---

Familiarize yourself with the key features of your new ergonomic combo.

### 3.1. Ergonomic Keyboard Features

- **Split Ergonomic Design:** The keyboard is split into two sections with a natural arc key layout, promoting a more natural hand and wrist position.
- **Integrated Palm Rest:** A built-in palm rest provides comfortable support for your wrists, keeping them level with the keyboard.
- **Adjustable Tilt Legs:** Foldable legs on the underside allow you to adjust the keyboard's tilt for optimal comfort, whether sitting or standing.
- **Low-Profile Keys:** Designed for fast and comfortable typing with reduced key travel.
- **Multimedia Shortcuts:** Dedicated keys for quick access to media controls and other functions.

# SPLIT ERGONOMIC DESIGN

Promotes a natural and comfortable typing experience



Image: A user's hands positioned on the split ergonomic keyboard, illustrating how the design promotes a natural and comfortable typing experience by allowing wrists to remain straight.

# NATURAL TYPING

Reduces Muscle Strain on Your Wrists and Forearms



Image: A side view of a user typing on the ergonomic keyboard, demonstrating the natural wrist and forearm alignment that reduces muscle strain.

## 3.2. Ergonomic Mouse Features

- **Ergonomic Shape:** Designed to fit the natural contours of your hand, reducing wrist pronation.
- **6 Buttons:** Standard left/right click, scroll wheel, DPI adjustment button, and two side buttons for navigation.
- **Adjustable DPI:** Cycle through 800, 1200, and 1600 DPI settings to adjust cursor sensitivity.

# HIGH SENSITIVITY

Easily Switch Between 3 DPI Levels




Image: The ergonomic mouse highlighting its adjustable DPI settings (800, 1200, 1600) and its comfortable design for hand placement.

## 4. SETUP

Follow these steps for initial setup of your UHURU UEKM-20 combo.

### 4.1. Battery Installation

#### 1. For the Keyboard:

- Locate the battery compartment on the underside of the keyboard.
- Open the battery cover.
- Insert two (2) AA batteries, ensuring correct polarity (+/-).

- Close the battery cover securely.

## 2. For the Mouse:

- Locate the battery compartment on the underside of the mouse.
- Open the battery cover.
- Insert two (2) AAA batteries, ensuring correct polarity (+/-).
- Close the battery cover securely.



Image: Illustrations showing the battery compartments for both the keyboard (AA batteries) and the mouse (AAA batteries), along with the location of the 2-in-1 USB Nano receiver.

## 4.2. Connecting the USB Nano Receiver

1. Locate the 2.4G USB Nano receiver, typically stored in the mouse's battery compartment for safekeeping during transport.

2. Plug the USB Nano receiver into an available USB port on your computer (PC, Laptop, Smart TV, Surface Pro, etc.).
3. The keyboard and mouse are designed for plug-and-play functionality and should connect automatically within a few seconds. No additional drivers are typically required.

Your browser does not support the video tag.

Video: An overview of the UHURU UEKM-20 Ergonomic Keyboard and Mouse Combo, demonstrating its features and ease of setup. This video highlights the ergonomic design, battery installation, and USB receiver connection.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Keyboard Usage

- **Ergonomic Typing:** Position your hands naturally on the split keyboard, allowing your wrists to rest comfortably on the integrated palm rest. Adjust the tilt legs on the underside of the keyboard to find your preferred typing angle.
- **Multimedia Keys:** The keyboard features 13 multimedia shortcut keys located along the top row. These keys allow for quick access to functions such as volume control, play/pause, web browser, email, and more. Refer to the keyboard layout for specific icons.
- **Compatibility:** The keyboard is compatible with various operating systems including Windows 10/11/8/7/Vista/XP, and Chrome OS. It supports PC, Laptop, Smart TV, and Surface Pro devices.

# RELIABLE 2.4G WIRELESS CONNECTION



## 13 Multimedia Shortcuts



Image: The ergonomic keyboard displaying its multimedia shortcut keys and illustrating the reliable 2.4G wireless connection to a laptop.

## 5.2. Mouse Usage

- Ergonomic Grip:** Hold the mouse with your hand in a natural, handshake-like position to reduce wrist pronation.
- DPI Adjustment:** Press the DPI button (usually located behind the scroll wheel) to cycle through the three available DPI settings: 800, 1200, and 1600. Choose the sensitivity that best suits your needs.
- Side Buttons:** Use the two side buttons for forward and backward navigation in web browsers or file explorers.

Your browser does not support the video tag.

Video: A demonstration of the ergonomic keyboard and mouse in use, highlighting the comfortable typing posture and the adjustable palm lift feature of the keyboard.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your UHURU UEKM-20 combo.

- Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp

cloth with mild soap can be used, ensuring no liquid enters the devices.

- Battery Replacement:** Replace batteries when performance degrades (e.g., delayed response, connection issues). Always use new batteries of the specified type (AA for keyboard, AAA for mouse).
- Storage:** When not in use for extended periods, remove the batteries to prevent leakage. Store the devices in a cool, dry place.
- Avoid Extreme Conditions:** Do not expose the devices to extreme temperatures, direct sunlight, or excessive moisture.

## 7. TROUBLESHOOTING

If you encounter issues, please refer to the following common solutions:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding.	Low or dead batteries. USB receiver not properly connected. Out of operating range.	Replace batteries with new ones. Ensure the USB receiver is firmly plugged into a working USB port. Try a different USB port. Move the keyboard and mouse closer to the USB receiver (within 30 feet).
Lagging or intermittent connection.	Interference from other wireless devices. Low battery.	Move other wireless devices (e.g., Wi-Fi routers, cordless phones) away from the receiver. Replace batteries.
Mouse cursor erratic or not moving smoothly.	Dirty optical sensor. Unsuitable surface. Incorrect DPI setting.	Clean the optical sensor on the underside of the mouse with a soft cloth. Use the mouse on a clean, non-reflective, opaque surface or a mouse pad. Press the DPI button to adjust the sensitivity.
Multimedia keys not working.	Software conflict or operating system issue.	Ensure your operating system is up to date. Some functions may require specific software or settings on your computer.

## 8. SPECIFICATIONS

Feature	Detail
Model	UEKM-20
Brand	UHURU
Connectivity	2.4G Wireless (via USB Nano Receiver)
Operating Range	Up to 30 feet (10 meters)
Keyboard Battery	2 x AA Batteries (included)
Mouse Battery	2 x AAA Batteries (included)
Mouse DPI Settings	800 / 1200 / 1600 DPI
Keyboard Dimensions (L x W x H)	17.3 x 4.9 x 0.9 inches (43.9 x 12.4 x 2.3 cm)
Item Weight	3.54 pounds (1.6 kg)
Color	Black

Feature	Detail
Compatibility	Windows 10/11/8/7/Vista/XP, Chrome OS. Supports PC, Laptop, Smart TV, Surface Pro.

## 9. WARRANTY AND SUPPORT

---

Information regarding product warranty and customer support was not provided in the available data. Please refer to the product packaging or the manufacturer's official website for the most up-to-date warranty details and support contact information.

© 2024 UHURU. All rights reserved.