W-KING T11

W-KING T11 Portable Party Bluetooth Speaker User Manual

Model: T11

Brand: W-KING

Introduction

The W-KING T11 is a powerful 240W Max portable Bluetooth speaker designed to deliver massive sound and vibrant party lights for various indoor and outdoor events. Featuring IPX6 waterproofing, dual subwoofers, dual tweeters, and advanced DSP technology, it provides a high-fidelity audio experience with deep bass and clear highs. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your speaker.

What's in the Box

- 100W Bluetooth Speaker (W-KING T11)
- T11 15V 1.6A DC Power Adapter
- 3.5mm Audio Cable
- User Manual

Product Features

Powerful Audio Performance

The T11 speaker is engineered with dual 5.25" subwoofers, dual 1.2" tweeters, and dual passive radiators, delivering a peak output of 240W (100W RMS). This configuration ensures breathtaking immersive stereo sound with incredibly powerful and springy bass, detailed and warm mids, and bright, airy treble. Advanced DSP chip technology minimizes distortion and enhances impactful bass for a hi-fi sound experience.



Figure 1: Internal components of the W-KING T11 speaker, highlighting the dual 5.25" woofers, dual 1.2" tweeters, and passive radiators for powerful sound delivery.

Massive Loudness and DSP Technology

Achieving 115dB of impactful sound, the T11 can cover extensive areas, making it suitable for large outdoor parties, basketball courts, or any event requiring loud, clear, and uncompromising audio. The integrated DSP chip ensures zero distortion and enhanced bass, providing a robust and immersive sound experience for all music genres.



Figure 2: The W-KING T11 speaker showcasing its powerful 115dB sound output and dynamic party lights in an outdoor event setting.

IPX6 Waterproof and Long Playback

With an IPX6 waterproof rating, the T11 is protected against powerful water jets, making it ideal for outdoor use, poolside parties, or beach gatherings. The large rechargeable lithium-ion battery provides up to 24 hours of continuous playback (actual playtime varies with volume and usage). It also functions as an emergency power bank to charge your smart devices via its USB port.



Figure 3: The W-KING T11 speaker's IPX6 waterproof design, shown with water splashing on it in a beach environment.



Figure 4: The W-KING T11 speaker acting as a power bank, charging a smartphone, highlighting its 24-hour battery life.

Connectivity and Controls

The T11 features Bluetooth 5.3 for faster and more stable wireless connections. It supports multiple playback modes including TF card, 3.5mm AUX audio cable, and USB flash drive. For enhanced audio, two T11 speakers can be wirelessly paired for a 480W ultra-stereo surround soundstage. The speaker also includes dedicated inputs for a 6.35mm microphone and guitar, with independent volume and ECHO controls.



Figure 5: The W-KING T11 speaker connected via Bluetooth 5.3, emphasizing its fast and stable wireless capabilities.



Figure 6: The W-KING T11 speaker's microphone and guitar input ports, allowing for karaoke and live instrument use.

RGB Party Lights and EQ Modes

Mesmerize your audience with a dazzling, dynamic light show that dances to the beat. The T11 offers 8 colors and 6 settings for its RGB party lights, creating a fiery party atmosphere. It also features EQ modes (bass and treble) for indoor and outdoor use, allowing you to tailor the sound to your preference by long-pressing the 'Triangular Tandem' button for 2 seconds.



Figure 7: The W-KING T11 speaker's dynamic RGB party lights with multiple colors and modes, enhancing the party ambiance.

Setup

1. **Charging the Speaker:** Before first use, fully charge the speaker using the provided 15V/1.6A DC power adapter. Connect the adapter to the charging port on the back of the speaker. The charging time is approximately 3.5 hours.

   Note: Use only the supplied power adapter or a compatible 15V 1.6A DC Power Adapter with a 5.5mm x 2.1mm plug.

2. **Powering On/Off:** Press and hold the power button) on the top panel for 1 second to turn the speaker on or off.

Operating Instructions

1. **Bluetooth Pairing:**
   - Turn on the W-KING T11 speaker. It will automatically enter Bluetooth pairing mode.
   - Enable Bluetooth on your smartphone or audio device.
   - Search for "W-KING T11" in the list of available devices and select it to pair.

- A voice prompt will confirm successful pairing.

2. **True Wireless Stereo (TWS) Pairing:**
   - Ensure both T11 speakers are powered on and not connected to any other Bluetooth device.
   - On one speaker, long-press the TWS button ) for 2 seconds.
   - The speakers will automatically connect to each other. A voice prompt will confirm TWS pairing.
   - Connect your Bluetooth device to one of the paired T11 speakers. Both speakers will now play in stereo.
3. **Adjusting Volume:** Use the '+' and '-' buttons on the top panel to adjust the main volume.
4. **EQ Mode Selection:** Long-press the 'Triangular Tandem' button (often combined with TWS button) for 2 seconds to switch between bass and treble modes (indoor/outdoor).
5. **Microphone/Guitar Usage:**
   - Plug your 6.35mm dynamic microphone or guitar into the respective input jack on the back.
   - Adjust the MIC/GUITAR volume using the dedicated controls on the top panel.
   - Adjust the ECHO effect using the ECHO '+' and '-' buttons. Note: When using this function, please press the ECHO '-' button to adjust it to 0 if you do not want echo.

Specifications

Feature	Detail
Brand	W-KING
Model Name	T11
Speaker Type	Subwoofer, 2*5.25" woofers, and 2*1.2" tweeters
Speaker Maximum Output Power	240 Watts (Peak)
Water Resistance Level	IPX6 Waterproof
Battery Life	24 Hours (varies with volume)
Battery Capacity	5200 Milliamp Hours (10.8V)
Connectivity Technology	Bluetooth 5.3, U-Disk, Auxiliary, TF Card
Special Features	Bass Boost, Multi Room Audio (TWS), ECHO, GUITAR PORT, USB Port (Power Bank), 6.35mm MIC
Product Dimensions	8.1"D x 8.64"W x 17.4"H
Item Weight	14.37 pounds (6.53 Kilograms)

Maintenance

- Keep the speaker clean by wiping it with a soft, dry cloth.
- Avoid exposing the speaker to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- Ensure all port covers are securely closed when not in use, especially in wet environments, to maintain IPX6 rating.
- Store the speaker in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is already paired or device Bluetooth is off.	Ensure speaker is in pairing mode. Turn off and on Bluetooth on your device. Forget previous pairings.
No sound or low volume.	Volume too low on speaker or device; incorrect input mode.	Increase volume on both speaker and device. Check input mode (Bluetooth, AUX, USB, TF).
Sound distortion at high volume.	Volume too high; audio source quality.	Reduce volume. Try a different audio source.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided in the included User Manual or visit the official W-KING website. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question