Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yitong Angel MT05-JD-14Q

Yitong Angel 14 Inch Queen Bed Frame Instruction Manual

Model: MT05-JD-14Q

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Yitong Angel 14 Inch Queen Bed Frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Yitong Angel 14 Inch Queen Bed Frame, fully assembled, in a bedroom setting.

Safety Information

- Exercise caution around sharp edges during assembly to prevent injury.
- Do not load the bed frame with more than 3500 pounds (approximately 1587 kg) of weight. Exceeding this limit may compromise structural integrity and safety.
- Ensure all bolts and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep small parts away from children during assembly to avoid choking hazards.

Package Contents

Before assembly, verify that all components are present. If any parts are missing or damaged, please contact customer support.

- Bed Frame Components (various metal bars and legs)
- Steel Slats
- Assembly Tools (e.g., Allen wrench)
- Non-slip Mattress Gaskets (4 pieces)
- Thickened Rubber Pads (for feet)



Image: Key components of the bed frame, highlighting the strong structure, anti-slip gaskets, and rubber foot pads.

Assembly Instructions

Assembly typically takes approximately 15 minutes. All necessary tools are included. It is recommended to assemble the bed frame with two people for ease and safety.

Step-by-Step Guide:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to

prevent scratches.

2. **Connect Frame Sections:** Follow the diagrams provided in your physical instruction manual to connect the main frame sections using the provided bolts and the Allen wrench. Ensure all connections are snug but do not overtighten until all sections are aligned.
3. **Install Center Supports:** Attach any central support legs or bars as indicated in the manual. These are crucial for the bed frame's heavy-duty capacity.
4. **Place Steel Slats:** Position the steel slats across the frame. The U-shaped groove design helps fix the slats in place.
5. **Apply Anti-slip Features:** Attach the four strips of tape (anti-slip gaskets) to the steel slats to reduce mattress slippage. Install the thickened rubber pads onto the bottom of the bed frame support feet to prevent sliding and protect your floor.
6. **Final Tightening:** Once all parts are correctly aligned, fully tighten all bolts.

Assembly Videos:

Your browser does not support the video tag.

Video: Detailed assembly guide for the Yitong Angel bed frame (Model MT05-14Queen, King, Full).

Your browser does not support the video tag.

Video: Instructions on how to correctly install the mattress stopper to prevent mattress movement.

Visual Aids for Assembly:



Image: Detail of the U-shaped groove for slat stability and the horizontal add-on tube for enhanced load-bearing.



Image: Illustration of the thickened rubber pad for noise-free and anti-slip floor protection.

Operating Instructions

Your Yitong Angel bed frame is designed for optimal support and convenience.

- **Mattress Placement:** Place your mattress directly onto the steel slats. A box spring is not required. The integrated anti-slip features will help keep your mattress in place.
- **Under-bed Storage:** Utilize the 12-inch clearance beneath the 14-inch high frame for convenient storage of items such as seasonal clothing, shoes, or storage bins.



Image: The bed frame illustrating the 12-inch under-bed storage space.

Maintenance

- **Regular Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if any looseness is detected to maintain stability and prevent noise.
- **Cleaning:** Wipe the metal frame with a damp cloth and mild detergent if necessary. Avoid abrasive cleaners that could damage the finish.
- **Weight Distribution:** Distribute weight evenly across the bed frame to prolong its lifespan and maintain structural integrity.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Bed frame is noisy (squeaking/creaking)	Loose bolts or connections.	Check and tighten all bolts and fasteners. Ensure all parts are properly seated.
Mattress slides on the frame	Anti-slip tape/gaskets not installed or worn.	Ensure the provided anti-slip tape/gaskets are correctly applied to the slats. Replace if worn.
Frame feels unstable or wobbly	Incomplete assembly or loose connections. Uneven floor.	Verify all assembly steps are completed and all bolts are securely tightened. Ensure the bed is on a level surface.

Specifications

Feature	Detail
Size	Queen
Material	Alloy Steel
Product Dimensions (L x W x H)	79.5"L x 59.5"W x 14"H
Style	14 inch
Special Features	Easy Assembly, Heavy Duty Metal, Steel Slat Support, No Box Spring Needed, Squeak Resistant
Included Components	Slat, Frame Components, Assembly Tools
Maximum Weight Recommendation	3500 pounds
Under-bed Clearance	12 inches
Item Weight	33 pounds
Model Number	MT05-JD-14Q
UPC	794261899007




Image: Dimensions and capacity details for the Queen size bed frame.

Warranty and Support

For any questions, missing parts, or support needs, please contact Yitong Angel customer service. Refer to your purchase documentation for specific warranty details.
You can visit the official Yitong Angel Store on Amazon for more information and contact options.

© 2026 Yitong Angel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZRVBFFQ

More documents and user manuals: **https://manuals.plus/**