Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yitong Angel MT09-JD-14F

Yitong Angel 14 Inch Full Size Bed Frame Instruction Manual

Model: MT09-JD-14F

1. Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of**3500 lbs**. Exceeding this limit may result in structural failure and injury.
- **Sharp Edges:** Exercise caution around all metal edges during assembly and handling to prevent injury.
- **Children:** Keep small parts and packaging materials away from children.
- **Level Surface:** Assemble and use the bed frame on a flat, level surface.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary.

2. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Image: All components of the Yitong Angel Full Size Bed Frame laid out before assembly.

Included Components:

- Bed Frame Sections (Head, Foot, Side Rails)
- Steel Slats
- Support Legs
- Hardware Pack (Bolts, Washers, Allen Wrench, Ratchet Tool)
- Anti-Slip Rubber Pads
- Plastic Anti-Slip Baffles (for mattress retention)

3. Setup and Assembly

The Yitong Angel bed frame is designed for easy assembly, typically completed by one person in approximately 20 minutes. Follow these steps carefully.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list to ensure everything is present.
2. **Assemble Frame Sections:** Connect the main frame sections using the provided bolts and tools. Ensure all connections are secure but do not overtighten initially.
3. **Install Support Legs:** Attach the support legs to the frame. Ensure the anti-slip rubber pads are correctly positioned on the bottom of each leg to protect your floor and prevent sliding.
4. **Insert Steel Slats:** Place the steel slats into the designated U-shaped grooves on the side rails. The slats are designed to fit snugly and provide robust mattress support.
5. **Attach Anti-Slip Baffles:** Secure the plastic anti-slip baffles to the frame where indicated. These prevent the mattress from shifting.
6. **Final Tightening:** Once all parts are assembled, go back and securely tighten all bolts. Do not overtighten to avoid stripping threads.

7. **Headboard Attachment (Optional):** The frame features pre-drilled holes on one side for attaching a headboard (not included). Align your headboard with these holes and secure it using appropriate hardware.



Image: Detailed diagram illustrating key features for assembly and stability, including pre-drilled holes for headboard, triangular structure for strength, anti-slip rubber pads, noiseless foam tape, U-shaped grooves for slats, and non-slip taped slats.

4. Operating Instructions

This platform bed frame is designed to support your mattress directly, eliminating the need for a box spring.

- **Mattress Placement:** Carefully place your full-size mattress (75"L x 54"W) directly onto the steel slats. The integrated anti-slip baffles will help keep the mattress in place.
- **Under-Bed Storage:** The 14-inch height provides approximately 12.4 inches of vertical clearance for under-bed storage. Utilize this space for bins, luggage, or other items.



Image: The Yitong Angel bed frame with a mattress, demonstrating the ample 12.4-inch under-bed storage space, shown with luggage neatly stored.

5. Maintenance

Proper maintenance ensures the longevity and performance of your bed frame.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Fastener Check:** Periodically (e.g., every 3-6 months) inspect all bolts and connections. Tighten any loose fasteners to maintain stability and prevent noise.
- **Rubber Pads:** Ensure the anti-slip rubber pads on the legs are intact and in place to protect your flooring.

6. Troubleshooting

Common issues and their solutions.

- **Squeaking Noise:**
  - Ensure all bolts are securely tightened. Loose connections are a primary cause of squeaking.
  - Check that the steel slats are properly seated in their U-shaped grooves.
  - Verify that the noiseless foam tape (if included) is correctly applied to the slats or frame contact points.
- **Mattress Sliding:**
  - Confirm that the plastic anti-slip baffles are installed correctly and are not damaged.
  - Ensure the bed frame is on a level surface.
- **Frame Instability:**
  - Re-check all connections and ensure they are fully tightened.
  - Verify that the triangular support structures (if applicable) are correctly assembled.

7. Specifications

Product Information




Image: Graphic detailing the dimensions (74.5"L x 53.4"W x 14"H), material (Metal), and weight capacity (3500 lbs) for the Full size bed frame.

Feature	Detail
Model Number	MT09-JD-14F
Size	Full
Product Dimensions	74.5"L x 53.5"W x 14"H
Compatible Mattress Size	75"L x 54"W
Weight Capacity	3500 lbs
Material	Alloy Steel
Color	Black

Feature	Detail
Finish Type	Matte
Ground to Item Distance	12 Inches
Assembly Required	Yes
Special Features	Mattress Slide Stopper, Steel Slat Support, No Box Spring Needed, Easy Assembly, Storage Space, Squeak Resistant, Headboard Compatible

8. Warranty Information

For specific warranty details regarding your Yitong Angel bed frame, please refer to the documentation included with your purchase or contact Yitong Angel customer support directly. Protection plans may be available for purchase separately.

9. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Yitong Angel customer support through the retailer where the product was purchased or visit the official Yitong Angel store page:

Visit the Yitong Angel Store

© 2025 Yitong Angel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZRVVXR3

More documents and user manuals: **https://manuals.plus/**