

[manuals.plus](#) /› [Holstein Housewares](#) /› [Holstein Housewares 27-oz Electric Citrus Juicer \(Model HH-09101036B\) Instruction Manual](#)

Holstein Housewares HH-09101036B

Holstein Housewares 27-oz Electric Citrus Juicer

Model: HH-09101036B



Official Holstein Housewares Product Manual

1. INTRODUCTION

The Holstein Housewares 27-oz Electric Citrus Juicer is designed for efficient and convenient juice extraction from citrus fruits. This appliance features a two-way rotation system for maximum juice yield, a 27-oz BPA-free pitcher with a pouring spout, and two interchangeable cones to accommodate various fruit sizes. Its compact design ensures minimal countertop space usage, and detachable parts facilitate easy cleaning. This manual provides essential information for safe operation, assembly, maintenance, and troubleshooting.



27oz pitcher

Large capacity container,
ideal for multiple servings



Front view of the Holstein Housewares 27-oz Electric Citrus Juicer.



A kitchen essential

A must-have appliance for fresh juice at home



The compact design of the juicer, measuring approximately 6.69 inches deep, 6.69 inches wide, and 8.98 inches high.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions before operating the appliance.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electric shock, do not immerse cord, plugs, or the appliance base in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

3. PARTS LIST

Familiarize yourself with the components of your Electric Citrus Juicer:

- **Protective Lid:** Covers the reamer and filter, keeping juice fresh and preventing spills.
- **Small Reamer:** For smaller citrus fruits like lemons and limes.
- **Large Reamer:** For larger citrus fruits like oranges and grapefruits.
- **Pulp Filter:** Separates pulp and seeds from the juice.
- **Juice Pitcher (27-oz / 800ml):** Collects the extracted juice and features a pouring spout.
- **Motor Base:** Houses the motor and power cord.



Protective lid

Keeps juice fresh and prevents spills



The protective lid helps keep the juice fresh and prevents spills.

 **Freshly squeezed**
Enjoy citrus flavors with a
juicer designed for extraction



The juicer includes two cones to adapt to different citrus fruit sizes for versatile use.



Easy to clean

Detachable parts, dishwasher-safe for easy maintenance



The 27-oz pitcher provides a large capacity for multiple servings of juice.

4. SETUP AND ASSEMBLY

Before first use, wash all detachable parts (lid, reamers, filter, pitcher) in warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.

1. Place the motor base on a stable, flat, and dry surface.
2. Position the juice pitcher onto the motor base, ensuring it is seated correctly.
3. Place the pulp filter into the juice pitcher.
4. Select the appropriate reamer (small for lemons/limes, large for oranges/grapefruits) and place it onto the shaft in the center of the pulp filter.
5. Cover the assembled parts with the protective lid.
6. Plug the power cord into a standard electrical outlet.

5. OPERATING INSTRUCTIONS

Follow these steps to extract fresh citrus juice:

1. Ensure the juicer is properly assembled and plugged in.
2. Cut your citrus fruit (e.g., orange, lemon, grapefruit) in half.
3. Remove the protective lid.
4. Place one half of the fruit, cut-side down, onto the reamer.
5. Apply gentle downward pressure to the fruit. The reamer will begin to rotate, extracting juice. The juicer features a two-way rotation for maximum juice extraction.
6. Continue pressing until all juice is extracted from the fruit half. Avoid excessive pressure, as this can slow down or stop the motor.
7. Lift the fruit off the reamer to stop the rotation.
8. Repeat with remaining fruit halves until the desired amount of juice is collected in the pitcher.
9. Once finished, unplug the appliance.
10. Pour the fresh juice from the pitcher using the integrated spout. The pitcher is refrigerator-friendly for storing leftover juice.



Duo-sized cones

Adapts to different citrus sizes for versatile use



The two-direction twist feature maximizes juice extraction with dual rotation.



Enjoy freshly squeezed juice from various citrus fruits.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance ensure the longevity and hygiene of your juicer.

1. Always unplug the juicer from the power outlet before cleaning.
2. Disassemble all detachable parts: protective lid, reamers, pulp filter, and juice pitcher.
3. Wash these detachable parts immediately after use in warm, soapy water. Rinse thoroughly and dry completely.
4. **Important:** The juice pitcher and other detachable parts are **not dishwasher safe**. Hand wash only.
5. Wipe the motor base with a soft, damp cloth. Do not immerse the motor base in water or any other liquid.
6. Do not use abrasive cleaners or scouring pads on any part of the juicer.
7. Store the clean and dry juicer in a cool, dry place.



Compact & convenient

Space-saving design for effortless storage



The juicer features detachable parts for easy cleaning and maintenance.

7. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
Reamer stops or slows down during juicing.	Too much pressure applied to the fruit; fruit is too hard or large for the reamer.	Reduce downward pressure. Ensure you are using the correct reamer size for the fruit. Cut larger fruits into smaller, manageable pieces if necessary.
Poor juice extraction.	Insufficient pressure; fruit not properly centered; reamer not rotating effectively.	Apply consistent, gentle pressure. Ensure the fruit half is centered on the reamer. Check that the reamer is securely attached.

Problem	Possible Cause	Solution
Excessive pulp in juice.	Pulp filter not properly seated or damaged.	Ensure the pulp filter is correctly placed in the pitcher. If damaged, contact customer support for a replacement.

8. SPECIFICATIONS

- **Brand:** Holstein Housewares
- **Model Name:** JUICER
- **Model Number:** HH-09101036B
- **Capacity:** 27-oz (approximately 800 ml)
- **Color:** Black
- **Material:** Plastic, Stainless Steel
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (AC)
- **Maximum Power:** 30 Watts
- **Product Dimensions:** 6.69"D x 6.69"W x 8.98"H
- **Item Weight:** 2.08 pounds
- **Care Instructions:** Hand Wash Only (detachable parts)

9. WARRANTY AND SUPPORT

Holstein Housewares offers a **1-year limited warranty** on this product from the date of purchase. This warranty covers manufacturing defects under normal household use. Please retain your proof of purchase for warranty claims.

For product support, warranty inquiries, or to purchase replacement parts, please visit the official Holstein Housewares website or contact their customer service department.

You can find more information and products from Holstein Housewares at their official store [Holstein Housewares Store](#)

Welcome to #HolsteinKitchen!

At Holstein, we believe the best memories start in the kitchen. Holstein Housewares was founded with the mission of simplifying life in the kitchen with functional, high quality and accessible small kitchen appliances. Our team designs with you in mind, to make everyday cooking and entertaining easier. We offer a thoughtful portfolio of products to help you create endless recipes from healthy meals to guilty pleasures, fitting many lifestyles.



Discover more from Holstein Housewares.

© 2026 Holstein Housewares. All rights reserved.