



Manuals.plus /

› Hozzwhoo /

› Hozzwhoo 3-in-1 Window Cleaner Squeegee Instruction Manual

Hozzwhoo 5003

Hozzwhoo 3-in-1 Window Cleaner Squeegee Instruction Manual

Model: 5003 | Brand: Hozzwhoo

INTRODUCTION

Thank you for choosing the Hozzwhoo 3-in-1 Window Cleaner Squeegee. This versatile tool is designed to simplify your cleaning tasks, offering a microfiber washer, integrated spray bottle, and a rubber squeegee for efficient and streak-free cleaning of various glass surfaces, including home windows, car windows, and mirrors.

SAFETY INFORMATION

- Always use appropriate cleaning solutions. Avoid harsh chemicals that may damage surfaces or the product.
- Keep out of reach of children and pets.
- Do not use on hot surfaces.
- Ensure all components are securely attached before use.

PACKAGE CONTENTS

- 1x Hozzwhoo 3-in-1 Window Cleaner Squeegee
- 1x Spray bottle (integrated)
- 1x Microfiber cleaning head (random color)




Image: The Hozzwhoo 3-in-1 Window Cleaner Squeegee showing its main components: the spray bottle handle, the microfiber scrubber, and the rubber squeegee blade.

SETUP

1. **Attach Microfiber Head:** The microfiber cleaning head needs to be installed and securely attached to the aluminum alloy clip on the squeegee unit. Ensure it is firmly in place.
2. **Fill Spray Bottle:** Unscrew the spray bottle from the handle. Fill it with your preferred window cleaning liquid. Screw the spray bottle back onto the handle until secure.



Image: Visual guide for assembling the Hozzwhoo 3-in-1 Window Cleaner Squeegee, demonstrating the attachment of the microfiber pad and the filling of the spray bottle.

OPERATING INSTRUCTIONS

The Hozzwhoo 3-in-1 Window Cleaner Squeegee allows for a three-step cleaning process: spraying, cleaning, and drying.

1. **Spray:** Hold the cleaner with the spray nozzle facing the surface. Press the trigger to spray cleaning liquid evenly onto the window or surface. The direction of the spray head can be adjusted for optimal coverage.
2. **Clean:** Use the microfiber cleaning head to scrub the surface. The high-quality microfiber is designed for strong decontamination and durability, effectively removing dirt and grime.
3. **Scrape Dry:** Flip the tool to use the rubber squeegee blade. Scrape the surface from top to bottom in overlapping strokes to remove the cleaning solution and water, leaving a streak-free finish. The natural rubber strip provides excellent watertight performance and a very good wiping effect.



Image: A hand holding the Hozzwhoo 3-in-1 Window Cleaner Squeegee, demonstrating the spray function on a window.



Image: The Hozzwho 3-in-1 Window Cleaner Squeegee in action, scrubbing a car window with its microfiber pad to remove dirt.

Instructions



1. Spray

If you want to use the detergent, Just put the detergent into the bottle, alignment the place you need to clean, by pressing the red button as shown in photo, The liquid can be sprayed out of the bottle, uniform distribution , Easy to operate.

2. Clean

Window cleaner using double-sided design, first, use the scrub wipes to cleaning glass, scrub wipes made of microfiber fabric, strong decontamination, durable, scrub wipes can be removed for cleaning.



3. Scrape dry

After cleaning the glass, scrape the Water stains on the glass, The glass will bright as new. The scrap strip is made from natural rubber material with excellent watertight , resilient, and very good wiper effect



Image: A visual step-by-step guide illustrating the three functions: spray, clean with the microfiber, and scrape dry with the squeegee.

Video Demonstrations

Video: A seller demonstrating the 3-in-1 Window Cleaning Scraper, showing its use for various cleaning tasks.

Video: A seller demonstrating the 3-in-1 Spray Squeegee, highlighting its spray, scrub, and wipe functions on glass surfaces.

MAINTENANCE

- **Cleaning the Microfiber Head:** The microfiber cleaning head is washable. Remove it from the squeegee and wash it with mild detergent. Allow it to air dry completely before reattaching.

- **Emptying the Spray Bottle:** After each use, empty any remaining cleaning solution from the spray bottle to prevent clogging and ensure longevity. Rinse the bottle and spray mechanism with clean water.
- **Storing the Squeegee:** Store the squeegee in a clean, dry place. The tool features a hook at the tail for convenient hanging and storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Squeegee leaves streaks	Dirty or worn rubber blade; improper technique; too much cleaning solution.	Clean the rubber blade; replace if worn; use less solution; ensure even pressure and overlapping strokes.
Spray bottle leaks	Bottle not securely tightened; damaged seal.	Ensure the bottle is tightly screwed onto the handle; check for cracks or damage and replace if necessary.
Spray nozzle clogged	Dried cleaning solution or debris.	Rinse the nozzle with warm water; use a thin needle to clear any blockages.

SPECIFICATIONS

- **Brand:** Hozzwhoo
- **Model:** 5003
- **Material:** PP+TDR Microfiber (Microfiber head), Rubber (Blade), Rubber (Handle)
- **Color:** Green
- **Product Dimensions:** 9.84"W x 9.25"H
- **Item Weight:** 5.5 ounces
- **Liquid Container Volume:** 200ML
- **Batteries Required:** No



Image: A diagram illustrating the dimensions of the Hozzwhoo 3-in-1 Window Cleaner Squeegee, including its width and height.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided with your purchase or visit the official Hozzwhoo website. Keep your purchase receipt for any warranty claims.