

Goeco 30925702

Goeco Round LED Ceiling Light (Model: 30925702)

32W 2958LM IP54 Waterproof 6500K Cool White

1. PRODUCT OVERVIEW

The Goeco Round LED Ceiling Light is a modern, energy-efficient lighting solution designed for various indoor environments. Featuring a slim, round design, it provides bright, cool white illumination suitable for bathrooms, bedrooms, kitchens, living rooms, and balconies. Its IP54 rating ensures dust and water resistance, making it ideal for damp locations.

- **Dimensions:** 25cm diameter, 3cm height
- **Power:** 32W, approximately 2958 Lumens
- **Color Temperature:** 6500K Cool White
- **Waterproof Rating:** IP54 (Dust and splash resistant)
- **Voltage:** 220V
- **Energy Efficiency:** Equivalent to a 200W incandescent lamp
- **Color Rendering Index (CRI):** >80, no strobe effect

2. SAFETY INFORMATION

Please read all safety instructions before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- Always turn off the power at the main circuit breaker before installing or servicing the light fixture.
- Installation should be performed by a qualified electrician or a person with sufficient electrical knowledge.
- Ensure the supply voltage is compatible with the light fixture (220V).
- Do not modify the fixture or use it for purposes other than intended.
- Keep packaging materials out of reach of children.
- Do not look directly into the LED light source when it is illuminated.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Goeco Round LED Ceiling Light Fixture

- Mounting Bracket
- Screws and Wall Plugs
- Instruction Manual (this document)

4. SPECIFICATIONS

Feature	Specification
Model Number	30925702
Dimensions (L x W x H)	25 x 25 x 3 cm
Weight	470 grams
Brand	Goeco
Color	White (Cool White Light)
Material	Aluminum
Style	Modern
Fixture Shape	Ceiling Light (Round)
Room Type	Kitchen, Bathroom, Bedroom, Living Room
Indoor/Outdoor Use	Indoor
Power Source	Corded Electric
Special Features	Waterproof, Easy to Install
Bulb Type	LED (Integrated)
Number of Bulbs	1
Voltage	220 Volts
Wattage	32 Watts
Energy Label	E
Mounting Type	Ceiling Mount, Flush Mount
Assembly Required	No

5. SETUP AND INSTALLATION

Follow these steps carefully to install your Goeco LED Ceiling Light. Ensure power is OFF before starting.

1. **Prepare for Installation:**

Turn off the main power supply at the circuit breaker to avoid electric shock. Ensure the area is dry and clear.

2. **Attach Mounting Bracket:**

Position the mounting bracket on the ceiling where you intend to install the light. Mark the drilling points. Drill holes and insert wall plugs if necessary. Secure the mounting bracket to the ceiling using the provided screws.



Image: Step-by-step diagram illustrating the process of securing the mounting bracket to the ceiling.

3. **Connect Electrical Wires:**

Carefully connect the electrical wires from the ceiling to the corresponding wires on the light fixture. Typically, this involves connecting live to live, neutral to neutral, and ground to ground (if applicable). Use appropriate wire connectors to ensure secure connections.



Image: Detailed illustration of connecting the household electrical wires to the light fixture's wires.

4. **Mount the Light Fixture:**

Align the light fixture with the mounting bracket and secure it in place. Many flush-mount lights twist or clip onto the bracket. Ensure it is firmly attached and flush against the ceiling.

5. **Restore Power:**

Once the light is securely installed and all connections are checked, turn the main power supply back on at the circuit breaker.

6. **OPERATING INSTRUCTIONS**

The Goeco Round LED Ceiling Light operates like a standard light fixture.

- **Turning On/Off:** Use your standard wall light switch to turn the light fixture on or off.
- **No Dimming:** This model provides a fixed 6500K cool white light and does not support dimming functions unless explicitly stated otherwise by your specific model variant.

7. **MAINTENANCE**

Regular maintenance ensures optimal performance and longevity of your LED ceiling light.

- **Cleaning:** Turn off the power before cleaning. Use a soft, dry cloth to wipe the surface of the light fixture. For stubborn dirt, a slightly damp cloth with mild soap can be used, followed by a dry cloth. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, turn off the power and consult a qualified electrician.
- **No Bulb Replacement:** This fixture uses integrated LED technology, meaning the LED chips are built into the unit and are not user-replaceable. The expected lifespan of the LEDs is long, reducing the need for frequent maintenance.

8. **TROUBLESHOOTING**

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power supply Loose wire connection Faulty switch	Check circuit breaker and wall switch. Turn off power, check wire connections. Test switch with another device or replace.

Problem	Possible Cause	Solution
Light flickers	Loose wire connection Incompatible dimmer switch (if applicable) Voltage fluctuations	Turn off power, check wire connections. Ensure no dimmer switch is used, or replace with LED-compatible dimmer. Consult an electrician for voltage issues.
Light is dim	Incorrect voltage Dust accumulation	Ensure correct 220V supply. Clean the light fixture surface.

If the problem persists after trying these solutions, please contact customer support.

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For warranty claims, technical support, or further assistance, please refer to the retailer where the product was purchased or contact Goeco customer service directly through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09TZ3DM2>

More documents and user manuals: <https://manuals.plus/>