

[manuals.plus](#) /› [CrossBeats](#) /› [CrossBeats Slide Wireless Bluetooth Earphones: User Manual](#)**CrossBeats CB-SLIDE**

CrossBeats Slide Wireless Bluetooth Earphones: User Manual

Model: CB-SLIDE

INTRODUCTION

Welcome to the CrossBeats Slide Wireless Bluetooth Earphones user manual. These True Wireless Stereo (TWS) earbuds are designed to provide a high-quality audio experience with advanced features such as EchoBlast™ 13mm Bass Drivers, Clearcomm™ Quad Mic Environmental Noise Cancellation (ENC), 40ms low latency, and IPX5 water resistance. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device.



Image: CrossBeats Slide Wireless Bluetooth Earphones in their open charging case, showcasing the earbuds and the unique slide-to-open design with a lanyard.

WHAT'S IN THE BOX

Please ensure all the following items are present in your product packaging:

- CrossBeats Slide Wireless Bluetooth Earphones (Left and Right earbuds)
- Wireless Charging Case
- USB Charging Cable (Type-C)
- Eartips (S/M/L sizes for snug fit)
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your CrossBeats Slide Earphones:

Earbuds: Left (L) and Right (R) earbuds with integrated touch controls and microphones.

Charging Case: Houses and charges the earbuds. Features a unique slide-to-open design and a lanyard for portability.

LED Indicators: Located on both the earbuds and the charging case to display battery status and pairing mode.

USB-C Charging Port: Located on the charging case for power input.

Microphones: Quad microphones for Clearcomm™ Environmental Noise Cancellation during calls.




Image: Close-up of the CrossBeats Slide charging case, highlighting the LED light indications, premium tag, and the unique slide-to-open design.

SETUP

1. Initial Charging

Before first use, fully charge your CrossBeats Slide Earphones. The charging case contains a Lithium Ion battery and acts as a portable power source for the earbuds.

- Connect the provided USB-C charging cable to the charging port on the case and to a power source.
- The LED indicators on the case will show charging status.
- A full charge provides up to 100 hours of listening time (with case).
- The SnapCharge™ feature allows for quick charging, providing significant playtime from just 10 minutes of charge.

2. Pairing with a Device

The CrossBeats Slide Earphones utilize Bluetooth 5.3 for stable and efficient wireless connectivity.

1. Ensure the earbuds are in the charging case and the case has sufficient charge.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by flashing LED lights.
3. On your device (smartphone, tablet, laptop, etc.), go to Bluetooth settings and enable Bluetooth.
4. Search for available devices and select "CrossBeats Slide" from the list.
5. Once connected, the earbud LEDs will stop flashing, indicating successful pairing.
6. The earbuds feature instant auto-pairing, meaning they will automatically connect to the last paired device when removed from the case.

The CrossBeats Slide is compatible with a wide range of devices including Laptops, Mobile Phones, Tablets, PCs, Smart TVs, and all Bluetooth-enabled devices running iOS or Android.

OPERATING INSTRUCTIONS

Touch Controls

The CrossBeats Slide Earphones feature multi-function touch controls on each earbud for easy management of audio playback, calls, and voice assistants.

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (L/R)	Activate Voice Assistant (Siri/Ok Google)
Long Press (L/R)	Reject Call

Swift Voice Commands



Siri



Ok Google



Multi-function touch controls



Image: CrossBeats Slide Earbuds illustrating the touch control area and icons for Siri and Ok Google voice commands.

Audio Features

- **EchoBlast™ 13mm Bass Driver:** Experience rich and powerful bass with the integrated dynamic drivers.
- **40ms Low Latency:** Enjoy synchronized audio and video, ideal for gaming and media consumption, powered by Bluetooth 5.3.

EchoBlast™

13mm Driver



Image: An illustration of a CrossBeats Slide earbud highlighting the EchoBlast™ 13mm driver for enhanced bass.

**SOUNDS
DIVINE**
Rich bass tune-up



Image: An internal view of a CrossBeats Slide earbud, illustrating the rich bass tune-up for divine sound quality.

Calling Features

- **Clearcomm™ Quad Mic ENC:** The integrated quad microphones with Environmental Noise Cancellation ensure clear voice transmission during calls by reducing background noise.

Handsfree calling with Quad Microphones



Image: A woman wearing a CrossBeats Slide earbud, demonstrating hands-free calling with the quad microphones.

QUAD
MICROPHONE
setup Low latency
built-in

Image: CrossBeats Slide Earbuds with an illustration of sound waves, representing the quad microphone setup and built-in low latency.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals. Ensure charging contacts are free of debris.
- **Water Resistance:** The earbuds are IPX5 rated, meaning they are resistant to splashes and sweat. They are not designed for submersion in water. Dry them thoroughly if they get wet before placing them back in the charging case.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.
- **Eartips:** Use the correct size eartips for a snug fit to ensure optimal sound quality and comfort. Clean eartips periodically.



Image: An infographic showcasing key features of the CrossBeats Slide, including Superlight Construction, Unique Slide Design,

TROUBLESHOOTING

If you encounter issues with your CrossBeats Slide Earphones, please refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure both earbuds are charged.
- Place earbuds back in the case, close it, then open it again to re-enter pairing mode.
- Turn off and on Bluetooth on your device.
- Forget "CrossBeats Slide" from your device's Bluetooth list and attempt to pair again.

- **No sound from one earbud:**

- Ensure both earbuds are charged.
- Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, place them in the case, close, and reopen).
- Check device's audio balance settings.

- **Charging issues:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different USB-C cable and power adapter.
- Clean the charging contacts on both the earbuds and inside the case.

- **Poor call quality:**

- Ensure microphones are not obstructed.
- Check your environment for excessive background noise.
- Ensure a stable Bluetooth connection.

SPECIFICATIONS

Model Name	CB-SLIDE
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Type	EchoBlast™ 13mm Dynamic Driver
Noise Control	Sound Isolation, Environmental Noise Cancelling (ENC)
Microphone	Quad Microphones, Unidirectional
Battery Life	Up to 100 Hours (with charging case)
Fast Charging	SnapCharge™ (0-100 in 10 minutes)
Water Resistance	IPX5 Rated (Water Resistant, Sweatproof)

Low Latency	40ms
Control Method	Multi-Function Touch, Voice Control (Siri, Ok Google)
Maximum Operating Distance	33 Feet
Form Factor	In-ear
Material	Plastic
Item Weight	30 Grams
Product Dimensions	5 x 2 x 2 cm
UPC	850025215534

WARRANTY AND SUPPORT

Your CrossBeats Slide Wireless Bluetooth Earphones come with a **12-month manufacturer warranty** covering manufacturing defects. CrossBeats maintains over 300 service centers across India for your convenience. For warranty claims, technical support, or further assistance, please contact CrossBeats customer service. You may also refer to the official CrossBeats website for updated support information.


Manufacturer: Crossbeats, sellbrite digital-Ground floor, brigade tower, brigade road, bangalore-560025

Importer: Crossbeats


© 2025 CrossBeats. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - CB-SLIDE

	<u>Crossbeats Slice Quick Start Guide - User Manual</u> Get started with your Crossbeats Slice wireless earbuds. This quick start guide provides essential information on overview, power on/off, pairing, mono mode, charging, reset, and controls for the CB-SLIDE model.
	<u>Crossbeats Neo Buds User Manual: Features, Controls, and Charging</u> Comprehensive user manual for Crossbeats Neo Buds wireless earbuds. Learn about pairing, controls, charging, LED indicators, and troubleshooting. Get the most out of your audio experience.


	<p>CrossBeats Neopods 300 User Manual User manual for CrossBeats Neopods 300 wireless earbuds, covering overview, power, charging, LED indicators, pairing, controls, and reset procedures.</p>
	<p>Crossbeats Curv True Wireless Earbuds User Manual User manual for the Crossbeats Curv true wireless earbuds, detailing setup, pairing, controls, charging, and LED indicators.</p>
	<p>CrossBeats ATOM User Manual: Features, Pairing, and Controls Comprehensive user manual for the CrossBeats ATOM true wireless earbuds. Learn about features, power management, Bluetooth pairing, LED indicators, charging, reset procedures, and touch controls.</p>
	<p>Crossbeats Ignite Nexus Smartwatch User Manual Comprehensive user manual for the Crossbeats Ignite Nexus smartwatch, covering setup, features, charging, connectivity, and troubleshooting. Learn how to use your smartwatch for fitness tracking, notifications, and more.</p>

Documents - CrossBeats – CB-SLIDE



[\[pdf\] User Manual](#)

CROSSBEATS SLIDE 01 MANUAL Manual Hub drive google file d
17zWzBYk1bYy83pcr8OBOuu8GIOdGjolc preview |||
<https://manual-hub.com/> <https://manual-hub.com/> <https://manual-hub.com/>
<https://manual-hub.com/> **CB-SLIDE CB-SLIDE** <https://manual-hub.com/>
<https://manual-hub.com/> <https://manual-hub.com/> <https://manual-hub.com/>
<https://manual-hub.com/> <https://manual-hub.com/> <https://manual-hub.co...>
lang: **score:26** filesize: 1.11 M page_count: 12 document date: 2023-09-14



[Crossbeats Slice Quick Start Guide - User Manual](#)

Get started with your Crossbeats Slice wireless earbuds. This quick start guide provides essential information on overview, power on/off, pairing, mono mode, charging, reset, and controls for the CB-SLIDE model.

lang: **score:26** filesize: 374.1 K page_count: 12 document date: 2022-07-04