

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Displays2go](#) /
- › [Displays2go Motorized Rolling TV Stand \(DGMLTSBK\) Instruction Manual](#)

## Displays2go DGMLTSBK

# Displays2go Motorized Rolling TV Stand (DGMLTSBK)

Instruction Manual

## INTRODUCTION

Thank you for choosing the Displays2go Motorized Rolling TV Stand. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your new TV stand. Please read all instructions carefully before assembly and use.

## IMPORTANT SAFETY INFORMATION

- **Read all instructions:** Ensure you understand all assembly and operation instructions before use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 265 lbs (120 kg).
- **Screen Size:** This stand is designed for screens between 43" and 100".
- **Power Source:** Connect the stand to a grounded power outlet (110V-250V).
- **Cable Management:** Ensure all cables are properly routed and secured to prevent tripping hazards or damage during movement.
- **Caster Locks:** Always engage the caster locks when the stand is in a stationary position to prevent accidental movement.
- **Children and Pets:** Keep children and pets away from the stand during operation to prevent injury.
- **Maintenance:** Do not attempt to service the motorized components yourself. Refer to qualified service personnel.

## SETUP AND ASSEMBLY

Carefully unpack all components and verify against the parts list (not provided in this document, refer to packaging). Assembly typically involves attaching the base, column, and TV mounting brackets.

### 1. Base Assembly

Attach the four heavy-duty casters to the base frame. Ensure they are securely fastened. Two casters are lockable; position them for easy access.

## **2. Column Installation**

Mount the motorized column onto the assembled base. Follow the specific instructions provided with your hardware kit to ensure proper alignment and secure attachment.

## **3. TV Mounting Bracket Attachment**

Attach the VESA-compatible mounting brackets to the back of your television. Refer to your TV's manual for appropriate screw sizes and mounting points. The stand supports VESA sizes up to 800x600.



Image: The TV stand's mounting brackets are visible, ready for television attachment. This image shows the stand without a TV, highlighting the VESA mounting plate and the motorized column.

#### 4. Mounting the TV

Carefully lift your television and hook the attached brackets onto the stand's mounting plate. Secure the TV using the provided safety screws or clips. Ensure the TV is level and stable.



Image: The motorized TV stand with a large television securely mounted in a vertical viewing position.

## 5. Power Connection

Connect the power cord to the stand and then to a suitable electrical outlet. The power cord length is 64 inches.

## OPERATING INSTRUCTIONS

---

The Displays2go Motorized Rolling TV Stand features remote-controlled height adjustment and tilt functionality.

### Remote Control Functions

- **Up/Down Buttons:** Use these buttons to raise or lower the television screen. The height can be adjusted from 36" to 62".
- **Tilt Buttons:** Use these buttons to adjust the viewing angle of the screen, from a vertical position (0°) down to a horizontal table position (90°).

### Adjusting Height

Press the "Up" or "Down" buttons on the remote control to move the screen to your desired height. The motorized mechanism will smoothly adjust the display.



Image: Illustration demonstrating the adjustable height feature of the TV stand, showing the screen at different vertical positions.

### Adjusting Tilt

Press the "Tilt Up" or "Tilt Down" buttons on the remote control to change the screen's angle. This allows for conversion from a vertical display to an interactive horizontal table.



Image: Illustration demonstrating the adjustable tilt feature, showing the screen transitioning from vertical to a horizontal table-like orientation.



Image: The TV stand with a television fully tilted to a horizontal position, suitable for interactive table use.

## Mobility

To move the stand, unlock the two lockable casters. Carefully push the stand to its new location. Once positioned, engage the caster locks to stabilize the stand.

## Product Video

Your browser does not support the video tag.

Video: This video demonstrates the motorized lift and tilt capabilities of the Displays2go Motorized Rolling TV Stand, showcasing its versatility in adjusting screen height and angle.

## MAINTENANCE

---

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Inspections:** Periodically check all fasteners and connections to ensure they are tight and secure.
- **Motorized Components:** The motorized system is designed for long-term use and generally requires no user maintenance. Do not lubricate or disassemble.
- **Casters:** Keep casters free of debris to ensure smooth rolling.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Stand does not move (lift/tilt)	<ul style="list-style-type: none"><li>◦ Power cord not connected</li><li>◦ No power to outlet</li><li>◦ Remote control batteries low or dead</li><li>◦ Obstruction preventing movement</li></ul>	<ul style="list-style-type: none"><li>◦ Ensure power cord is securely plugged into stand and outlet.</li><li>◦ Check circuit breaker or try another outlet.</li><li>◦ Replace remote control batteries.</li><li>◦ Remove any objects obstructing the stand's movement path.</li></ul>
Stand moves unevenly or makes unusual noises	<ul style="list-style-type: none"><li>◦ Overload (exceeding weight capacity)</li><li>◦ Loose components</li></ul>	<ul style="list-style-type: none"><li>◦ Ensure TV weight is within the specified limit (265 lbs).</li><li>◦ Check all assembly fasteners and tighten if necessary.</li><li>◦ If problem persists, contact customer support.</li></ul>
Casters do not roll smoothly	<ul style="list-style-type: none"><li>◦ Debris in casters</li><li>◦ Caster locks engaged</li></ul>	<ul style="list-style-type: none"><li>◦ Clean any hair or debris from around the caster wheels.</li><li>◦ Ensure caster locks are disengaged before attempting to move the stand.</li></ul>

## SPECIFICATIONS

---

Feature	Detail
Brand	Displays2go
Model	DGMLTSBK
Overall Width x Depth	37.5" x 30.0"
Height Range (Min. x Max)	36.0" x 62.0"
Weight	175.0 lbs (Product), 219 lbs (Shipping)
Material	Steel, Alloy Steel
Finish	Powder-Coated
Placement Type	Floor Standing
Orientation	Landscape
Features	Motorized, Wheels, Tilting, Adjustable Height, Remote Controlled
Color	Black
Power Cord Length	64.0"
Wattage	260W
Mounting Bracket Width	15.8" (with extenders: 35.5")
VESA Size	Up to 800x600
Min Monitor Size	43"
Max Monitor Size	100"
Bracket Type	Tilting
Max Monitor Weight	265.0 lbs
Viewing Angle	0° - 90°
Input Voltage	110V-250V
Power Output	24V

## WARRANTY AND SUPPORT

---

### Warranty Information

This product is typically covered by a manufacturer's warranty. Please refer to your purchase documentation or contact Displays2go directly for specific warranty terms and conditions. A 30-day return policy is generally offered for this product.

### Customer Support

For technical assistance, missing parts, or any questions regarding your Displays2go Motorized Rolling TV Stand, please contact Displays2go customer support. Contact information can typically be found on the Displays2go website or your purchase invoice.

