LG 29WQ600-W

LG 29WQ600-W UltraWide FHD IPS Monitor User Manual

Model: 29WQ600-W

Safety Information | Product Overview | What's in the Box | Assembly & Setup | Connectivity
Basic Operation | Advanced Features | Care & Maintenance | Troubleshooting | Specifications
Warranty & Support

1. Important Safety Instructions

Please read these safety instructions carefully before using your monitor. Keep this manual for future reference.

- Do not place the monitor on an unstable cart, stand, tripod, bracket, or table.
- Do not block ventilation openings.
- Do not expose the monitor to rain or moisture.
- Use only the power cord and adapter provided by the manufacturer.
- Disconnect the power plug during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

2. Product Overview

The LG 29WQ600-W is a 29-inch UltraWide Full HD (2560x1080) IPS monitor designed for enhanced productivity and immersive entertainment. It features HDR10 compatibility for vivid visuals, AMD FreeSync for smooth gameplay, and USB Type-C connectivity for simplified setup.



Figure 2.1: Front view of the LG 29WQ600-W UltraWide Monitor displaying a multi-window workspace.

Your browser does not support the video tag.

Video 2.1: An official product overview video showcasing the LG 29WQ600-W UltraWide Monitor's features and design.

3. What's in the Box

Verify that all components are present before proceeding with assembly:

- LG 29WQ600-W Monitor
- Monitor Stand (Base and Neck)
- Power Cord
- HDMI Cable

4. Assembly and Setup

Follow these steps to assemble your monitor stand and attach it to the display panel.

1. Carefully remove the monitor and stand components from the packaging.
2. Attach the stand neck to the base. Secure it firmly.
3. Align the assembled stand with the mounting points on the back of the monitor panel.
4. Gently push the stand into place until it clicks securely.
5. Place the assembled monitor on a stable, flat surface.



Figure 4.1: Visual guide for attaching the monitor stand to the display panel.

5. Connectivity

The LG 29WQ600-W monitor offers various ports for connecting to your computer and other devices.

- **HDMI Ports:** Connect your computer or other HDMI-enabled devices using the provided HDMI cable.
- **DisplayPort:** For high-resolution and high-refresh-rate connections, use a DisplayPort cable.
- **USB Type-C:** This port supports video, data transfer, and power delivery, allowing for a single-cable solution with compatible laptops.
- **Audio Out:** Connect external speakers or headphones.



Figure 5.1: Rear view of the monitor highlighting the available connectivity ports.



Figure 5.2: The USB Type-C port provides a convenient single-cable connection for compatible devices.

6. Basic Operation

The monitor's functions are controlled by a joystick button located at the bottom center of the display.

- **Power On/Off:** Press the joystick button once to turn the monitor on. Press and hold to turn it off.
- **Menu Navigation:** Move the joystick left, right, up, or down to navigate through the On-Screen Display (OSD) menu.
- **Select:** Press the joystick button to confirm a selection in the OSD menu.
- **Input Selection:** Access the input list to switch between HDMI, DisplayPort, and USB Type-C sources.

7. Advanced Features

7.1. HDR10 Compatibility

HDR10 (High Dynamic Range) provides a wider range of colors and contrast, resulting in more vibrant and lifelike images. Ensure your content and graphics card support HDR10 for optimal viewing.

7.2. AMD FreeSync

AMD FreeSync technology synchronizes the monitor's refresh rate with your graphics card's frame rate, eliminating screen tearing and stuttering for a smoother gaming experience. This feature is active when connected to a compatible AMD graphics card.



Figure 7.1: AMD FreeSync ensures fluid motion and eliminates screen tearing during gaming.

7.3. Dynamic Action Sync (DAS)

DAS minimizes input lag, allowing you to react faster in fast-paced games. This feature processes input signals more quickly, providing a competitive edge.




Figure 7.2: Dynamic Action Sync reduces input lag for quicker responses in games.

7.4. Black Stabilizer

Black Stabilizer brightens dark areas in games, making it easier to spot enemies hiding in shadows. This enhances visibility in dark scenes without overexposing bright areas.




Figure 7.3: Black Stabilizer enhances visibility in dark gaming environments.

7.5. Crosshair Feature

The Crosshair feature places a fixed crosshair in the center of the screen, improving aiming accuracy in first-person shooter games.




Figure 7.4: The Crosshair feature aids in aiming precision during gameplay.

7.6. Reader Mode

Reader Mode adjusts color temperature and luminance to create optimal conditions for comfortable reading, reducing eye strain during prolonged use.

7.7. On-Screen Control

On-Screen Control software allows you to easily adjust monitor settings, including picture, audio, and Screen Split options, with a few clicks of your mouse. This enhances multitasking efficiency.




Figure 7.5: On-Screen Control software provides intuitive management of display settings and screen layout.

8. Care and Maintenance

- **Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a monitor-specific cleaning solution applied to the cloth, not directly to the screen.
- **Storage:** When storing the monitor for an extended period, place it in its original packaging or a protective cover to prevent dust and damage.
- **Avoid Direct Sunlight:** Do not expose the monitor to direct sunlight or heat sources, as this can damage the screen and internal components.

9. Troubleshooting

If you encounter issues with your monitor, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cord not connected or power outlet faulty.	Ensure power cord is securely connected. Test power outlet with another device.
No image on screen	Incorrect input source selected or video cable loose.	Select correct input source via joystick. Check video cable connections.
Screen tearing/stuttering	AMD FreeSync not enabled or incompatible graphics card.	Ensure FreeSync is enabled in monitor/graphics card settings. Verify graphics card compatibility.
Flickering screen	Refresh rate mismatch or faulty cable.	Adjust refresh rate in display settings. Try a different video cable.

10. Specifications

Feature	Detail
Model Number	29WQ600-W
Screen Size	29 Inches
Screen Resolution	2560x1080 (FHD Ultra Wide)
Aspect Ratio	21:9
Panel Type	IPS
Refresh Rate	100 Hz
Response Time	1ms Motion Blur Reduction (MBR)
HDR Compatibility	HDR10
Adaptive Sync	AMD FreeSync
Connectivity	HDMI, DisplayPort, USB Type-C, Audio Out
Built-in Speakers	7W x 2 with Maxx Audio
Mounting	100 x 100 mm VESA compatible
Dimensions (LxWxH)	8.8 x 27.1 x 16 inches
Weight	9.9 pounds

11. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official LG Electronics website. Software downloads for features like On-Screen Control can be found at LGUSA.com/OnScreenControlSupport.

© 2023 LG Electronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question