

YHO HX45K8

YHO Mini Portable Charger USB-C Power Bank

MODEL: HX45K8

User Manual

1. INTRODUCTION

Thank you for choosing the YHO Mini Portable Charger. This ultra-compact 5200mAh power bank is designed for convenient on-the-go charging of your USB-C compatible devices. Featuring a built-in plug and an LCD display, it provides a reliable backup power supply for daily use. Please read this manual carefully to ensure proper operation and longevity of your device.

2. PRODUCT OVERVIEW

The YHO Mini Portable Charger is designed for ultimate portability and ease of use. Its compact size, similar to a lipstick, makes it easy to carry in your pocket or purse without the need for extra cables.



Figure 2.1: YHO Mini Portable Charger in use.

Key Features:

- **Portable Plug-in Design:** Directly plugs into your USB-C device, eliminating the need for additional cables.
- **Ultra-Compact:** Small and lightweight, ideal for travel and daily commutes.
- **LCD Digital Display:** Clearly shows the remaining battery percentage of the power bank.
- **Dual Input:** Can be recharged using either a USB-C cable or a Lightning cable.
- **5200mAh Capacity:** Provides at least one full charge for most Android phone models.

Components:

5200mAh Capacity

Other input and Type-C input/output



Figure 2.2: Product components and ports.

- USB-C Output Connector
- LCD Display Screen
- Power On/Off Button
- USB-C Input/Output Port
- Lightning Input Port

3. SETUP

What's in the Box:

- 1 x YHO USB-C Power Bank Portable Charger
- 1 x USB-C Charging Cable
- 1 x User Manual

Initial Charging of the Power Bank:

Before first use, fully charge your YHO Mini Portable Charger. This ensures optimal performance and battery longevity.

1. Connect the provided USB-C charging cable to the USB-C Input/Output Port on the power bank.
2. Connect the other end of the USB-C cable to a compatible USB wall adapter (not included) or a computer's USB port.
3. The LCD display will show the charging progress, indicating the battery percentage. Charge until the display shows '100%'.

Note: You can also use a Lightning cable to charge the power bank via its Lightning Input Port.

4. OPERATING INSTRUCTIONS

Charging Your Device:

The YHO Mini Portable Charger is designed for direct plug-in charging, making it incredibly convenient.

1. Ensure the power bank is sufficiently charged (check the LCD display).
2. Align the USB-C output connector of the power bank with the USB-C charging port of your smartphone or compatible device.
3. Gently plug the power bank directly into your device. The LCD display on the power bank will illuminate and show its remaining charge, while your device will indicate that it is charging.
4. To stop charging, simply unplug the power bank from your device.

Add More Than 100% Battery Life For Your Phone




Figure 4.1: Portable charging on the go.

Pass-Through Charging:

The power bank supports pass-through charging, allowing you to charge both the power bank and your device simultaneously.

1. Plug the power bank into your device's USB-C port.
2. Connect the USB-C charging cable to the power bank's USB-C Input/Output Port and then to a power source.
3. Both the power bank and your device will begin charging.

Pass-Through Technology

Recharge power bank while charging phone



Figure 4.2: Pass-through charging setup.

5. COMPATIBILITY

Compatible Devices:

- iPhone 16/16 Plus/16 Pro/16 Pro Max
- iPhone 15/15 Plus/15 Pro/15 Pro Max
- Samsung S22/S23 series
- Samsung S20 FE, Galaxy A52, Note 20 Ultra, S10 Plus, S10, S10e, Note 9, S9 Plus, S9, Note 8
- Samsung Galaxy Fold, Flip 3 and Fold 3 Series
- LG, Moto, Google Pixel, and other Android USB-C Phones

Important Compatibility Notes:

- **Phone Case Thickness:** This portable charger is compatible with phone cases less than 4MM thick. If your phone case is thicker than 4MM, you may need to remove it for the USB-C port to properly connect to the charging slot.
- **Incompatible Devices:** This USB-C portable charger is NOT compatible with iPhone 14/13/12/11/XR/XS/XS MAX /8/7/6/5/SE series and earlier iPhone models.

6. MAINTENANCE

To ensure the longevity and optimal performance of your YHO Mini Portable Charger, please follow these maintenance guidelines:

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or abrasive materials.
- **Avoid Drops and Impacts:** Protect the device from drops, impacts, and excessive vibration, as these can damage internal components.
- **Water Exposure:** Keep the power bank away from water, moisture, and high humidity. It is not waterproof.
- **Regular Use:** For best battery health, use and recharge the power bank regularly, even if not frequently needed.

7. TROUBLESHOOTING

If you encounter any issues with your YHO Mini Portable Charger, please refer to the following common troubleshooting steps:

Power Bank Not Charging:

- Ensure the charging cable is securely connected to both the power bank's input port and the power adapter/source.
- Try using a different USB-C or Lightning charging cable.
- Verify that the wall adapter or USB port you are using is functional.

Device Not Charging from Power Bank:

- Ensure the power bank is sufficiently charged (check the LCD display).
- Make sure the power bank's USB-C output connector is fully and correctly inserted into your device's charging port.
- Check if your phone case thickness is less than 4MM. If not, remove the case and try again.
- Confirm your device is USB-C compatible and not an incompatible iPhone model (see Compatibility section).
- Press the power button on the side of the power bank to activate charging if it doesn't start automatically.

LCD Display Not Working:

- Press the power button to wake up the display.
- If the display remains off, the power bank might be completely depleted. Try charging the power bank.

If the issue persists after trying these steps, please contact customer support for further assistance.

8. SPECIFICATIONS

Feature	Specification
Model Number	HX45K8

Battery Capacity	5200mAh (19.24Wh)
Product Dimensions	3 x 1.5 x 1.02 inches
Item Weight	3.53 ounces
USB-C Input/Output	5V/2A, 5V/3A
Lightning Input	5V/2A
Special Features	LCD Digital Display, Mini Size, Plug-in Design, Case-Friendly (thickness < 4MM)

9. WARRANTY AND SUPPORT

Warranty Policy:

Your YHO Mini Portable Charger comes with a **24-month warranty policy** from the date of purchase. This warranty covers manufacturing defects and ensures your satisfaction with the product. Please retain your proof of purchase for warranty claims.

Customer Service:

We are committed to providing excellent customer service. If you have any questions, concerns, or require assistance with your product, our friendly customer service team is available **24 hours a day** to help you. For support, please contact us through the platform where you purchased the product or refer to the contact information provided on the product packaging.

© 2025 YHO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question