

BELLA 17638

BELLA 2 Slice Dot Toaster Instruction Manual

Model: 17638

INTRODUCTION

The BELLA 2 Slice Dot Toaster in Stainless Steel and Black is designed for efficient and versatile toasting. It features wide slots to accommodate various bread types, including thick bagels and Texas-style toast. This manual provides essential information for safe operation, maintenance, and optimal use of your toaster.

Key features include auto-centering guides for even toasting, a cancel button to stop toasting at any time, anti-jam and auto shut-off for added safety, a removable crumb tray for easy cleanup, and convenient cord wrap storage.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the toaster.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.

PARTS AND FEATURES

Familiarize yourself with the components of your BELLA 2 Slice Dot Toaster:

- **Toasting Slots:** Two wide slots for various bread types.
- **Toasting Lever:** Lowers and raises bread into the slots.
- **Browning Control Dial:** Adjusts toast shade from light to dark.
- **Function Buttons:** Includes Reheat, Toast, Bagel, Defrost, Waffle, Gluten-Free, and Cancel.
- **Removable Crumb Tray:** Collects crumbs for easy cleaning.
- **Cord Wrap Storage:** Located at the bottom for tidy storage.

Perfect Toast Every Time

**Browning control for precise results
the way you like it**



Overall view of the BELLA 2 Slice Dot Toaster, highlighting its sleek design and dual toasting slots.



Advanced Control Panel

**Reheat, toast, bagel, defrost, waffle,
gluten-free, and cancel function**

Detailed view of the advanced control panel, featuring buttons for Reheat, Toast, Bagel, Defrost, Waffle, Gluten-Free, and Cancel, along with the browning control dial.

Wide Slots

For a variety of breads and bagels



The toaster features extra-wide slots, ensuring compatibility with a diverse range of breads, bagels, and muffins.

INITIAL SETUP

Before first use, please follow these steps:

1. Unpack the toaster and remove all packaging materials, including any protective films or cardboard inserts from the toasting slots.
2. Place the toaster on a stable, heat-resistant surface away from flammable materials.
3. Plug the power cord into a standard electrical outlet.
4. For the first use, operate the toaster without bread on the highest browning setting to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal and will dissipate. Ensure adequate ventilation.

OPERATING INSTRUCTIONS

Basic Toasting

1. Insert slices of bread, bagels, or waffles into the toasting slots. The auto-centering guides will hold them in place.
2. Adjust the browning control dial to your desired shade (1 for lightest, 7 for darkest).
3. Press the toasting lever down until it locks into place. The toaster will begin toasting.
4. Once the toasting cycle is complete, the toast will automatically pop up.
5. To stop the toasting cycle at any time, press the 'Cancel' button.

Function Buttons

Your toaster is equipped with several specialized functions:

Function	Description
Reheat	Warms previously toasted items without further browning.
Toast	Standard toasting for bread slices.
Bagel	Toasts the cut side of bagels while gently warming the outer side.
Defrost	Thaws and toasts frozen items.
Waffle	Optimized setting for toasting waffles.
Gluten-Free	Adjusts toasting time and temperature for gluten-free bread.
Cancel	Stops the current toasting cycle immediately.

Your browser does not support the video tag.

Official product video demonstrating the BELLA 2 Slice Dotted Toaster in Stainless Steel and Black, showcasing its features and operation.

Your browser does not support the video tag.

Official product video highlighting the BELLA Dot Collection Toaster, illustrating its design and various functions.

CARE AND CLEANING

Proper care and cleaning will extend the life of your toaster.

Crumb Tray

1. Always unplug the toaster and allow it to cool completely before cleaning.
2. Pull out the removable crumb tray located at the bottom of the toaster.
3. Discard accumulated crumbs.
4. Wipe the tray with a damp cloth and dry thoroughly before reinserting.
5. Never operate the toaster without the crumb tray in place.

Toast Your Way



BELLA 2 SLICE TOASTER

The removable crumb tray slides out from the bottom for easy disposal of crumbs and cleaning.

Exterior Cleaning

- Wipe the exterior of the toaster with a damp cloth and dry thoroughly.
- Do not use abrasive cleaners or scouring pads, as they may scratch the surface.

TROUBLESHOOTING

If you encounter issues with your toaster, refer to the following common problems and solutions:

- **Toaster does not turn on:** Ensure the power cord is securely plugged into a working electrical outlet. Check your household fuse/circuit breaker.
- **Toast is too light or too dark:** Adjust the browning control dial to a higher or lower setting.
- **Bread is stuck:** Unplug the toaster and carefully remove the bread using non-metallic utensils. Do not force the lever.
- **Uneven toasting:** Ensure bread slices are centered in the slots. The auto-centering guides should help, but very thin or irregular slices may toast unevenly.

PRODUCT SPECIFICATIONS

Specification	Detail
Brand	BELLA
Model Number	17638
Color	Stainless Steel and Black
Material	Stainless Steel
Product Dimensions	18"D x 28"W x 20"H
Wattage	900 watts
Voltage	240 Volts
Number of Slices	2
Number of Settings	3 (Light/Medium/Dark browning control)
Special Features	Anti-Slip Base, Illuminated indicator lights, Wide slots, Auto centering guides, Cancel button, Anti-jam and auto shut off, Removable crumb tray, Cord wrap storage
Item Weight	2.64 pounds
UPC	829486176388

WARRANTY AND CUSTOMER SUPPORT

Your BELLA 2 Slice Dot Toaster comes with a**2-Year Limited Warranty**. Please retain your proof of purchase for warranty claims.

The Original Bella Toaster!

“Awesome sauce. Works great, has great features & selections of toast. Bagels & gluten free are fantastic. Only have it on a third of the darkness & toast is perfect! Love, Love, Love!!!! ” -Diane

 @bellalifestyle

 @officialbellalifestyle

PIZZA UNCRUSTABLES

using the bella 2qt air fryer



MAKING CAKE POPS WITH THE BELLA CAKE POP MAKER



DOGGY DONUTS

using the Bella donut maker



Elmer
★★★★★
Good product, great appearance and reliable function.

Rose
★★★★★
Perfect for grilling all sandwiches. I can make up to 4 grilled cheese sandwiches for my grandson.



The BELLA 2 Slice Dot Toaster is backed by a 2-Year Limited Warranty.

For customer support, product registration, or to inquire about replacement parts, please visit the official BELLA website or contact their customer service department. Contact details can typically be found in the packaging or on the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question