

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CIRYCASE](#) /

› [CIRYCASE Flexible Mini Tripod User Manual](#)

CIRYCASE Tripod 30Q

CIRYCASE Flexible Mini Tripod User Manual

Model: Tripod 30Q

1. PRODUCT OVERVIEW

The CIRYCASE Flexible Mini Tripod is a versatile accessory designed for smartphones, cameras, and GoPro devices. It features flexible legs, a 360° rotatable ball head, and includes a wireless Bluetooth remote control for convenient photo and video capture. Its compact and lightweight design makes it suitable for various shooting scenarios, from stable desktop use to wrapping around objects for unique angles.



Image 1.1: The CIRYCASE Flexible Mini Tripod with a smartphone and Bluetooth remote.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 × Smartphone Tripod
- 1 × Bluetooth Remote Control
- 1 × Phone Clip
- 1 × User Manual

3. SETUP GUIDE

3.1 Attaching Your Device

1. **For Smartphones:** Screw the phone clip onto the 1/4" screw thread on the tripod's ball head. Ensure it is securely tightened. Insert your smartphone into the clip, ensuring it is held firmly.

2. **For Cameras/GoPro:** Directly screw your camera or GoPro onto the 1/4" screw thread on the tripod's ball head. Ensure it is securely tightened.

3.2 Adjusting the Tripod


The flexible legs allow for various configurations:

- **Standard Tripod:** Extend the legs to form a stable base on flat surfaces.
- **Wrap-Around:** Bend the flexible legs to wrap around objects such as poles, branches, or fences for unique mounting options.
- **Handheld/Selfie Stick:** Keep the legs together to use the tripod as a comfortable handle for handheld shooting or as a short selfie stick.

JAMBES DE TRÉPIED SOLIDES ET FLEXIBLES



Structure
Triangulaire



Souple



Durable



Particules
Anti-gorgée

Image 3.1: The flexible legs allow for versatile mounting options.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Remote Control Pairing

Follow these steps to pair the Bluetooth remote control with your smartphone:

1. Locate the ON-OFF button on the Bluetooth remote control and slide it to the "ON" position. A blue indicator light will start flashing. If the blue light flashes slowly, the remote is in pairing mode.
2. On your smartphone, open the Bluetooth settings.
3. Search for available devices and select "AB Shutter3" from the list.
4. Once connected, the indicator light on the remote will turn off, indicating successful pairing.

The remote allows you to take photos or record videos from up to 10 meters (33 feet) away, reducing camera shake.

TÉLÉCOMMANDE BLUETOOTH SANS FIL

Compatible avec le système IOS et Android



Image 4.1: Bluetooth remote control pairing steps.

4.2 Adjusting Shooting Angles

The tripod features a 360° rotatable metal ball head. Loosen the locking knob to adjust your device to any desired angle, including horizontal and vertical orientations. Tighten the knob to secure the position firmly.



Image 4.2: The tripod's adjustable head allows for 90-degree and 360-degree rotation.

5. COMPATIBILITY

The CIRYCASE Flexible Mini Tripod offers broad compatibility with various devices:

- **Smartphones:** Compatible with mobile phones with a width of 2.16" - 3.38" (5.49 - 8.59 cm). This includes models such as iPhone 14 Pro Max/14 Pro/14 Plus/13 Pro Max/13/12/11/XS Max/XR/XS/X/SE/8 Plus/7, Samsung Galaxy S22 Ultra/S21+/S22, Huawei, Xiaomi, LG, HTC, SONY, and more.
- **Cameras:** Features a built-in 1/4" screw thread, making it compatible with DSLR cameras, sports cameras (like GoPro), and digital cameras.

LARGE COMPATIBILITÉ

Le clip universel et le support à vis standard de 1/4 "s'adaptent à la plupart des téléphones/appareils photo



Compatible avec iPhone 14 Pro Max/13 Pro Max/12 Pro Max/11/XS/XR, etc.

Compatible avec les téléphones Android tels que Samsung S22 Ultra/S21+/S20/Z Flip3/Note 20 Ultra, etc.

Compatible avec DSLR, caméra de sport, appareil photo numérique, etc.



Image 5.1: Universal compatibility with smartphones and cameras.

6. MAINTENANCE

To ensure the longevity and optimal performance of your CIRYCASE Flexible Mini Tripod, follow these maintenance guidelines:

- **Cleaning:** Wipe the tripod with a soft, dry cloth to remove dust and dirt. For stubborn marks, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** While the legs are flexible, avoid excessive force or bending them beyond their natural range to prevent damage to the internal structure.
- **Water Exposure:** The tripod is not waterproof. Avoid exposing it to water or high humidity.

7. TROUBLESHOOTING

If you encounter any issues with your CIRYCASE Flexible Mini Tripod, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bluetooth remote not pairing.	<ul style="list-style-type: none"> • Remote is off. • Battery is low. • Bluetooth on phone is off. • Incorrect device selected. 	<ul style="list-style-type: none"> • Ensure the remote is switched "ON". • Replace the remote's battery if necessary. • Enable Bluetooth on your smartphone. • Ensure you select "AB Shutter3" from the Bluetooth device list.
Tripod is unstable.	<ul style="list-style-type: none"> • Legs are not properly positioned. • Device is too heavy or not centered. • Ball head not tightened. 	<ul style="list-style-type: none"> • Adjust the legs to create a wider, more stable base. • Ensure your device is within the weight limit and properly centered on the mount. • Tighten the ball head locking knob after adjusting the angle.
Phone clip not holding device securely.	<ul style="list-style-type: none"> • Phone width exceeds clip's range. • Clip not screwed on tightly. 	<ul style="list-style-type: none"> • Verify your phone's width is within 2.16" - 3.38" (5.49 - 8.59 cm). • Ensure the phone clip is securely screwed onto the tripod's 1/4" thread.

8. SPECIFICATIONS

Feature	Detail
Model	Tripod 30Q
Brand	CIRYCASE
Color	Black
Material	High-quality aluminum alloy, high-density rubber
Item Weight	361 Grams

Feature	Detail
Product Dimensions (L x W x H)	20 x 10.2 x 4.6 cm
Minimum Height	15 Centimeters
Maximum Height	152 Centimeters (when used as selfie stick/extended)
Tripod Head Type	Ball Head (360° Rotatable)
Bluetooth Remote Range	Up to 10 meters (33 feet)
Phone Clip Width Range	2.16" - 3.38" (5.49 - 8.59 cm)
Battery Composition (Remote)	Lithium-ion (1 included)
Water Resistance	Not waterproof

9. WARRANTY AND SUPPORT

CIRYCASE products are designed for durability and performance. For any warranty claims or technical support, please contact CIRYCASE customer service through the retailer where the product was purchased or refer to the contact information provided on the product packaging or official CIRYCASE website.

Please retain your proof of purchase for warranty purposes.



© 2024 CIRYCASE. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents - Tripod 30Q

	<p>CIRYCASE 360° Rotatable Bike Phone Mount User Manual</p> <p>User manual for the CIRYCASE 360° Rotatable Bike Phone Mount. This guide details installation and usage for securing smartphones on bicycles, motorcycles, scooters, and ATVs, highlighting its anti-vibration features and secure handlebar clamp.</p>
	<p>CIRYCASE J49 Bluetooth Receiver User Manual - Wireless Audio Adapter</p> <p>User manual for the CIRYCASE J49 Bluetooth V5.3 Receiver. Learn how to pair, charge, operate, and troubleshoot this wireless audio adapter for car stereos, home stereos, and headphones.</p>



[CIRYCASE BC89 Bluetooth 5.3 Car FM Transmitter User Manual](#)

Comprehensive user manual for the CIRYCASE BC89 Bluetooth 5.3 car FM transmitter. Learn how to pair, play music, make calls, and troubleshoot issues with this car adapter, featuring Type-C PD and QC3.0 charging.



[User Manual: CIRYCASE Car Phone Holder - Installation and Usage Guide](#)

Comprehensive user manual for the CIRYCASE Car Phone Holder, detailing installation steps, usage notes, and important considerations for dashboard and windshield mounting. Includes multilingual instructions.



[CIRYCASE Bike Phone Holder User Manual](#)

User manual for the CIRYCASE Bike Phone Holder, detailing its features, installation, and usage for bicycles, scooters, and motorbikes. Includes compatibility and safety information.



[QIRITA Smartphone Tripod User Guide and Instructions](#)

Comprehensive guide for the QIRITA smartphone tripod, covering connection, setup, phone mounting, and battery replacement. Learn how to use your QIRITA tripod effectively.