

[Manuals.plus](#) /

› [Doublepow](#) /

› Camping LED Fan with Light Instruction Manual

Doublepow D10-Orange 20000mAh

Camping LED Fan with Light Instruction Manual

Model: D10-Orange 20000mAh

Brand: Doublepow

1. INTRODUCTION

Thank you for purchasing the Doublepow Camping LED Fan with Light. This versatile device is designed to provide cooling and illumination for various outdoor activities such as camping, fishing, and worksites, as well as for indoor use during power outages. With its 20000mAh rechargeable battery, multiple speed settings, and bright LED light, it offers convenience and reliability.

2. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using the product to prevent injury or damage.

- Do not insert fingers or any objects into the fan guard.
- Keep away from water and excessive moisture.
- Do not disassemble or attempt to repair the unit yourself. Contact customer support for assistance.
- Use only the specified charging cable and power adapter (5V3A recommended).
- Keep out of reach of children.
- Do not expose to extreme temperatures or direct sunlight for prolonged periods.
- Ensure the fan is placed on a stable surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Doublepow Camping LED Fan with Light
- 1 x Type-C Charging Cable
- 1 x Lanyard

- 1 x User Manual (this document)

4. PRODUCT FEATURES

The Doublepow Camping LED Fan is equipped with several features for optimal performance and convenience:

- **20000mAh Rechargeable Battery:** Provides 8-100 hours of operation depending on speed and light usage. Fully charges in 8-9 hours.
- **Super Bright LED Light:** Features 16 LED beads with Cold and Warm Illumination modes and 5 brightness settings (3 cold, 2 warm).
- **Double Clover Design:** Enhances airflow for more powerful cooling.
- **4 Speed Settings:** Adjustable fan speeds to meet different cooling needs.
- **270° Rotation:** Allows for quick and precise airflow direction.
- **Independent Controls:** Fan and LED lights are controlled separately.
- **Battery and Speed Indicators:** 4 speed lights and 4 battery lights display current settings and remaining capacity.
- **Sleep Mode:** Button to turn off lights for undisturbed sleep.
- **Versatile Placement:** Features a 360° swivel table base and foldable hooks for hanging.
- **Durable Construction:** Made of sturdy ABS material, designed to be fall-proof and collision-proof.



Figure 4.1: Front view of the Doublepow Camping LED Fan, highlighting its compact and robust design.



Figure 4.2: Illustration detailing the fan's running times at different speeds and LED light levels, along with its impressive 20000mAh battery capacity.

5. SETUP

The Doublepow Camping LED Fan is designed for easy setup. Follow these steps to prepare your fan for use:

1. **Unpack:** Carefully remove the fan and all accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the fan using the provided Type-C cable. Connect the cable to the fan's charging port and plug the other end into a 5V3A power adapter (not included). The battery indicator lights will show charging progress.
3. **Placement:**
 - For tabletop use, ensure the fan is on a flat, stable surface.
 - For hanging, extend the integrated hook from the base and securely hang the fan from a tent loop, branch, or other suitable fixture.



Figure 5.1: The fan being charged via its Type-C port, demonstrating its rechargeable capability.

6. OPERATING INSTRUCTIONS

The fan and light functions are controlled independently.

6.1 Fan Operation

1. **Power On/Off:** Press the fan power button (usually indicated by a fan icon) to turn the fan on or off.
2. **Adjust Fan Speed:** Repeatedly press the fan speed button to cycle through the 4 available speed settings. The speed indicator lights will illuminate to show the current speed.
3. **Adjust Direction:** Manually adjust the fan head up or down by 270 degrees to direct airflow as needed.



Figure 6.1: The fan head demonstrating its 270-degree rotation capability for adjustable airflow.

6.2 LED Light Operation

1. **Power On/Off:** Press the light power button (usually indicated by a light bulb icon) to turn the LED light on or off.
2. **Adjust Brightness/Mode:** Repeatedly press the light button to cycle through the 5 brightness settings (3 cold light, 2 warm light).
3. **Sleep Mode:** Press the moon icon button to activate sleep mode, which turns off all indicator lights for undisturbed rest.

6.3 Battery Indicator

The 4 battery indicator lights on the control panel show the remaining battery capacity. Each light typically represents 25% of the battery charge.

7. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your fan.

- **Cleaning:**

- Ensure the fan is turned off and unplugged before cleaning.
- Use a soft, dry cloth to wipe down the exterior of the fan.
- For stubborn dirt, a slightly damp cloth can be used, but ensure no water enters the fan's internal components.
- Do not use abrasive cleaners or solvents.

- **Storage:**

- When not in use for extended periods, store the fan in a cool, dry place.
- It is recommended to fully charge the battery before storing and to recharge it every 3-6 months

to maintain battery health.

8. TROUBLESHOOTING

If you encounter any issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully using the Type-C cable.
Fan is not charging.	Loose cable connection or faulty adapter/cable.	Ensure the Type-C cable is securely connected. Try a different USB port, adapter, or cable.
LED light does not turn on.	Light function is off or battery is low.	Press the light power button. Check battery level and recharge if necessary.
Weak airflow.	Fan is on a low speed setting or battery is low.	Increase the fan speed. Recharge the battery.
Unusual noise during operation.	Obstruction in the fan blades or internal issue.	Turn off the fan and check for any obstructions. If the noise persists, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact Doublepow customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
Brand	Doublepow
Model Name	D10
Color	D10-Orange
Power Source	Battery Powered
Battery Capacity	20000mAh
Charging Input	5V3A (via Type-C)
Charging Time	8-9 hours
Running Time (Fan only)	8-100 hours (depending on speed)
LED Beads	16
Light Modes	Cold and Warm Illumination (5 brightness settings)
Fan Speeds	4
Rotation Angle	270° (manual tilt)
Material	Durable ABS

Feature	Detail
Product Dimensions	2.83"D x 3.35"W x 4.06"H
Item Weight	2.64 Pounds
Included Components	Lanyard

10. WARRANTY AND SUPPORT

Doublepow products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Doublepow website. Please have your product model number (D10-Orange 20000mAh) and purchase date ready when contacting support.

For more information, you may visit the brand's Amazon store:[Doublepow Amazon Store](#)