onerbl BB730, BB742, BB743, BB783

onerbl AC Power Adapter Charger User Manual

For Billboard Wireless Speaker Models: BB730, BB742, BB743, BB783

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC Power Adapter Charger. This adapter is specifically designed to provide power to Billboard Wireless Speaker models BB730, BB742, BB743, and BB783. Please read this manual thoroughly before operating the device and retain it for future reference.



Image 1.1: The onerbl brand logo, indicating a superior power supply product.

2. Safety Information

To ensure safe operation and prevent damage, observe the following safety precautions:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter. This will void the warranty and may cause electrical hazards.
- Ensure the adapter is used with compatible devices only. Refer to the specifications section for details.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.



Image 2.1: The adapter features a smart chip for multiple protections, including short-circuit, over-voltage, and over-current protection, enhancing electrical safety.

3. Setup

Follow these steps to set up your onerbl AC Power Adapter Charger:

1. **Verify Compatibility:** Ensure your Billboard Wireless Speaker model (BB730, BB742, BB743, or BB783) is compatible with this adapter.
2. **Connect to Speaker:** Insert the barrel connector end of the adapter cable into the power input port on your Billboard Wireless Speaker.
3. **Connect to Power Outlet:** Plug the 2-pin AC plug of the adapter into a standard AC 100-240V wall power outlet.
4. **Power On:** Once connected, your speaker should receive power. Refer to your speaker's manual for specific power-on instructions.

4. Operating Instructions

The onerbl AC Power Adapter Charger operates automatically once connected to a power source and a compatible device. It is designed for continuous use within its specified voltage range.

- The adapter automatically adjusts to input voltages between 100-240V AC.
- The built-in protection features safeguard both the adapter and your connected speaker from electrical irregularities.



Image 4.1: The adapter features an extended cord design, offering various cable lengths (e.g., 10 ft and 6.6 ft) for flexible placement and convenience.

5. Maintenance

Proper maintenance ensures the longevity and performance of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the speaker before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connector for any signs of wear, cuts, or damage. If damage is observed, discontinue use and replace the adapter.



Image 5.1: The adapter is constructed with quality control in mind, featuring durable materials like copper wire and a PVC jacket for enhanced longevity and safety.

6. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

- **No Power to Speaker:**
  - Ensure the adapter is securely plugged into both the wall outlet and the speaker.
  - Check if the wall outlet is functional by plugging in another device.
  - Verify that the speaker's power input port is clean and free of debris.
- **Adapter Overheating:**
  - Disconnect the adapter and allow it to cool down.
  - Ensure the adapter is not covered or placed in an area with poor ventilation.
  - If overheating persists, discontinue use and contact support.
- **Loose Connection:**
  - Check the barrel connector for any damage or bending.
  - Ensure the speaker's power port is not damaged.

If these steps do not resolve the issue, please contact customer support.

7. Specifications

Brand	onerbl
Model Compatibility	Billboard Wireless Speakers (BB730, BB742, BB743, BB783)
Input Voltage	AC 100-240V, 50/61Hz (Worldwide Auto Input)

Connector Type	Barrel Connector
Main Power Connector Type	2 Pin
Protection Features	Over Voltage Protection, Over Heat Protection, Short-circuit Protection, Over-current Protection
Product Dimensions	6 x 4 x 2 inches
Item Weight	8 ounces
Power Source	Corded Electric



Image 7.1: The onerbl power adapter is designed for a wide range of applications, compatible with various electronic devices beyond the specified speakers.

8. Warranty Information

This onerbl product is typically covered by a standard manufacturer's warranty, which generally covers defects in materials and workmanship under normal use. The specific duration and terms of the warranty may vary. Please refer to the product packaging or contact the retailer for detailed warranty information.

9. Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact the retailer or manufacturer directly. Have your product model number (BB730, BB742, BB743, BB783) and ASIN (B0B151SP67) available when contacting support.