Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl B0B1528M64

onerbl AC Adapter Power Supply User Manual

For Nordic Track Ellipse 950e and 950c

1. Introduction and Overview

This manual provides essential information for the safe and effective use of your onerbl AC Adapter Power Supply. This adapter is designed as a replacement power source for Nordic Track Ellipse 950e and 950c models. Please read this manual thoroughly before use to ensure proper operation and to prevent damage to the adapter or your device.



Image: Front and side view of the onerbl AC adapter, showing its compact design and two-pin plug.

2. Safety Information

Your onerbl AC Adapter is equipped with advanced safety features to protect your devices and ensure safe operation. Adhering to these guidelines is crucial for preventing electrical hazards and equipment damage.

- **Over Voltage Protection:** Prevents damage to connected devices from excessive voltage input.
- **Over Heat Protection:** Automatically shuts down the adapter if internal temperatures exceed safe operating limits.
- **Short-Circuit Protection:** Guards against electrical shorts, protecting both the adapter and the connected device.

The adapter operates with a wide input voltage range of AC 100-240V, 50/60Hz, making it suitable for various regions. Always ensure the power outlet matches the adapter's specifications and local electrical standards. Do not use the adapter if it appears damaged or if the cable is frayed.



Image: A diagram illustrating the smart chip technology and multiple protection features, including short-circuit, over-voltage, and over-current protection, ensuring electricity safety.

3. Setup Instructions

Follow these steps to correctly set up and connect your AC adapter to your Nordic Track Ellipse device:

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter unit and its power cable for any signs of physical damage, cuts, or fraying. Do not use the adapter if any damage is observed.
2. **Connect to Device:** Carefully insert the adapter's output connector (the smaller plug) firmly into the power input port of your Nordic Track Ellipse 950e or 950c. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the AC adapter's two-pin plug into a standard, functional wall power outlet. The adapter is compatible with AC 100-240V, 50/60Hz outlets.
4. **Verify Connection:** Once both connections are made, ensure they are secure. Your Nordic Track Ellipse device should now receive power.



Image: An onerbl AC adapter plugged into a power strip, with its cable extending to connect to a laptop, demonstrating a typical usage scenario.

4. Operating Instructions

Once properly connected, the onerbl AC adapter will automatically supply the necessary power to your Nordic Track Ellipse device. No further user intervention is typically required for operation.

- The adapter is designed for continuous operation within its specified voltage and current limits.
- To conserve energy and prolong the adapter's lifespan, disconnect the adapter from the wall power outlet when the device is not in use for extended periods.
- Ensure the adapter is placed in a well-ventilated area to prevent overheating during prolonged use.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your onerbl AC adapter. Follow these guidelines for care:

- **Cleaning:** Always disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry, lint-free cloth to wipe the exterior. Do not use liquid cleaners, abrasive chemicals, or solvents, as these can damage the adapter.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight, moisture, and extreme temperatures. Avoid tightly coiling the cable, which can stress the internal wires and lead to damage.
- **Cable Care:** Do not bend, twist, or pinch the power cable excessively, especially near the connectors. Avoid placing heavy objects on the cable, as this can cause internal damage. Always grasp the plug, not the cable, when disconnecting from an outlet.



Image: A diagram highlighting the internal copper wire and PVC jacket construction, emphasizing the durable design and quality control of the adapter's cable.

6. Troubleshooting

If you encounter issues with your onerbl AC adapter, refer to the following common problems and solutions:

- **No Power to Device:**
  - Ensure the adapter is securely plugged into both your Nordic Track Ellipse device and the wall power outlet.
  - Check if the wall outlet is functional by plugging in another known working device.
  - Verify that the device's power input port is clean and undamaged.
- **Adapter is Excessively Hot:**
  - It is normal for the adapter to feel warm during operation. If it becomes excessively hot to the touch, disconnect it immediately and allow it to cool in a well-ventilated area.
  - Ensure adequate ventilation around the adapter and that it is not covered by anything.
  - Check if the device connected is drawing too much power, potentially exceeding the adapter's capacity.
- **Intermittent Power:**

- Check all connections (device to adapter, adapter to wall) for looseness. Re-seat them firmly.
- Inspect the cable for any visible damage, kinks, or fraying that could interrupt the power flow.

If problems persist after attempting these solutions, discontinue use and contact customer support for further assistance.

7. Specifications




Image: A diagram illustrating the physical dimensions of the AC adapter, including its length (2.6 inches), width (1.6 inches), height (1.2 inches), and the cable length (76 inches).

Product Specifications

Feature	Detail
Brand	onerbl
Model Number (ASIN)	B0B1528M64
Input Voltage	AC 100-240V, 50/60Hz

Feature	Detail
Power Source	Corded Electric
Main Power Connector Type	2 Pin (US Standard)
Item Weight	8 Ounces (approx. 227 grams)
Cable Length	76 inches (approx. 6.3 feet / 1.9 meters)
Manufacturer	Shenzhen Waweis Technology Co., Ltd

8. Warranty and Support

For specific warranty information regarding your onerbl AC Adapter Power Supply, please refer to the documentation provided with your original purchase. In most cases, warranty details are included with the product packaging or available from the seller.

For technical support, troubleshooting assistance beyond what is covered in this manual, or to inquire about warranty claims, please contact the seller or manufacturer directly. Keep your purchase receipt or order number handy, as it may be required for support or warranty services.

Contact Information: Please refer to your purchase platform or product packaging for the most current contact details for onerbl or the authorized seller.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B1528M64

More documents and user manuals: **https://manuals.plus/**