

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ANGELBLISS](#) /
- › [ANGELBLISS BC-G Portable Baby Bouncer Instruction Manual](#)

ANGELBLISS BC-G

ANGELBLISS BC-G Portable Baby Bouncer Instruction Manual

Model: BC-G

Brand: ANGELBLISS

1. SAFETY INFORMATION

Please read and understand all instructions before assembling and using the ANGELBLISS BC-G Portable Baby Bouncer. Keep this manual for future reference.

- **Age and Weight Limit:** Suitable for newborns and infants from 0-9 months, up to a maximum weight of 19.8 lbs (9 kg).
- **Harness Use:** Always secure your child with the 3-point safety harness. Ensure it is properly adjusted and fastened.
- **Supervision:** Never leave your child unattended in the bouncer. Constant adult supervision is required.
- **Placement:** Place the bouncer on a flat, stable, and level surface. Avoid placing it on elevated surfaces where a fall could occur.
- **Stability:** The thickened iron frame base with non-slip pads is designed for stability. Ensure the bouncer is stable before placing your child in it.
- **Avoid Hazards:** Keep the bouncer away from stairs, open flames, heaters, and other potential hazards.
- **Product Integrity:** Regularly inspect the bouncer for any signs of damage, loose parts, or wear. Discontinue use if any issues are found.

2. PRODUCT OVERVIEW

The ANGELBLISS BC-G Portable Baby Bouncer is designed to provide a safe and comfortable space

for your infant, encouraging natural movement and development.

Key Features:

- **Natural Bouncing:** Engages and soothes babies with gentle, natural up-and-down motion powered by the baby's own movements, aiding in balance and motor skill development.
- **Ergonomic Design:** Features an ergonomic fabric seat and specific recline to fit the baby's body, providing proper support for their back, head, and neck, and protecting the spine.
- **Quality Construction:** The wood grain base utilizes an environmentally friendly thermal transfer printing process, ensuring it is non-toxic, mold-free, and resistant to paint loss. The sleek, modern design complements any home decor.
- **Safety & Portability:** ASTM approved with a 3-point harness for secure restraint. Lightweight and compact for easy movement and travel. Quick-release design for simple cleaning.



Figure 1: The ANGELBLISS BC-G Portable Baby Bouncer in Grey, shown with a mother interacting with her baby.

3. SETUP AND ASSEMBLY

The ANGELBLISS BC-G Portable Baby Bouncer is designed for quick and easy assembly. Follow

these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure you have the fabric seat, the wooden base, and any connecting rods or fasteners.
2. **Assemble the Base:** Connect the wooden base components. The design typically involves inserting rods into designated slots on the base frame. Ensure all connections are secure.
3. **Attach Fabric Seat:** Position the fabric seat onto the assembled base. The seat features a quick-release design, often with snaps or buttons along the edges that attach to the frame.
4. **Secure the Seat:** Fasten all snaps or buttons to ensure the fabric seat is firmly attached to the base. Verify that the seat is taut and correctly aligned.
5. **Check Harness:** Ensure the 3-point safety harness is untwisted and easily accessible for securing your baby.

WOODEN BASE

Adopt thermal-transfer printing process



100% POLYESTER

Elastic, soft and comfortable texture
give baby proper protection

Figure 2: Detail of the bouncer's wooden base and the quilted polyester fabric, highlighting the quality workmanship.

Assembly Video:

Your browser does not support the video tag.

Video 1: Official product video demonstrating the ANGELBLISS Portable Bouncer for Babies, including assembly and usage. This video is provided by the seller, LZH's Online Shop.

4. OPERATING INSTRUCTIONS

Using your ANGELBLISS BC-G Portable Baby Bouncer is straightforward, providing comfort and engagement for your baby.

1. **Place Baby in Bouncer:** Gently place your baby into the bouncer seat, ensuring their back, head, and neck are properly supported by the ergonomic design.
2. **Secure the Harness:** Fasten the 3-point safety harness around your baby. Adjust the straps to ensure a snug but comfortable fit. The harness is designed to keep your little one safely strapped in.
3. **Natural Bouncing:** The bouncer is designed to respond to your baby's own movements, creating a gentle, natural bouncing motion. You can also gently rock the bouncer with your hand or foot to encourage movement.
4. **Interaction:** Engage with your baby while they are in the bouncer. The upright position allows for good visibility and interaction.
5. **Portability:** The lightweight and compact design allows you to easily move the bouncer between rooms, keeping your baby close by.



Figure 3: A baby safely secured in the bouncer using the 3-point harness.



Figure 4: The bouncer's ergonomic design and natural bouncing motion.

5. MAINTENANCE AND CLEANING

Regular maintenance and cleaning will ensure the longevity and hygiene of your ANGELBLISS BC-G Portable Baby Bouncer.

- **Fabric Seat:** The fabric seat features a quick-release design, making it easy to remove. It is machine washable. Follow the care instructions on the label, typically using a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat.
- **Base Frame:** Wipe the wooden base and plastic components with a damp cloth and mild soap. Dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the bouncer in a clean, dry place away from direct sunlight and extreme temperatures. Its compact design allows for easy storage.

6. TROUBLESHOOTING

If you encounter any issues with your ANGELBLISS BC-G Portable Baby Bouncer, please refer to the following common solutions:

- **Bouncer not stable:** Ensure all base components are correctly assembled and securely fastened. Check that the bouncer is placed on a flat, even surface. Verify the non-slip pads are intact.
- **Harness not securing properly:** Ensure the harness straps are not twisted and are correctly threaded through the buckles. Adjust the straps to fit your baby snugly.
- **Difficulty removing/attaching fabric seat:** Ensure all snaps or buttons are fully disengaged before attempting to remove the seat. When reattaching, align the snaps/buttons carefully and press firmly until they click into place.

For further assistance, please contact ANGELBLISS customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	28"D x 18"W x 20"H (71 x 46 x 51 cm)
Item Model Number	BC-G
Maximum Weight Recommendation	19.8 Pounds (9 kg)
Material Type	Polyester
Material Composition	Polyester
Care Instructions	Machine Washable
Batteries Required	No
Is Portable	Yes
Item Weight	4.32 Pounds (1.96 kg)
Color	Grey



Figure 5: Product dimensions and key features like the adjustable harness and anti-skidding pads.

8. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official ANGELBLISS website or contact their customer service department directly.

Keep your proof of purchase for any warranty claims.