

[Manuals.plus](#) /

› [A-MIND](#) /

› A-MIND Screen Replacement for Sky Devices Elite Octa Plus 8-inch Tablet - Instruction Manual

A-MIND Elite Octa Plus

Instruction Manual: Sky Devices Elite Octa Plus Touch Screen Replacement

Brand: A-MIND | Model: Elite Octa Plus

1. INTRODUCTION

This manual provides essential information for the installation and care of your A-MIND replacement touch screen digitizer for the Sky Devices Elite Octa Plus 8-inch tablet. This product is a touch screen panel digitizer glass and does **not** include the LCD display. It is intended for repair purposes to restore touch functionality to your device.

2. PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- 1x Black Digitizer For Sky Devices Elite Octa Plus Glass Touch Screen Replacement
- 1x Strong Suction Cup
- 1x Triangle Opening Tools
- 1x Spudger
- 1x Adhesive Tape



Image 2.1: Contents of the Sky Devices Elite Octa Plus touch screen replacement kit, including the digitizer and various repair tools.

3. COMPATIBILITY

This touch screen digitizer is **only** compatible with the **45-pin Sky Devices Elite Octa Plus 8-inch Tablet PC**. It is crucial to correctly identify your device model before attempting any installation. Using an incorrect model may result in damage to your tablet or the replacement part.

4. IMPORTANT SAFETY AND INSTALLATION WARNINGS

Replacing a tablet screen requires specialized tools and technical expertise. **We strongly recommend that installation be performed by a professional repair technician.** Attempting self-installation without proper knowledge and tools may lead to further damage to your device, voiding any potential warranty or return eligibility.

- **Risk of Damage:** Screens are made of glass and are fragile. Handle with extreme care during unpacking and installation to prevent breakage.
- **Battery Disconnection:** Before beginning any installation, always disconnect the battery from your equipment. This prevents short circuits and potential damage to the device's internal components.
- **Pre-Installation Testing:** Before permanently installing the screen with adhesive, connect the new screen and test its functionality. Reconnect the battery and power on your device to ensure the touch screen responds correctly. Do not apply adhesive until you confirm the screen works perfectly. Once adhesive is

applied, returns or refunds for functional issues may not be accepted.

- **Professional Tools:** Separation of the old touch screen from the LCD and installation of the new touch screen onto the LCD typically requires professional machinery.



Image 4.1: The replacement touch screen digitizer shown in its protective packaging.




Image 4.2: A close-up view of the flex cable connector on the touch screen digitizer, which connects to the tablet's main board.





Image 4.3: The reverse side of the touch screen digitizer, showing the adhesive strips for secure mounting.






Image 4.4: Front view of the Sky Devices Elite Octa Plus touch screen replacement, ready for installation.

5. INSTALLATION GUIDE

As this is a complex repair, detailed step-by-step instructions are not provided in this manual. We highly recommend seeking professional assistance for installation. For visual guidance, you may search for installation videos on platforms like YouTube. Search terms such as "Sky Devices Elite Octa Plus screen replacement" may yield helpful results.

Video 5.1: A showcase video demonstrating the Sky Devices Elite Octa Plus Touch Screen Replacement. This video provides a visual overview of the product.

6. CARE AND MAINTENANCE

Once installed, treat your new touch screen with care to ensure its longevity:

- **Avoid Excessive Pressure:** Do not apply undue pressure to the screen, as this can cause damage to the digitizer or the underlying LCD.
- **Clean Gently:** Use a soft, lint-free cloth, slightly dampened with water or a screen-safe cleaner, to wipe the screen. Avoid harsh chemicals or abrasive materials.
- **Protect from Drops:** Consider using a protective case and screen protector to minimize the risk of damage from accidental drops or impacts.
- **Temperature Extremes:** Avoid exposing the device to extreme temperatures, as this can affect screen performance and lifespan.

7. TROUBLESHOOTING

If you encounter issues after installation, consider the following:

- **No Touch Response:** Ensure all flex cables are securely connected and not damaged. A loose connection is a common cause.
- **Partial Touch Response:** This could also indicate a loose or damaged flex cable, or an issue with the digitizer itself.
- **Screen Not Lighting Up:** This product is a digitizer only. If the screen does not light up, the issue is likely with the LCD display, not the touch screen digitizer.
- **Ghost Touches/Erratic Behavior:** Ensure the screen is clean and free of debris. Recheck connections.

If problems persist, please refer to the Warranty and Support section for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	Screen Replacement For Sky Devices Elite Octa Plus
Size	8.0 inch
Type	Touch Screen Panel Digitizer Glass (Not LCD Display)
Package Dimensions	10.59 x 6.02 x 1.34 inches
Item Weight	7.8 ounces
Manufacturer	A-MIND

9. WARRANTY AND SUPPORT

We provide a **3-month warranty** for this product. The warranty covers manufacturing defects and functional issues under normal use. It does not cover damage caused by improper installation, misuse, or physical damage (e.g., scratches, cracks, liquid damage).

All products undergo strict quality control testing before shipment to ensure they are in good working condition. If you have any problems with your order or require assistance, please do not hesitate to contact our customer service team. We are committed to providing support within 24 hours.

For quality-related issues, provided the screen has no man-made or physical damage, we can arrange an exchange if it does not function normally.

