

Zippo Heatbank 9s

Zippo Heatbank 9s Rechargeable Hand Warmer Instruction Manual

Model: Heatbank 9s

1. INTRODUCTION

Thank you for choosing the Zippo Heatbank 9s Rechargeable Hand Warmer. This device provides reliable warmth and also functions as a portable power bank for your USB-compatible devices. Please read this manual thoroughly before use to ensure proper operation and safety.



Figure 1: Front view of the Zippo Heatbank 9s Rechargeable Hand Warmer.

2. PRODUCT OVERVIEW

The Zippo Heatbank 9s is designed for comfort and utility in cold conditions. It features a durable aluminum housing and an ergonomic design for easy handling. Key features include:

- Dual-sided heat output up to 120°F / 50°C.
- Six (6) adjustable heat settings.
- Integrated 5200 mAh lithium-ion battery for up to 9 hours of warmth.
- Functions as a power bank to charge USB-compatible devices.

- Battery and heat indicator lights.
- Includes a lanyard and charging cord.



Figure 2: Back view of the Zippo Heatbank 9s, showing model and capacity details.



Figure 3: Close-up of the charging ports and indicator lights on the Heatbank 9s.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your Zippo Heatbank 9s. Connect the included USB charging cable to the micro-USB input port on the device and to a USB power source (e.g., computer, wall adapter). The blue indicator lights will flash during charging and remain solid when fully charged.

3.2 Attaching the Lanyard

The Heatbank 9s comes with a lanyard for convenient carrying. Thread the loop of the lanyard through the designated hole at the top of the device and secure it as desired.



Figure 4: The Zippo Heatbank 9s with its included lanyard and USB charging cable.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To turn on the hand warmer function, press and hold the power button for approximately 3 seconds. The indicator lights will illuminate.

To turn off the hand warmer function, press and hold the power button for approximately 3 seconds until the lights turn off.

4.2 Checking Battery Level

Press the power button quickly (do not hold) to check the current battery level. The blue indicator lights will show the charge status.

4.3 Adjusting Heat Settings

Once the hand warmer is on, short press the power button to cycle through the heat settings:

- **Blue Lights:** Indicate dual-sided heating. There are three intensity levels within this mode.
- **Green Lights:** Indicate single-sided heating. There are three intensity levels within this mode.

The device will reach its maximum temperature of 120°F / 50°C on the highest setting.

5. CHARGING EXTERNAL DEVICES

The Zippo Heatbank 9s can also charge other USB-compatible devices. Connect your device's charging cable to the USB-A output port on the Heatbank 9s. The blue indicator lights will show the remaining battery capacity. Note that the heating function is disabled when the device is actively charging an external device.

6. MAINTENANCE

To ensure the longevity of your Zippo Heatbank 9s:

- Keep the device clean and dry.
- Avoid extreme temperatures and direct sunlight.
- Store in a cool, dry place when not in use.
- Do not attempt to disassemble or modify the device.

7. TROUBLESHOOTING

7.1 Device Not Heating

- Ensure the device is sufficiently charged. Check battery indicator lights.
- Confirm the heating function is activated by pressing and holding the power button until lights illuminate.
- If charging an external device, the heating function is temporarily disabled. Disconnect the external device.

7.2 Device Not Charging

- Verify the charging cable is securely connected to both the Heatbank 9s micro-USB input and the power source.
- Try a different USB charging cable or power source.
- Ensure the power source is active.

8. SPECIFICATIONS

Feature	Detail
Model Name	Heatbank 9s
Part Number	40652
Battery Type	Lithium-Ion
Battery Capacity	5200 mAh
Upper Temperature Rating	120°F / 50°C
Heat Settings	6 (3 dual-sided, 3 single-sided)
Run Time	Up to 9 hours
Material	Aluminum
Item Weight	5.6 ounces
Item Dimensions (LxWxH)	2.38 x 0.95 x 4.88 inches
UPC	191693406528

9. OFFICIAL PRODUCT VIDEO

Video 1: A brief product overview demonstrating the Zippo Heatbank 9s features and functionality.

10. WARRANTY AND SUPPORT

The Zippo Heatbank 9s comes with a 1-year warranty. For warranty claims or technical support, please refer to the contact information provided on the official Zippo website or your purchase documentation.

11. SAFETY INFORMATION

WARNING: Cancer and Reproductive Harm -www.P65Warnings.ca.gov. KEEP OUT OF REACH OF CHILDREN. KEEP AWAY FROM FIRE OR TEMPERATURES ABOVE 120°F (49°C).