

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ASONPAO](#) /

› [ASONPAO Garage Door Opener Remote GITR-3 OCDTR-3 Intellicode Instruction Manual](#)

ASONPAO GITR-3/OCDTR-3

ASONPAO Garage Door Opener Remote Instruction Manual

Model: GITR-3/OCDTR-3

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ASONPAO GITR-3/OCDTR-3 garage door opener remote. This remote is designed for wide compatibility with Genie and Overhead Door garage door openers manufactured from 1997 to the present, utilizing Intellicode technology.

The remote features a durable ABS alloy casing, a long-lasting 240mAh lithium battery, and Auto-Seek Rolling Code technology for enhanced security. It offers a control range of up to 164 feet and includes a convenient clip for sun visor attachment.



Figure 1: ASONPAO GITR-3/ OCDTR-3 Garage Door Opener Remote. This image shows the compact, black remote with three buttons and a metal clip for attachment.

2. IMPORTANT COMPATIBILITY INFORMATION

This remote is compatible with Genie and Overhead Door garage door openers manufactured from 1997 to the present that use Intellicode technology. **It is NOT compatible with openers that use DIP switches.**

This remote replaces the following models:

- GITR-3, OCDTR-3
- GIT-1, ACSCTG Type1, ACSCTO Type 1, 1704
- ACSCTG Type 3, ACSCTO Type 3, OCDT-3
- GIC-3, OCDT3, GIC3, GIT-3, GIT3
- ACSOT, B8QACSOT, OC2T-3, B8Q 315390T
- 2133A 315390T, ocd390-3

IMPORTANT BEFORE PURCHASING



Replaces These Models — 1997 to Present



Not Works For Remote With **DIP SWITCH**



Figure 2: Compatibility overview. This image illustrates various compatible remote models and clearly indicates that remotes with DIP switches are not supported.

3. SETUP AND PROGRAMMING

Follow these steps to program your ASONPAO remote to your garage door opener. Ensure you are near your garage door opener unit during the programming process.

3.1. Putting Your Opener into Programming Mode

For New Openers:

1. Press and hold the program button on your opener unit until the round LED turns blue. Then, release the button.
2. The round LED will go out, and the long LED will begin flashing purple.

For Garage Door Openers and External Receivers Manufactured between 1995 to 2011:

- Press and release the "LEARN CODE" button once. The red LED will begin to flash.

Proceed to step 3.2 after your opener is in programming mode.

3.2. Programming the Remote to Your Opener

Note: Once in programming mode, you will have approximately 30 seconds to perform this step.

1. Stand at least 5 feet away from the opener. This ensures proper communication between the remote and the opener.
2. Slowly press and release the remote button of your choice two times. The opener LEDs will flash and go off, indicating successful programming.
3. Press and release the same button a third time, and the garage door should operate. If the LEDs do not go off, or if the door does not operate, press the remote button several more times to achieve confirmation.



Figure 3: Remote Programming Steps. This image provides a visual guide to the programming process for both new and older garage door openers.

3.3. Erasing All Remotes (Lost or Stolen Remote)

For New Openers:

1. Press and hold the program button until the round LED turns blue, then release.
2. Press and hold the UP (^) Down (v) buttons at the same time until both LEDs flash blue and go OFF.

For Openers and External Receivers Manufactured between 1995 to 2011:

- To erase all remote devices from all other types of Genie® openers, press and hold the Learn Code button until the LED stops blinking.

Note: Clearing remote control memory from the power head will clear ALL programmed remotes and keypads. Your opener will no longer recognize any signal from any remote device, including a missing remote device.

4. OPERATING INSTRUCTIONS

Once programmed, your ASONPAO remote is ready for use. Simply press the programmed button to open or close your garage door. The remote offers a reliable control range of up to 164 feet (50 meters).

The compact design includes a sun visor clip for convenient access while driving. Attach the remote to your car's sun visor for easy operation.

ADDITIONAL CONTROLLER, ADDED CONVENIENCE



For Members of All Types



Cross-Vehicle Applicability



Applicable to Multiple Scenarios

Figure 4: Remote Operation. This image shows the remote being used from inside a vehicle, highlighting its convenience and range.

5. MAINTENANCE

5.1. Battery Replacement

Your remote is equipped with a long-lasting 240mAh lithium battery (CR2032). When the remote's range decreases significantly or the indicator light fails to illuminate, it may be time to replace the battery.

To replace the battery:

1. Carefully open the remote casing.
2. Remove the old CR2032 battery.
3. Insert a new 3V CR2032 lithium battery, ensuring correct polarity.
4. Close the remote casing securely.

Dispose of old batteries responsibly according to local regulations.



Figure 5: High Battery Longevity. This image emphasizes the remote's 240mAh lithium battery, contributing to extended battery life.

6. TROUBLESHOOTING

- **Remote not working after programming:** Re-attempt the programming steps carefully, ensuring the opener is in programming mode and you are within range.
- **Reduced operating range:** Check the remote's battery and replace it if necessary (refer to Section 5.1). Ensure there are no obstructions between the remote and the garage door opener.
- **Remote not compatible:** Verify that your garage door opener is a Genie or Overhead Door Intellicode model manufactured from 1997 to present. This remote is not compatible with DIP switch openers.
- **Indicator light not illuminating:** Replace the battery.

If you continue to experience issues, please refer to the Warranty and Support section for assistance.

7. SPECIFICATIONS

Model Number	GITR-3/ OCDTR-3
Brand	ASONPAO
Product Dimensions	3.5 x 2.05 x 0.62 inches
Item Weight	3.2 ounces
Batteries	2 Lithium Metal batteries (CR2032) required (included)
Working Voltage	DC3V
Frequency	390MHz

Channel	3
Max Number of Supported Devices	3
Control Range	164 feet (50 meters)
Shell Material	ABS Alloy
Security Code Type	Intellicode (Auto-Seek Rolling Code)

PRODUCT PARAMETER

Model:	GITR-3/OCDTR-3	Shell Material:	ABS
Working Range:	164Feet	Product Size:	3.5*2.05*0.62inches
Working Voltage:	DC3V	Product weight:	0.088LBS
Frequency:	390MHZ	Warranty:	3 years
Channel:	3	Colour:	Black
Battery Model:	3V CR2032	Code:	Intellicode

Figure 6: Product Specifications. This image provides a visual summary of the remote's key technical parameters.

8. WARRANTY AND SUPPORT

ASONPAO provides a **10-year warranty** for this product, ensuring long-term reliability and customer satisfaction. The product has undergone 100,000 validation tests and holds FCC certification.

For any queries or assistance, please contact ASONPAO customer support through the seller's page on Amazon or via

the provided support email. Our team aims to respond within 24 hours.



Figure 7: Warranty and Support Information. This image highlights the product's warranty, FCC certification, and available customer support.

