

[Manuals.plus](#) /

› [TUTOTAK](#) /

› TUTOTAK TB01BB024 C-Shaped End Table with Charging Station User Manual

TUTOTAK TB01BB024

TUTOTAK TB01BB024 C-Shaped End Table with Charging Station User Manual

Brand: **TUTOTAK** | Model: **TB01BB024**

1. PRODUCT OVERVIEW

The TUTOTAK TB01BB024 C-Shaped End Table is designed for convenience and functionality in various living spaces. This versatile table features an integrated charging station, a multi-pocket storage bag, and a sturdy C-shaped metal frame, allowing it to slide easily under sofas or beds. It serves as an ideal solution for keeping essential items and electronic devices within reach.



Image 1.1: The TUTOTAK C-Shaped End Table with its integrated charging station and storage bag, positioned beside a sofa.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use.

- **Adjustable feet:** Do not place on tiles or directly on wooden floors without proper protection to prevent scratches.
- **Electrical hazard:** Keep electrical outlets and USB ports dry and away from water. Do not overload electrical outlets. Unplug when not in use.
- Always follow manufacturer's instructions for safe use and assembly.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Tabletop (Engineered Wood)

- Metal Frame Components
- Charging Station (2 AC Outlets, 2 USB Ports, 6.5 ft Power Cord)
- Storage Bag (Fabric)
- Adjustable Feet (4 units)
- Assembly Hardware (screws, bolts, etc.)
- Assembly Instructions

4. ASSEMBLY INSTRUCTIONS

Assembly of the TUTOTAK C-Shaped End Table is designed to be simple and straightforward. Please refer to the detailed assembly instructions included in your package for step-by-step guidance. No special tools are required beyond a screwdriver (not included).



Image 4.1: Components of the C-Shaped End Table before assembly.

Ensure all screws are tightened securely, but do not overtighten. Attach the storage bag to the designated points on the metal frame. Finally, install the adjustable feet to ensure stability on uneven surfaces.



Image 4.2: The assembled C-Shaped End Table.

5. OPERATING INSTRUCTIONS


5.1 Charging Station

The integrated charging station provides convenient power access. It includes two standard AC outlets (120V/12A) and two USB ports (5V/2A) for charging various electronic devices. The power cord is 6.5 feet long, offering flexibility in placement.




120V/12A

– 2 AC Outlets –



5V/2A

– 2 USB Ports –



6.5-Foot

– Power Cord –



Image 5.1: Detail of the integrated charging station.

To use, simply plug the table's power cord into a wall outlet. Then, connect your devices to the available AC outlets or USB ports. Ensure devices are compatible with the provided power specifications.



Image 5.2: Table in use, demonstrating device charging.

5.2 Storage Bag

The side-mounted storage bag offers organized storage for various items. It features one large bag (9.1"x8.1") suitable for tablets, newspapers, or magazines, two intermediate bags (4.5"x5.5") for small notepads, and three small cloth bags for remote controls, mobile phones, or chargers.



Image 5.3: Detail of the multi-pocket storage bag.

5.3 Versatile Placement

The C-shaped design allows the table to slide under most sofas, couches, or beds, bringing the tabletop surface closer to you. This makes it suitable for use as a couch side table, laptop table, snack table, or coffee table.



Image 5.4: Table used as a bedside companion.

Your browser does not support the video tag.

Video 5.1: Official TUTOTAK video demonstrating the slim C-shaped end table with charging station and its versatile use.

6. MAINTENANCE

To maintain the appearance and longevity of your end table, follow these care instructions:

- Wipe the tabletop and metal frame with a damp cloth to remove dust and spills.
- For thorough cleaning, wipe with a dry cloth immediately after using a damp cloth.
- The tabletop is designed to be waterproof, heat-resistant, and anti-scratch, but avoid prolonged exposure to moisture or extreme heat.
- Regularly check the adjustable feet and tighten if necessary to ensure stability.



Image 6.1: Features highlighting the table's durability and adjustable feet.

7. TROUBLESHOOTING

If you encounter any issues with your TUTOTAK C-Shaped End Table, please refer to the following common solutions:

- **Power Outlets/USB Ports Not Working:**

- Ensure the table's main power cord is securely plugged into a functional wall outlet.
- Check if the device you are trying to charge is properly connected and functioning.
- Avoid overloading the outlets; disconnect some devices if too many are plugged in.
- If only USB ports are not working, try a different USB cable or device to isolate the issue.

- **Table Wobbles:**

- Adjust the four leveling feet at the bottom of the table to compensate for uneven floors.
- Ensure all assembly screws are tightened.

- **Difficulty Sliding Under Furniture:**

- Verify the height clearance of your sofa/bed. The table requires approximately 24.6 inches of

clearance.

8. SPECIFICATIONS

Feature	Specification
Brand	TUTOTAK
Model Number	TB01BB024
Product Dimensions (D x W x H)	15.8"D x 11.8"W x 24.6"H
Item Weight	8.88 Pounds
Maximum Weight Recommendation	7.8 Kilograms
Material Type	Engineered Wood, Metal
Frame Material Type	Metal
Top Material Type	Engineered Wood
Color	Brown
Power Outlets	2 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	6.5 feet
Storage Bag Dimensions (Large)	9.1" x 8.1"
Storage Bag Dimensions (Intermediate)	4.5" x 5.5" (2 bags)
Storage Bag Dimensions (Small)	3.4" x 4" (3 bags)
Special Features	Adjustable Feet, Waterproof, Heat-resistant, Anti-scratch
Indoor/Outdoor Usage	Indoor

9. WARRANTY AND SUPPORT

TUTOTAK offers a 30-day return policy and an 18-month limited warranty for this product. If you have any questions, concerns, or require assistance, please contact TUTOTAK customer service. Our friendly and reliable customer service team aims to respond within 24 hours.

For further support, please visit the official TUTOTAK store: [TUTOTAK Store on Amazon](#)