



[Manuals.plus](#) /

› [FLEXISPOT](#) /

› FLEXISPOT Q8W Electric Standing Desk User Manual

FLEXISPOT Q8

FLEXISPOT Q8W Electric Standing Desk User Manual

Model: Q8 | Brand: FLEXISPOT

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your FLEXISPOT Q8W Electric Standing Desk. Please read this manual thoroughly before use to ensure proper function and safety.

2. SAFETY INFORMATION

- Ensure the desk is completely lowered before moving it.
- Do not exceed the maximum weight capacity of the desk.
- Keep children and pets away from the desk during height adjustments.
- The anti-collision system is designed to prevent damage. Do not intentionally obstruct the desk's movement.
- Only use the provided power cable and accessories.
- Do not disassemble or modify the desk's electrical components.

3. SETUP AND ASSEMBLY

The FLEXISPOT Q8W desk is designed for straightforward assembly. It typically arrives in two packages, which may be delivered separately.



Image: The desk components are shipped in two separate boxes.

Assembly can be completed in approximately 15 minutes with the included tools and instructions. It is recommended to have two people for assembly due to the weight of the tabletop.

15 Min Quick Installation

Package includes Installation Instruction & Tool



Image: All components for the 15-minute quick installation, including the bamboo top, legs, and control unit.

Assembly Steps:

1. Unpack all components and verify against the parts list in the included manual.
2. Attach the desk legs to the tabletop using the provided screws and tools.
3. Connect the control panel and motor cables as instructed.
4. Place the desk in its desired location and plug it into a power outlet.

4. OPERATING INSTRUCTIONS

Height Adjustment:

The desk features an electric height adjustment system with a triple telescopic column for stability. The height can be adjusted from 62 cm to 125 cm.

REAL BAMBOO



Sustainable
Material



Resistant
to Wear



Nature
Pattern



Image: Smart Control Panel with height adjustment buttons and memory presets.

- Use the **Up** and **Down** arrows on the control panel to adjust the desk to your desired height.
- The desk includes four memory presets. To save a height, adjust the desk to the desired position, then press the **M** button followed by one of the numbered preset buttons **1, 2, 3, or 4**.
- To recall a saved height, simply press the corresponding numbered preset button.

Anti-Collision System:

The desk is equipped with an anti-collision system that automatically reverses movement if an obstacle is detected during height adjustment. This protects objects, children, and pets.

Charging Features:

The desk includes integrated charging capabilities for your devices.

Smart Control Panel




Image: Wireless charging area on the desk surface.

- **Wireless Charging:** Place your compatible smartphone on the designated wireless charging area on the desktop.
- **USB Ports:** Utilize the integrated USB Type-A and Type-C ports for charging other devices.

Integrated Drawer:

The desk features a spacious integrated drawer for organized storage of documents, supplies, and small items.



Image: Spacious desk drawer for organizing essentials.

5. MAINTENANCE

The bamboo tabletop is naturally resistant to water, scratches, and mites, requiring minimal maintenance.

- Regularly wipe the desk surface with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the bamboo finish.
- Periodically check all screws and connections to ensure they are secure.
- Keep the area around the desk legs clear to prevent obstruction during height adjustments.

6. TROUBLESHOOTING

If you encounter any issues with your FLEXISPOT Q8W desk, refer to the following common troubleshooting steps:

Desk Not Responding:

- Check if the power cable is securely plugged into both the desk and the wall outlet.

- Ensure there are no obstructions preventing the desk from moving.
- Try resetting the desk by unplugging it for 30 seconds and then plugging it back in.

Uneven Movement:

- Verify that the desk is placed on a level surface.
- Ensure that the weight on the desk is evenly distributed.

Charging Issues:

- For wireless charging, ensure your device is compatible and correctly positioned on the charging area.
- For USB ports, try a different cable or device to confirm the issue is with the port and not the cable/device.
Note that USB ports are primarily for charging phones and headphones, not high-power devices like laptops.

If problems persist after attempting these steps, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model Number	Q8
Model Name	Q8 Wide
Dimensions (L x W x H)	140 x 70 x 72 cm (Product Dimensions)
Adjustable Height Range	62 cm (Min) to 125 cm (Max)
Tabletop Material	Bamboo
Frame Material	Metal
Color	White Frame, Bamboo Top
Number of Motors	2
Number of Columns	3
Special Features	Height Adjustable, Electric, Wireless Charging, USB-A & USB-C Ports, Integrated Drawer, Anti-collision System
Number of Drawers	1
Assembly Required	Yes (Recommended 2 people)
UPC	810072808974

8. WARRANTY AND SUPPORT

Warranty Information:

The FLEXISPOT Q8W Electric Standing Desk comes with a 7-year limited warranty, ensuring reliable and worry-free use.

Customer Support:

For further assistance, technical support, or warranty claims, please visit the official FLEXISPOT store or contact their customer service directly.

[Visit the FLEXISPOT Store](#)