

Manuals.plus /
› [BoxWave](#) /
› BoxWave Sports Armband Instruction Manual

BoxWave Sports Armband

BoxWave Sports Armband Instruction Manual

Model: Sports Armband

INTRODUCTION

This manual provides instructions for the proper use and care of your BoxWave Sports Armband. Designed for active individuals, this armband offers a secure and convenient way to carry your compatible device during workouts, runs, or daily activities. It features an adjustable strap, a clear screen window, and durable elastic materials.



Figure 1: BoxWave Sports Armband shown with a compatible device (Nexgo K300 Mini-POS).

SETUP

Follow these steps to set up your BoxWave Sports Armband for use:

1. **Prepare the Armband:** Unfold the armband to reveal the device pocket and the adjustable strap.



Figure 2: The armband unfolded, displaying the interior pocket and strap mechanism.

2. **Insert Your Device:** Gently slide your compatible device (e.g., Nexgo K300 Mini-POS) into the clear window pocket of the armband. Ensure it is fully seated and the screen is visible through the clear window.
3. **Position on Arm:** Wrap the armband around your bicep or wrist. The clear window should face outwards for easy viewing.
4. **Secure the Strap:** Use the VELCRO fasteners to adjust the strap for a snug yet comfortable fit. Ensure the armband is secure enough not to slip during activity, but not so tight as to restrict circulation.



Figure 3: Proper placement of the armband on the bicep for secure wear.

OPERATING INSTRUCTIONS

The BoxWave Sports Armband is designed for simple and effective use:

- **Screen Access:** The clear window allows full touch screen access to your device. You can operate your device's functions, view notifications, and control apps without removing it from the armband.
- **Accessory Pockets:** The armband includes small integrated pockets for carrying essential items.
 - **Key Pocket:** A dedicated slot is available for a small key, ensuring it is secure during your activity.



Figure 4: Detail of the integrated key pocket for small essentials.

- **Headphone Port:** A cutout is provided for headphone cables, allowing you to listen to audio while your device is secured.



Figure 5: View of the headphone port and key pocket, demonstrating accessibility.

- **Hands-Free Convenience:** Enjoy the freedom of movement without needing to hold your device, making it ideal for various physical activities.

MAINTENANCE

To ensure the longevity and hygiene of your BoxWave Sports Armband, follow these maintenance guidelines:

- **Cleaning:** Wipe the armband with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Drying:** Allow the armband to air dry completely before storing or reusing it. Do not machine wash or tumble dry.
- **Storage:** Store the armband in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

If you encounter any issues with your BoxWave Sports Armband, consider the following:

Problem	Possible Cause	Solution
Armband feels too tight or too loose.	Incorrect strap adjustment.	Adjust the VELCRO fasteners to achieve a comfortable and secure fit around your bicep or wrist.
Device screen is difficult to see or operate through the clear window.	Device not properly aligned; clear window dirty.	Ensure the device is fully inserted and centered. Clean the clear window with a soft, damp cloth.
Armband slips during activity.	Strap is too loose; excessive sweat.	Tighten the strap using the VELCRO. If sweating heavily, consider wearing the armband over a thin sleeve.

SPECIFICATIONS

Feature	Detail
Item Weight	1.8 ounces
ASIN	B0B1G86CJJ
Date First Available	April 21, 2022
Manufacturer	BoxWave
Country of Origin	China
Compatible Devices	Mobile Phone (specifically Nexgo K300 Mini-POS)
Brand	BoxWave
Color	Jet Black
Special Feature	Flexible, Adjustable Band
Form Factor	Case

WARRANTY AND SUPPORT

BoxWave products are designed for quality and durability. For information regarding returns or support, please refer to the retailer's return policy or contact BoxWave Corporation directly.

Manufacturer: BoxWave Corporation

Return Policy: Typically 30 days (refer to purchase platform for specific details).

For further assistance, please visit the official BoxWave website or contact their customer service.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B1G86CJJ>

More documents and user manuals: **<https://manuals.plus/>**