

[Manuals.plus](#) /

> [CAROMIO](#) /

> CAROMIO Heated Blanket Electric Throw 50x60 Inch - User Manual

## CAROMIO HMHB-5060a

# CAROMIO Heated Blanket Electric Throw 50"x60" User Manual

Model: HMHB-5060a

## IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your CAROMIO Heated Blanket. Failure to follow these instructions may result in fire, electric shock, or injury. Keep this manual for future reference.

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if wet.
- Do not use with damaged cords or plugs.
- Do not use with pointed objects.
- Always disconnect the power cord from the outlet when not in use or before cleaning.
- Do not dry clean.
- Do not iron.
- Do not use bleach.
- Ensure the controller is not covered during use to prevent overheating.
- This blanket is designed for household use only.

## PRODUCT FEATURES

- **Material:** Soft thickened flannel (220GSM) on one side and fluffy sherpa (200GSM) on the reverse.
- **Dimensions:** 50 inches x 60 inches.
- **Heat Levels:** 5 adjustable heat settings (86°F-112°F).
- **Auto-Off Timer:** 4-hour auto-off feature for safety and energy saving.
- **Safety:** ETL certified with advanced overheating protection.
- **Controller:** Easy-to-use controller with clear heat level indicators.
- **Power Cord:** 10-foot long power cord for flexible placement.

- **Versatility:** Detachable controller allows use as a regular blanket.

# One-click Operation for Easy Use



Image: Close-up of the CAROMIO heated blanket controller, showing buttons for High, Med, Low, Warm heat settings, and a 4-hour auto-off timer. This controller allows for easy adjustment of the blanket's temperature and timer settings.




Image: Diagram illustrating the layered construction of the CAROMIO heated blanket. It highlights the 220GSM fleece flannel, non-woven fabric, PTC/NTC heating wires for fast heating and safety, and 200GSM sherpa fabric for extra warmth and comfort. The diagram also indicates ETL certification.

## SETUP

1. **Unpack:** Carefully remove the heated blanket from its packaging.
2. **Inspect:** Check the blanket, power cord, and controller for any signs of damage. Do not use if damaged.
3. **Connect Controller:** Ensure the controller cable is securely plugged into the blanket's connector.
4. **Placement:** Lay the blanket flat on a bed, couch, or other desired surface. Ensure there are no kinks or folds in the heating wires.
5. **Plug In:** Plug the power cord into a standard 120V AC electrical outlet.



**10% THICKER**  
than others for better warmth

Image: The CAROMIO heated blanket draped over a light-colored couch, showcasing its grey flannel side and white sherpa lining. The controller is visible on the blanket, indicating it's ready for use. This image demonstrates a typical setup for the blanket in a living room setting.

## OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the controller to turn the blanket on. The indicator light will illuminate.
2. **Adjust Heat Level:** Press the heat level button to cycle through the 5 available heat settings: Warm, Low, Med, High. The corresponding indicator light will show the selected level. (86°F-112°F)
3. **Set Auto-Off Timer:** The blanket features a 4-hour auto-off timer for safety. It will automatically shut off after 4 hours of continuous use.
4. **Power Off:** Press the power button again to turn the blanket off. Unplug the blanket from the wall outlet when not in use.

Your browser does not support the video tag.

Video: An official product video from CAROMIO demonstrating the features of the Heated Blanket, including its flannel and sherpa sides

and how to operate the controller. This video provides a visual guide to using the blanket.

## MAINTENANCE

### Cleaning Instructions:

The CAROMIO Heated Blanket is machine washable. Follow these steps for proper cleaning:

1. **Disconnect:** Always unplug the blanket from the wall outlet and detach the controller from the blanket before cleaning.
2. **Machine Wash:** Wash the blanket in cold water on a gentle cycle.
3. **Detergent:** Use a mild detergent. Do not use bleach.
4. **Rinse:** Rinse thoroughly.
5. **Tumble Dry:** Tumble dry on low heat.
6. **Reshape:** After washing and drying, gently stretch the blanket to its original size for optimal performance.
7. **Storage:** Store the blanket in a cool, dry place when not in use.

### Care and Storage:

- Do not dry clean, as cleaning solvents may damage the insulation of the heating element.
- Do not iron the blanket.
- Avoid folding the blanket tightly when storing to prevent damage to the internal wiring.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Blanket does not heat.	Not plugged in correctly. Controller not securely connected to blanket. Power outlet not functioning. Overheating protection activated.	Ensure power cord is firmly plugged into a working outlet. Check that the controller cable is fully inserted into the blanket's connector. Test the outlet with another appliance. Unplug the blanket for 30 minutes, then plug back in.
Blanket heats unevenly.	Heating wires are folded or bunched.	Lay the blanket flat and smooth out any folds or creases.
Controller lights are flashing.	Internal error or safety feature activated.	Unplug the blanket from the wall outlet for 30 minutes. Reconnect and try again. If the issue persists, contact customer support.

## SPECIFICATIONS

- **Model:** HMHB-5060a
- **Dimensions:** 50"L x 60"W
- **Material:** 220GSM Flannel, 200GSM Sherpa (Polyester)
- **Heat Settings:** 5 Levels (86°F-112°F)
- **Auto-Off Timer:** 4 Hours

- **Power Cord Length:** 10 FT
- **Certification:** ETL Certified
- **Manufacturer:** CAROMIO
- **UPC:** 196336021991

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact CAROMIO customer service. Refer to the product packaging or the official CAROMIO website for contact details.

**Manufacturer:** CAROMIO

**Website:** [CAROMIO Store on Amazon](#)

