Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo ST19005-E

ChooChoo Farmhouse Nightstand with Charging Station

Model: ST19005-E | Brand: ChooChoo

1. Product Overview

The ChooChoo Farmhouse Nightstand is a versatile bedside table designed to enhance your bedroom with both style and functionality. It features a rustic wooden top paired with a clean white body, a spacious drawer, and an open storage shelf. A key feature is the integrated charging station, providing convenient access to power for your electronic devices.



This image displays the ChooChoo Farmhouse Nightstand with Charging Station, featuring a white body and a wooden top, positioned next to a bed. A lamp and a small plant are on the top surface, and a woven basket is in the open storage shelf below the drawer.

2. Safety Information

- **Anti-Tip Safety:** Always secure the nightstand to the wall using the provided anti-tip kit to prevent accidental tipping, especially in households with children or pets.
- **Weight Limits:** Do not exceed the maximum weight capacity for the top surface (e.g., 50 lbs) or the drawer/shelf (e.g., 15 lbs). Overloading can compromise stability and cause damage.
- **Electrical Safety:** Ensure the charging station is plugged into a properly grounded electrical outlet. Do not overload the outlets. Keep liquids away from the charging station to prevent electrical hazards.
- **Assembly:** Follow all assembly instructions carefully. Do not use power tools for assembly unless specifically instructed, as this may overtighten screws and damage the wood.
- **Placement:** Place the nightstand on a flat, stable surface. Avoid placing it in areas with high humidity or direct sunlight, which can affect the wood finish.

3. Package Contents

Before beginning assembly, verify that all parts and hardware listed below are present and undamaged. If any components are missing or damaged, please contact customer support.



This image provides a comprehensive exploded view of the nightstand's structure, detailing each wooden panel, the drawer components, and the power strip, along with the necessary screws and dowels for assembly.

Components List:

- Top Panel with Charging Station
- Side Panels (Left & Right)
- Back Panel
- Bottom Shelf Panel
- Drawer Front Panel
- Drawer Side Panels (2)
- Drawer Back Panel
- Drawer Bottom Panel
- Drawer Handle

Hardware List:

- Screws (various sizes)

- Wooden Dowels
- Cam Locks and Cam Dowels
- Drawer Slides
- Anti-tip Kit
- Allen Wrench (if applicable)

4. Assembly Instructions

Assembly is required for this nightstand. Please follow these steps carefully. All parts are numbered for easy identification. A Phillips head screwdriver (not included) is recommended.

1. **Step 1: Prepare Components.** Unpack all components and hardware. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided labels.
2. **Step 2: Assemble the Main Frame.** Attach the side panels to the bottom shelf panel using the designated screws and dowels. Ensure all connections are secure.
3. **Step 3: Install the Back Panel.** Slide the back panel into the grooves on the side panels and secure it with small nails or screws as indicated in the diagram.
4. **Step 4: Attach the Top Panel.** Carefully place the top panel onto the assembled frame, aligning the pre-drilled holes. Secure it with screws. Ensure the charging station is correctly oriented.
5. **Step 5: Assemble the Drawer.** Connect the drawer side, back, and front panels using screws and dowels. Insert the drawer bottom panel into the grooves. Attach the drawer handle to the front panel.
6. **Step 6: Install Drawer Slides.** Attach the drawer slides to the inside of the nightstand frame and to the sides of the drawer, ensuring they are level and aligned for smooth operation.
7. **Step 7: Insert the Drawer.** Gently slide the assembled drawer into the nightstand frame. Test the drawer for smooth opening and closing.
8. **Step 8: Secure with Anti-Tip Kit.** For safety, attach the anti-tip kit to the back of the nightstand and to a wall stud, following the specific instructions provided with the kit.

5. Operating Instructions: Charging Station

The integrated charging station provides convenient power access for your devices.



This image highlights the integrated charging station on the nightstand's top surface, featuring two standard electrical outlets and two USB ports, designed for convenient charging of electronic devices.

- **Power Connection:** Plug the nightstand's power cord into a standard 120V AC wall outlet.
- **AC Outlets:** The charging station includes two 120V/12A AC outlets. Use these for devices requiring standard wall power, such as lamps or laptops.
- **USB Ports:** Two 5V/2.1A USB ports are available for charging smartphones, tablets, and other USB-powered devices.
- **Cord Management:** The power cord is approximately 6.5 feet long. Ensure the cord is not pinched or placed in a high-traffic area where it could be damaged.

6. Maintenance

Proper care will extend the life and appearance of your nightstand.



This image shows water beading on the wooden top of the nightstand, illustrating its waterproof desktop feature, which simplifies cleaning and protects against spills.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. For spills on the wooden top, wipe immediately.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Drawer Care:** If the drawer becomes stiff, apply a small amount of silicone lubricant to the drawer slides. Avoid forcing the drawer.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain stability.
- **Avoid Extreme Conditions:** Do not expose the nightstand to extreme temperatures, humidity, or direct sunlight for prolonged periods, as this can cause warping or fading.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Drawer sticks or does not slide smoothly.	Misaligned drawer slides, loose screws, or debris in the tracks.	Check that drawer slides are properly aligned and securely fastened. Clean tracks of any debris. Apply silicone lubricant to the slides.
Nightstand feels wobbly or unstable.	Loose fasteners or uneven floor surface.	Tighten all assembly screws. Ensure the nightstand is on a level surface; use furniture pads if necessary to stabilize. Ensure anti-tip kit is installed.
Charging station not working.	Not plugged in, power outage, or faulty outlet.	Verify the nightstand's power cord is securely plugged into a working wall outlet. Test the wall outlet with another device. Check for tripped circuit breakers.
Difficulty during assembly (e.g., screw holes not deep enough).	Minor manufacturing variation or incorrect tool usage.	Ensure you are using the correct screws for each step. Apply firm, even pressure when screwing. If a hole is too shallow, carefully deepen it slightly with a hand drill, ensuring not to drill through the other side.

8. Specifications

Detailed specifications for the ChooChoo Farmhouse Nightstand.



This graphic provides a detailed view of the nightstand's dimensions, including its depth, width, and height, along with measurements for the drawer and open storage shelf.

Feature	Detail
Brand	ChooChoo
Model Name	ST19005-E
Product Dimensions (D x W x H)	13.8"D x 17.7"W x 23.6"H
Color	White (with Wooden Top)
Material Type	Engineered Wood (MDF Boards)
Number of Drawers	1

Feature	Detail
Charging Station	2 Standard AC Outlets (120V/12A), 2 USB Ports (5V/2.1A)
Power Cord Length	Approx. 6.5 feet
Indoor/Outdoor Usage	Indoor
Assembly Required	Yes

9. Warranty and Support

ChooChoo is committed to providing high-quality products. For any questions regarding assembly, missing parts, or product issues, please contact ChooChoo customer support. Keep your purchase receipt for warranty claims.

Visit the official ChooChoo Store for more information and support:ChooChoo Store on Amazon

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B1J1S2LR

More documents and user manuals: **https://manuals.plus/**